

slochi 6b4fedda-0459-4ee1-89c1-d5ba4e6c7ba8

slochi 12-Inch LED Flush Mount Ceiling Light Fixture User Manual

Model: 6b4fedda-0459-4ee1-89c1-d5ba4e6c7ba8

INTRODUCTION

The slochi 12-Inch LED Flush Mount Ceiling Light Fixture is designed to provide efficient and versatile lighting for various indoor spaces. This ultra-thin fixture features adjustable color temperature settings from 3000K to 6500K and delivers 3200 lumens of brightness, ensuring optimal illumination for your environment. Its low-profile design and easy installation make it a practical lighting solution.

SAFETY INFORMATION

Please read all safety instructions before installation and use. Failure to follow these instructions may result in electric shock, fire, or other hazards.

- **Always turn off the power supply at the circuit breaker before beginning installation, maintenance, or cleaning.**
- Ensure the fixture is properly grounded to avoid electrical shock.
- Do not attempt to modify the fixture in any way. Any modifications may void the warranty and create safety risks.
- This product is designed for indoor use only.
- The fixture's casing is made of non-flammable plastic to enhance safety and prevent electrical risks.
- If you are unsure about any part of the installation process, consult a qualified electrician.

PACKAGE CONTENTS

Verify that all components are present before beginning installation:

- 1 x slochi 24W LED Ceiling Light Fixture
- 2 x Wire Connectors
- 2 x Mounting Screws
- 1 x User Manual

SPECIFICATIONS

Feature	Specification
Brand	slochi
Model Number	6b4fedda-0459-4ee1-89c1-d5ba4e6c7ba8
Dimensions	12"L x 12"W x 0.7"H
Wattage	24 Watts
Brightness	3200 Lumens
Color Temperature	3000K / 3500K / 4000K / 5000K / 6500K (Adjustable)
Material	Plastic, Polycarbonate (Shade)
Installation Type	Flush Mount
Power Source	AC
Water Resistance Level	Waterproof (IP44)
Light Source Type	LED
Control Method	Touch (via internal switch)

SETUP AND INSTALLATION

The slochi LED ceiling light is designed for easy installation, compatible with most standard junction boxes. One person can complete the installation in minutes.

- Turn off the Power:** Locate the circuit breaker controlling the light fixture's power and switch it off to prevent electrical shock.
- Attach Mounting Bracket:** Secure the provided mounting bracket to the junction box on the ceiling using the included screws.
- Connect the Wires:** Connect the fixture's wires to the corresponding household wires (live, neutral, ground) using the provided wire connectors. Ensure all connections are secure.
- Rotate Lamp Body:** Align the light fixture with the mounting bracket and rotate it clockwise until it locks securely into place.

Easy to Install



1. Turn off the power.



2. Attach mounting bracket.



3. Connect the wires.



4. Rotate lamp body.




Image: Step-by-step guide illustrating the easy installation process of the slochi LED ceiling light, including turning off power, attaching the mounting base, connecting wires, and rotating the lamp body to fix it.



Image: A diagram highlighting the super thin design of the slochi 12-inch LED ceiling light, showing its 0.7-inch thickness and compatibility with various junction boxes.

OPERATING INSTRUCTIONS

The slochi LED ceiling light offers five selectable color temperatures to suit different preferences and environments.

Adjusting Color Temperature

Before installation, you can select your desired color temperature using the small switch located on the back of the light fixture. The available settings are 3000K (Warm White), 3500K (Warm Neutral), 4000K (Cool White), 5000K (Daylight), and 6500K (Cool Daylight).

One light 5 color temperature,selectable



3000K

3500K

4000K

5000K

6500K

Select your ideal color temperature




Image: Visual representation of the five selectable color temperatures (3000K, 3500K, 4000K, 5000K, 6500K) and a close-up of the internal switch for selection.

General Operation

Once installed and the desired color temperature is set, the light fixture operates via a standard wall switch. Simply toggle the switch to turn the light on or off.






Image: Four panels showing the slochi LED ceiling light installed in different rooms: a kitchen, a bathroom, a hallway, and a living room, demonstrating its versatility.

MAINTENANCE

The slochi LED ceiling light is designed for minimal maintenance due to its sealed, dust-resistant, and IP44 waterproof construction.

- **Cleaning:** To clean the fixture, ensure the power is off. Use a soft, damp cloth to gently wipe the surface. Avoid abrasive cleaners or solvents, as these can damage the finish.
- **Durability:** The robust plastic casing is resistant to fading, rust, and corrosion, ensuring long-term performance.

TROUBLESHOOTING

If you encounter any issues with your slochi LED ceiling light, refer to the following common troubleshooting steps:

- **Light Does Not Turn On:**
 - Check if the power supply at the circuit breaker is on.

- Ensure all wire connections are secure and properly connected.
- Verify that the wall switch is in the 'ON' position.

- **Light Flickers:**

- Turn off the power and re-check all wire connections to ensure they are tight and secure.
- Ensure the fixture is not connected to a dimmer switch unless explicitly stated as compatible.

- **Incorrect Color Temperature:**

- Before installation, ensure the internal switch on the back of the fixture is set to your desired color temperature. This setting cannot be changed after installation without removing the fixture.

If the problem persists after attempting these steps, please contact slochi customer support for further assistance.

WARRANTY AND SUPPORT

slochi stands behind the quality of its products. This LED ceiling light fixture comes with:

- **365-Day Support Guarantee:** Comprehensive support for one year from the date of purchase.
- **30-Day Free Return & Exchange:** If you are not satisfied with your purchase, you may return or exchange the product within 30 days.

For warranty claims, technical support, or any questions regarding your slochi product, please refer to the contact information provided on your purchase receipt or visit the official slochi website.



Image: Information regarding slochi's 365-day support guarantee and 30-day free return and exchange policy.

© 2025 slochi. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question