

slochi 12 Inch 24W

slochi 12-Inch 24W LED Flush Mount Ceiling Light Fixture

INSTRUCTION MANUAL - MODEL: 12 INCH 24W

1. Introduction and Overview

Thank you for choosing the slochi 12-Inch 24W LED Flush Mount Ceiling Light Fixture. This manual provides essential information for the safe installation, operation, and maintenance of your new lighting fixture. Please read these instructions carefully before installation and retain them for future reference.

This ultra-thin LED ceiling light is designed for seamless integration into various indoor spaces, offering adjustable color temperatures and energy-efficient illumination.

2. What's in the Box

- 4 x 24W LED Ceiling Lights
- 8 x Connectors
- 8 x Screws
- 1 x User Manual

3. Key Features

- **Ultra-Thin Design:** With a thickness of only 0.7 inches, this fixture offers a low-profile and modern aesthetic that blends seamlessly with any flat ceiling.
- **Adjustable Color Temperature:** Choose from 5 color temperatures (3000K, 3500K, 4000K, 5000K, 6500K) to suit different lighting preferences and room ambiances.
- **Energy Efficient:** The 24W LED light produces 3200 lumens, has a lifespan exceeding 25,000 hours, and can save up to 90% on energy costs compared to traditional lighting.
- **Durable and Safe:** Constructed with a robust, non-flammable plastic casing to prevent electrical risks. It is IP44 waterproof and dustproof, making it suitable for damp and dusty environments like kitchens and laundry rooms.
- **Flicker-Free Illumination:** Designed to provide comfortable, soft light without flickering, reducing eye fatigue.

4. Setup and Installation

Installation of the slochi LED Flush Mount Ceiling Light is designed to be straightforward. Please ensure the power is turned off at the circuit breaker before beginning any electrical work.

Easy to Install



1. Turn off the power.



2. Attach mounting bracket.



3. Connect the wires.



4. Rotate lamp body.




Figure 4.1: Step-by-step installation guide.

Your browser does not support the video tag.

Video 4.1: Official slochi LED Flush Mount Ceiling Light Fixture installation guide.

Installation Steps:

1. **Turn off the Power:** Locate the circuit breaker controlling the light fixture and switch it off to prevent electrical shock.
2. **Attach Mounting Bracket:** Secure the provided mounting bracket to the junction box on your ceiling using the included screws.
3. **Connect the Wires:** Connect the live, neutral, and ground wires from your ceiling to the corresponding wires on the

light fixture using the provided connectors. Ensure all connections are secure.

4. **Rotate Lamp Body:** Carefully push the light fixture up towards the ceiling and rotate it clockwise until it locks securely into the mounting bracket.

The user-friendly base design is compatible with 99% of junction boxes, simplifying the installation process.

5. Operating Instructions

Adjusting Color Temperature:

Your slochi LED ceiling light offers 5 selectable color temperatures. Before final installation, you can set your preferred color temperature using the switch located on the back of the fixture.




Figure 5.1: Visual representation of 5 selectable color temperatures.




Figure 5.2: Location of the color temperature selection switch.

To change the color temperature, remove the fixture from the ceiling (if already installed), locate the small switch on the back, and slide it to your desired setting (3000K, 3500K, 4000K, 5000K, or 6500K). Reinstall the fixture after making your selection.

6. Maintenance

The integrated design and IP44 rating of your slochi LED ceiling light make it dust-resistant and easy to clean. Simply wipe the surface with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these can damage the fixture's finish.

7. Troubleshooting

- **Light does not turn on:**
 - Ensure the power supply is connected correctly and the circuit breaker is on.
 - Check wire connections for looseness.

- **Light flickers:**
 - Verify that the fixture is securely installed and connections are tight.
 - Ensure the power supply is stable.
- **Incorrect color temperature:**
 - Refer to Section 5 to adjust the color temperature switch on the back of the fixture.

If problems persist, please contact customer support.

8. Specifications

Attribute	Value
Brand	slochi
Model	12 Inch 24W
Color	White
Material	Plastic (Polycarbonate)
Dimensions (L x W x H)	12"L x 12"W x 0.7"H
Wattage	24 watts
Brightness	3200 Lumen
Color Temperature	3000K-6500K Adjustable
Light Source	LED
Water Resistance Level	Waterproof (IP44)
Mounting Type	Flush Mount
Power Source	AC
Unit Count	4.0 Count

9. Warranty and Support

slochi is committed to providing high-quality lighting products. Your purchase includes a 365-day support guarantee. For returns or exchanges, a 30-day free return and exchange policy is available.



Figure 9.1: Warranty and support information.

For further assistance or inquiries, please refer to the contact information provided with your product packaging or visit the official slochi store online.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question