



[Manuals.plus](#) /

› [Vongrasig](#) /

› Vongrasig Tall Kitchen Pantry Storage Cabinet User Manual

Vongrasig SHX15754-WH-2

Vongrasig Tall Kitchen Pantry Storage Cabinet User Manual

Model: SHX15754-WH-2

1. INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your Vongrasig Tall Kitchen Pantry Storage Cabinet. Please read all instructions carefully before beginning assembly and retain this manual for future reference. This cabinet is designed to provide versatile storage in kitchen, dining, or living room environments.



Image 1.1: Front view of the Vongrasig Tall Kitchen Pantry Storage Cabinet.

2. SAFETY INFORMATION

WARNING: To prevent injury or property damage, always adhere to the following safety guidelines.

- Always ensure the cabinet is securely mounted to the wall using the provided wall attachments. Failure to do so may result in the cabinet tipping over, causing injury or damage.
- Do not overload shelves. Refer to the specifications section for weight capacities.

- Keep small parts and assembly hardware away from children during assembly.
- Assemble the cabinet on a soft, clean surface to prevent scratches.
- It is recommended to assemble this product with a companion.

3. PACKAGE CONTENTS

Before assembly, verify that all parts and hardware are present. If any components are missing or damaged, contact customer support immediately.

The package should contain:

- Cabinet panels (top, bottom, side, back, shelves, doors, drawer components)
- Hardware pack (screws, dowels, cam locks, hinges, drawer slides, handles, wall anchors)
- Instruction manual

4. ASSEMBLY INSTRUCTIONS

Follow these steps carefully. It is recommended to have a second person assist with assembly.

1. **Unpack and Identify Parts:** Lay out all panels and hardware. Match each piece to the corresponding label in the assembly diagram (not provided in this manual, refer to included diagram).
2. **Assemble the Base:** Connect the bottom panel to the side panels using the specified hardware. Ensure all connections are secure.
3. **Construct the Main Frame:** Attach the remaining side panels and internal dividers to form the main structure of the cabinet.
4. **Install Back Panels:** Secure the back panels to the frame. Ensure the appliance link charging hole is correctly oriented if applicable.
5. **Assemble and Install Drawer:** Follow the specific instructions for assembling the drawer box and installing the drawer slides into the cabinet frame. Insert the assembled drawer.
6. **Attach Doors:** Mount the hinges to the cabinet doors and then attach the doors to the cabinet frame. Adjust hinges as necessary for proper door alignment.
7. **Insert Shelves:** Place the adjustable shelves into the desired positions using the shelf pins.
8. **Install Handles:** Attach the handles to the doors and drawer.
9. **Secure to Wall:** Position the cabinet in its final location. Using the provided wall attachments, secure the cabinet to a wall stud to prevent tipping. This step is crucial for safety.



Image 4.1: The cabinet interior, showcasing various storage compartments and the removable wine rack.

5. USAGE

The Vongrasig Tall Kitchen Pantry Storage Cabinet offers versatile storage solutions.

- **Adjustable Shelves:** The cabinet features adjustable shelves that can be moved to different heights to accommodate items of various sizes. Simply remove the shelf pins, reposition them to the desired height, and reinsert the shelf.



Image 5.1: Illustration of the adjustable shelf feature, demonstrating three possible height settings.

- **Countertop:** The spacious countertop area is suitable for small appliances such as a microwave or coffee maker.
- **Drawer:** A convenient drawer provides enclosed storage for smaller items.
- **Acrylic Doors:** The upper cabinet doors feature clear acrylic panels, allowing visibility of stored items while keeping them protected.
- **Removable Wine Rack:** A dedicated removable wine rack is included for organized bottle storage.

6. MAINTENANCE


- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, which can damage the finish.
- **Spills:** Clean spills immediately to prevent staining or damage to the MDF material.
- **Hardware:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary.
- **Avoid Excessive Moisture:** Do not expose the cabinet to excessive moisture or humidity, as this can cause swelling or warping of the wood composite.

7. TROUBLESHOOTING

- **Wobbling Cabinet:** Ensure all assembly screws are fully tightened. Verify the cabinet is placed on a level surface. If wobbling persists, re-check wall attachments for secure installation.
- **Doors Not Aligning:** Adjust the hinges on the doors. Most hinges allow for minor adjustments in height, depth, and side-to-side positioning. Refer to the hinge manufacturer's instructions if specific adjustments are unclear.
- **Drawer Sticking:** Check that the drawer slides are installed correctly and are free of obstructions. Ensure all screws on the slides are tight.
- **Missing Parts:** If any parts are missing or damaged upon arrival, do not proceed with assembly. Contact customer support for replacement parts.

8. SPECIFICATIONS

Feature	Detail
Brand	Vongrasig
Model Number	SHX15754-WH-2
Color	White
Overall Dimensions (W x D x H)	41.3" x 15.7" x 68"
Material	High-quality MDF board
Number of Compartments	7
Number of Shelves	8 (including fixed and adjustable)
Special Feature	Adjustable Shelves, Removable Wine Rack, Acrylic Doors
Mounting Type	Floor Mount (with wall attachments for stability)
Assembly Required	Yes
Item Weight	97 Pounds



Product size

Overall size : 41.3" L x 15.7" W x 68" H



Image 8.1: Detailed product dimensions and internal measurements.

9. WARRANTY AND SUPPORT

For any issues, missing parts, or questions regarding your Vongrasig Tall Kitchen Pantry Storage Cabinet, please contact customer support.

To contact the seller:

1. Log in to your Amazon account.
2. Navigate to "Your Orders".
3. Find the order ID for your purchase.
4. Click on "Contact seller".

Please have your order ID and model number (SHX15754-WH-2) ready when contacting support to expedite assistance.