

[Manuals.plus](#) /

> [EROMMY](#) /

> EROMMY 13 x 13 Ft Outdoor Gazebo User Manual

EROMMY PXHWGB118YE

EROMMY 13 x 13 Ft Outdoor Gazebo User Manual

Model: PXHWGB118YE

1. INTRODUCTION AND PRODUCT OVERVIEW

This manual provides essential information for the assembly, operation, maintenance, and troubleshooting of your EROMMY 13 x 13 Ft Outdoor Gazebo. This gazebo is designed to provide a comfortable and protected outdoor space, featuring a spacious 6-sided design, a dual-layer roof for enhanced ventilation and wind resistance, and high-quality, UV-protective, and waterproof fabric.

The gazebo includes removable high-density nettings to offer protection from insects and enhance privacy. Its sturdy powder-coated steel frame ensures durability and stability for various outdoor settings.




Image 1.1: The EROMMY 13 x 13 Ft Outdoor Gazebo installed in a backyard, showcasing its spacious design and integrated mosquito netting.

2. IMPORTANT SAFETY INFORMATION

Always follow the assembly instructions carefully. Use appropriate tools for assembly and disassembly. Keep children and pets away from the gazebo during assembly and disassembly. Do not exceed the weight limit of the gazebo. Secure the gazebo to a stable foundation to prevent it from tipping over in windy conditions. Always inspect the gazebo for any damage before use.

While the gazebo is designed with wind resistance, it is recommended to disassemble or secure it further during extreme weather conditions such as strong winds, heavy snow, or severe thunderstorms to prevent damage and ensure safety.

3. SETUP AND ASSEMBLY

The EROMMY gazebo is designed for straightforward assembly. All necessary hardware and clear instructions are included in the packaging. It is highly recommended that at least two people participate in the assembly process, especially when attaching the roof canopy, to ensure safety and ease of installation.

3.1. Packing List Verification

Before beginning assembly, unpack all components and verify them against the packing list provided in your instruction manual. Ensure all parts are present and undamaged.



Image 3.1: Visual representation of the main components included in the EROMMY Gazebo package: the frame (assembly required), two canopy tops, six netting walls, and twelve ground nails.

3.2. Frame Assembly

Begin by assembling the powder-coated steel frame. Follow the numbered steps in the provided instruction manual. Ensure all connections are secure and tightened appropriately. The frame is supported by 6 steel poles and includes 12 ground stakes for enhanced stability.



Image 3.2: Close-up details of the gazebo's structural components, including the top with 6 steel supporting ribs, a convenient central hook, durable beam frame for reliable support, and ground nails for enhanced stability.

3.3. Canopy and Netting Installation

Once the frame is erected, install the dual-layer canopy. The canopy is crafted from 180 g/m² polyester fabric, providing 99% UV protection and waterproofing. Attach the 6 removable high-density nettings to the frame. These nettings are designed to keep mosquitoes out, protect privacy, and can be easily installed or removed.



Image 3.3: A close-up view of the removable netting system, highlighting its ease of installation and portability.

4. OPERATING YOUR GAZEBO

Your EROMMY gazebo is designed for versatile outdoor use, offering comfort and protection in various conditions.

4.1. Ventilation and Airflow

The unique double-layer roof structure promotes excellent ventilation, maintaining a cooler temperature inside the gazebo compared to single-layer designs. The top mesh design further enhances air circulation and reduces heat buildup.



Image 4.1: An illustration of the double roof design, emphasizing its benefits for waterproofing, ventilation, and anti-mosquito features.

4.2. Sun and Weather Protection

The canopy fabric provides 99% UV protection, shielding occupants from harmful sun rays. It is also waterproof, offering protection during light rain. For heavy rain, some leakage may occur, and it is advisable to seek additional

shelter or temporarily remove items that could be damaged by water.




Image 4.2: The gazebo's performance in different weather conditions, illustrating its ventilation, sun-proof, and waterproof capabilities.

4.3. Using the Central Hook

The gazebo includes a hook at the top of the interior frame. This hook can be used for hanging lightweight items such as fans, lights, or decorative elements to enhance your outdoor experience.



Image 4.3: A detailed view of the canopy's central hook, indicating its use for ceiling fans, chandeliers, or hanging plants.

5. MAINTENANCE

Regular maintenance will extend the life and appearance of your EROMMY gazebo.

5.1. Fabric Care

The polyester canopy fabric is waterproof and UV-resistant. To clean, gently wipe with a damp cloth and mild soap. Avoid harsh chemicals or abrasive cleaners, as these can damage the fabric's protective coating. Ensure the canopy is completely dry before storing to prevent mold and mildew.




Image 5.1: A magnified view of the high-quality fabric, highlighting its twin-needle process for durability and resistance to tearing.

5.2. Frame Care

The steel frame is powder-coated to resist rust and corrosion. Periodically inspect the frame for any signs of wear, rust, or loose connections. Clean the frame with a damp cloth. If rust spots appear, clean them and apply a rust-inhibiting paint to prevent further corrosion.

5.3. Netting Care

The high-density nettings can be cleaned with mild soap and water. Inspect them regularly for any tears or damage. While durable, excessive force can cause tearing.

6. TROUBLESHOOTING

This section addresses common issues you might encounter with your gazebo.

6.1. Assembly Difficulties (Misaligned Holes/Warped Metal)

If you encounter difficulties aligning holes or connecting poles during assembly, ensure that all parts are oriented correctly according to the manual. Sometimes, slight adjustments or gentle pressure may be needed. Avoid forcing components, as this can cause damage. If a part appears significantly warped or misaligned, contact customer support for assistance.

6.2. Water Leakage

While the canopy is waterproof, some leakage may occur during heavy or prolonged rain, particularly at seams or where water may pool. Ensure the canopy is taut and properly stretched to allow water to run off. For added protection, consider applying a seam sealer to the canopy seams.

6.3. Netting Tears

The netting is designed to be durable but can tear under excessive stress or sharp objects. Inspect nettings regularly. Small tears can often be repaired with a patch kit or strong adhesive suitable for fabric. For significant damage, replacement nettings may be available from the manufacturer.

6.4. Stability Issues

Ensure all ground stakes are fully inserted into stable ground. For additional stability, especially in areas prone to strong winds, consider using heavier-duty ground anchors or securing the gazebo to a permanent structure if possible. Always ensure the frame connections are tight.

7. SPECIFICATIONS

Brand	EROMMY
Model Number	PXHWGB118YE
Material	Metal (Frame), 180 g/m ² Polyester Fabric (Canopy)
Product Dimensions	78"L x 78"W x 108"H (Approximate)
Floor Area	169 Square Feet
Item Weight	62 Pounds
Water Resistance Level	Waterproof
UV Protection	Yes (99%)
Assembly Required	Yes
Occupancy	12-14 People
Color	Beige



Image 7.1: A diagram illustrating the stable hexagonal structure and key dimensions of the gazebo, including height and width.

8. WARRANTY AND SUPPORT

EROMMY stands behind the quality of its products. If you have any questions about the product, assembly, or encounter any issues, do not hesitate to reach out to us. Please refer to your purchase documentation for specific

warranty terms and contact information.

Typically, products are eligible for returns or replacements within 30 days of purchase, subject to the retailer's policy. Extended protection plans may also be available for purchase separately to cover your investment for a longer period.