Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- Kidsneed /
- > Kidsneed SM935A Video Baby Monitor User Manual

Kidsneed 35A

Kidsneed SM935A Video Baby Monitor User Manual

Model: SM935A

Your trusted companion for monitoring your little one.

Introduction

Thank you for choosing the Kidsneed SM935A Video Baby Monitor. This manual provides detailed instructions to help you set up, operate, and maintain your new baby monitor, ensuring a safe and secure environment for your child. Please read this manual thoroughly before use and keep it for future reference.

Package Contents

Please check the package contents to ensure all items are present:

- 1 x Parent Unit (Monitor)
- 1 x Baby Unit (Camera)
- 2 x Power Adapters
- 1 x User Manual

Setup Guide

- 1. **Charging the Parent Unit:** Connect one power adapter to the Parent Unit and plug it into a power outlet. Charge the unit fully before first use (approximately 4 hours for 1200mAh battery).
- 2. **Powering the Baby Unit (Camera):** Connect the second power adapter to the Baby Unit and plug it into a power outlet. The camera requires continuous power to operate.
- 3. **Positioning the Baby Unit:** Place the Baby Unit in a location that provides a clear view of your baby's crib or play area. Ensure it is at least 3 feet (1 meter) away from the baby to avoid cord hazards. The camera can be tabletop mounted or wall-mounted.
- 4. **Pairing (Pre-paired):** The Parent Unit and Baby Unit are pre-paired at the factory. If re-pairing is needed, refer to the "Troubleshooting" section.



Image: Kidsneed SM935A Baby Monitor showing the parent unit and camera.

Operating Instructions

- 1. Power On/Off: Press and hold the power button on both the Parent Unit and Baby Unit to turn them on or off.
- 2. Screen Display: The 3.5-inch large display on the Parent Unit will show the live video feed from the Baby Unit.
- 3. **Remote Pan/Tilt/Zoom:** Use the directional buttons on the Parent Unit to remotely pan (left/right), tilt (up/down), and zoom (in/out) the camera lens to get a better view of your baby. Ensure the pan/tilt mode is active by pressing the corresponding button.
- 4. **Two-Way Talk:** Press and hold the microphone button on the Parent Unit to speak to your baby through the Baby Unit's speaker. Release the button to hear your baby.
- 5. Volume Adjustment: Use the volume buttons on the Parent Unit to increase or decrease the sound level.
- 6. Brightness Adjustment: Use the brightness buttons on the Parent Unit to adjust the screen brightness.
- 7. **Lullabies:** Select from 4 pre-programmed lullabies to play through the Baby Unit. Access this feature via the menu.
- 8. **Temperature Monitoring:** The Baby Unit has a built-in temperature sensor. The room temperature will be displayed on the Parent Unit. You can switch between Fahrenheit and Celsius in the settings.
- 9. **ECO Mode (Voice Activation):** Activate ECO mode to conserve battery. The screen will turn off, and sound will be muted until a sound above a set threshold is detected from the baby's room.
- 10. Feeding Timer: Set reminders for feeding times (2, 4, or 6 hours) using the menu options.



Image: Parent unit showing live feed and control buttons.



Image: Remote pan and tilt in action, showing the camera's wide coverage.

Key Features

- 3.5" Large Display: Provides a clear and comprehensive view of your baby.
- Remote Pan/Tilt/Zoom: Control the camera's viewing angle and zoom level directly from the parent unit.
- Night Vision: Automatic infrared night vision for clear monitoring in low-light conditions.
- Two-Way Talk: Communicate with your baby from another room.

- Smart Temperature Monitoring: Built-in sensor alerts you to temperature changes in the baby's room.
- Lullabies: Soothe your baby with pre-programmed melodies.
- Secure 2.4G FHSS Transmission: Ensures 100% privacy and security, free from Wi-Fi interference and hacking risks.
- Long Range: Up to 960 feet of reliable signal transmission.
- **Multi-Camera Expandability:** Supports up to four cameras for monitoring multiple rooms or children (additional cameras sold separately).
- VOX Mode (Eco Mode Voice Activation): Conserves battery by activating the screen and sound only when noise is detected.
- Sound Activated LEDs: Visual indication of sound levels from the baby's room.
- Alarm/Timer Setting: Customizable alerts for feeding or other routines.





Remote Pan Tilt Zoom



Infrared Night Vision



Two Way Communication



Room Temperature Display



Zoom In/Out



Lullabies Playing



Up to 960 ft Range



1200mah Battery

Image: Visual representation of the monitor's key features.

Care and Maintenance

- Cleaning: Use a soft, dry cloth to clean the surfaces of the Parent Unit and Baby Unit. Do not use abrasive cleaners or solvents.
- Battery Care: For optimal battery life, fully charge the Parent Unit before first use. Avoid extreme temperatures.
- Storage: If storing the monitor for an extended period, ensure both units are powered off and stored in a cool, dry place.
- Placement: Keep units away from direct sunlight, heat sources, and moisture.

Troubleshooting

| Problem | Possible Cause | Solution |
|---|--|---|
| No picture/sound on Parent Unit. | Units are not powered on or not paired. | Ensure both units are plugged in and powered on. If still no connection, try repairing (refer to manual for pairing steps, typically involves pressing a pair button on the camera and initiating pairing from the monitor menu). |
| Poor signal reception. | Units are too far apart or obstructions are present. | Move the Parent Unit closer to the Baby Unit. Reduce obstacles like thick walls or other electronic devices. |
| Screen freezes or unresponsive. | Temporary software glitch. | Turn off both units, unplug them, wait a few seconds, then plug them back in and power on. |
| Battery drains quickly. | ECO mode is off or screen brightness is too high. | Activate ECO mode. Reduce screen brightness. Ensure the battery is fully charged before each use. |

Specifications

• Model: SM935A

• Display Size: 3.5 inches

• Connectivity: 2.4GHz FHSS (Wireless)

• Parent Unit Battery: 1200 mAh Lithium Ion (included)

Range: Up to 960 feet (line of sight)Video Capture Resolution: 480p

Power Source: Battery Powered/Corded Electric
Dimensions (Parent Unit): 5.2 x 4.1 x 6.4 inches

• Weight: 1.21 pounds

• Indoor/Outdoor Usage: Indoor

• Manufacturer: Kidsneed

Warranty and Support

For warranty information and customer support, please refer to the contact details provided on the product packaging or visit the official Kidsneed website. Keep your purchase receipt as proof of purchase for warranty claims.

Related Documents - 35A



Kidsneed SM935A Video Baby Monitor: Features, Setup, and FAQs

Comprehensive guide to the Kidsneed SM935A Video Baby Monitor, covering specifications, setup instructions, and frequently asked questions for remote pan-tilt-zoom camera and audio monitoring.



Kidsneed SM935C Baby Monitor User Manual

User manual for the Kidsneed SM935C Digital Wireless Video Baby Monitor with a 3.5-inch color screen. Covers setup, operation, safety guidelines, technical specifications, and troubleshooting for optimal use.



Kidsneed SM530 Video Baby Monitor User Manual

User manual for the Kidsneed SM530 Video Baby Monitor with a 5" LCD 720P screen. Includes setup, operation, functions, specifications, and troubleshooting.



Kidsneed SM530 Video Baby Monitor User Manual

User manual for the Kidsneed SM530 Video Baby Monitor with a 5" LCD 720P screen. Includes setup, operation, troubleshooting, and specifications for the baby monitor and camera.



Kidsneed Baby Monitor Lifetime Warranty and Support

Information regarding the active lifetime warranty and customer service for Kidsneed Baby Monitors. Contact support@kidsneed.top for assistance or to activate your warranty.