

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [homary](#) /

› [homary 4 Piece Outdoor Combo Sofa Set Instruction Manual \(Model HW221F1B37\)](#)

homary HW221F1B37

homary 4 Piece Outdoor Combo Sofa Set Instruction Manual

Model: HW221F1B37

1. IMPORTANT SAFETY INFORMATION

Please read all instructions carefully before assembly and use. Keep this manual for future reference.

- **Assembly Caution:** Exercise care during assembly. Follow all instructions provided.
- **Sharp Edges:** Be aware of potential sharp edges on the teak frame and rope accents, especially when handling the furniture around children and pets.
- **Weight Limit:** Do not exceed the maximum weight limit of 260 pounds for the entire set to ensure stability and prevent damage.
- **Placement:** Place the furniture on a flat, stable surface to prevent tipping.
- **Outdoor Use:** This furniture set is designed for outdoor use. While weather-resistant, prolonged exposure to extreme weather conditions may affect its longevity.

2. PACKAGE CONTENTS

Verify that all components are present before beginning assembly. If any parts are missing or damaged, please contact customer support.

- Two (2) Single Sofas
- One (1) Two-Seater Sofa
- One (1) Coffee Table
- Seat Cushions and Back Pillows for all sofas
- Assembly Hardware (screws, washers, Allen wrench)

3. ASSEMBLY INSTRUCTIONS (SETUP)

Before You Begin

- Clear a spacious area for assembly.
- Lay out all components and hardware.
- Tools required: Included Allen wrench. A Phillips head screwdriver may be helpful for some steps (not included).

Step-by-Step Assembly

Some assembly is required. The main structure of the sofas and coffee table may come partially pre-assembled. Cushions and pillows need to be attached.

1. **Unpack Components:** Carefully remove all items from the packaging. Retain packaging materials until assembly is complete.
2. **Assemble Sofa Frames:** If not pre-assembled, connect the back and side frames of the single and two-seater sofas using the provided screws and Allen wrench. Ensure all connections are secure but do not overtighten initially.
3. **Assemble Coffee Table:** If required, attach the legs or base to the coffee table top.
4. **Tighten All Screws:** Once all components are loosely assembled, go back and tighten all screws. *Note: Some screws may need to be tightened inside the woven rope sections. This can be tricky and tedious, requiring small quarter turns with the Allen wrench.*
5. **Place Cushions and Pillows:** Position the seat cushions and back pillows onto the assembled sofas.



Image 3.1: Overview of the assembled 4-piece outdoor sofa set.



Image 3.2: Detail of a single sofa, highlighting the teak wood and handwoven rope accents.



Image 3.3: Detail of the coffee table, showcasing its slatted teak top and woven base.

4. OPERATING INSTRUCTIONS

The homary 4 Piece Outdoor Combo Sofa Set is designed for comfortable outdoor lounging and entertaining.

- **Cushion Placement:** Ensure cushions are properly seated on the sofa frames for optimal comfort and stability.
- **Arrangement:** The individual pieces can be arranged to suit your outdoor space and preferences.
- **Coffee Table Use:** Use the coffee table for beverages, snacks, or decorative items. Avoid placing excessively hot items directly on the teak surface without protection.
- **Weather Protection:** While the set is all-weather resistant, consider covering it during heavy rain, snow, or prolonged periods of non-use to extend its lifespan.

5. CARE AND MAINTENANCE

Proper care will help maintain the appearance and longevity of your outdoor furniture set.

Teak Wood Care

- **Cleaning:** Clean teak wood with a soft brush or cloth and mild soapy water. Rinse thoroughly with clean water and allow to air dry.
- **Natural Patina:** Teak naturally weathers to a silver-gray patina over time. If you prefer to maintain the original golden-brown color, apply a teak sealer or oil annually.
- **Stains:** For stubborn stains, lightly sand the affected area with fine-grit sandpaper in the direction of the wood grain, then clean and re-oil if desired.

Cushion Care

- **Cleaning:** The cushions are made with waterproof polyester fabric. Spot clean with a mild soap solution and a soft cloth. For deeper cleaning, remove covers if possible and hand wash or machine wash on a gentle cycle with cold water. Air dry only.
- **Storage:** Store cushions indoors or in a waterproof storage box during inclement weather or prolonged periods of non-use to prevent mildew and fading.

Rope Accents Care

- **Cleaning:** Gently wipe the handwoven rope with a damp cloth and mild soap. Rinse with clean water. Avoid harsh chemicals or abrasive cleaners.
- **Inspection:** Periodically inspect the rope for any signs of wear or damage.



Image 5.1: Detail of the natural teak wood grain.



Image 5.2: Close-up of the comfortable beige cushion and woven rope detail.

6. TROUBLESHOOTING

If you encounter any issues with your homary outdoor sofa set, refer to the following common solutions:

- **Wobbly Furniture:** Ensure all screws are securely tightened. Check that the furniture is placed on a level surface. Adjust furniture position if necessary.
- **Cushions Feel Too Firm:** New cushions may feel firm initially. They will soften with use over time.
- **Discoloration of Teak:** Teak wood naturally changes color to a silver-gray patina when exposed to the elements. This is a normal process and does not affect the wood's durability. If you prefer the original color, refer to the Teak Wood Care section.
- **Mildew on Cushions:** If cushions develop mildew, clean them immediately using a solution of mild soap and water, or a specialized outdoor fabric cleaner. Ensure cushions are completely dry before storing.

7. PRODUCT SPECIFICATIONS

Feature	Detail
Brand	homary
Model Number	HW221F1B37
Material	Handwoven Rope, High Performance Canvas, Teak Wood
Color	Natural
Style	Modern
Item Weight	260 pounds
Product Dimensions (Single Sofa)	30.7 x 30.7 x 25.6 inches (780 x 780 x 650 mm)
Product Dimensions (2-Seater Sofa)	59.4 x 30.7 x 25.6 inches (1510 x 780 x 650 mm)

Feature	Detail
Product Dimensions (Coffee Table)	31.5 inch Diameter x 15.7 inches Height (800 mm Diameter x 400 mm Height)



Image 7.1: Single Sofa Dimensions.



Image 7.2: Two-Seater Sofa Dimensions.



Image 7.3: Coffee Table Dimensions.

8. WARRANTY INFORMATION

For specific warranty details regarding your homary 4 Piece Outdoor Combo Sofa Set, please refer to the warranty documentation included with your purchase or contact homary customer service directly. Protection plans may be available for purchase separately.

9. CUSTOMER SUPPORT

Should you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact homary customer service.

- **Email:** service@homary.com
- Please provide your order number when contacting customer service for faster assistance.