

Feasto GL4101S

Feasto GL4101S 4+1 Burner Propane Gas Grill Instruction Manual

MODEL: GL4101S | BRAND: FEASTO

1. Introduction

This manual provides essential information for the safe assembly, operation, and maintenance of your Feasto GL4101S 4+1 Burner Propane Gas Grill. Please read all instructions carefully before using the grill to ensure proper function and safety.

Your Feasto gas grill features a durable stainless steel construction, porcelain-enameled cast-iron grates, and a total of 36,000 BTU across four main burners and one side burner. It offers a generous 559 sq. in. cooking area, including a warming rack, and convenient side tables for food preparation.

2. Important Safety Information

WARNING: This product can expose you to chemicals including carbon monoxide, which is known to the State of California to cause birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov.

- Always use the grill outdoors in a well-ventilated area.
- Keep combustible materials at least 36 inches (91 cm) away from the top, back, and sides of the grill.
- Never store a spare LP cylinder under or near the grill.
- Check for gas leaks before each use. Refer to the full safety guidelines in the included owner's manual.
- Do not attempt to repair or alter the grill. Contact qualified service personnel for assistance.

3. Assembly Instructions

Proper assembly is crucial for the safe and efficient operation of your Feasto gas grill. Follow the steps outlined in the video below. It is recommended to have two people for assembly.

Your browser does not support the video tag.

Video Description: This video provides a detailed 3D animation of the assembly process for the Feasto GL4101S gas grill. It visually guides users through each step, from attaching the base frame and side panels to installing the main grill body, side tables, burners, and connecting the propane tank. The video highlights the placement of screws and components for clear understanding.

Assembly Overview:

1. **Base Frame Assembly:** Connect the bottom frame components using the provided hardware.
2. **Side Panel Attachment:** Secure the side panels to the assembled base frame.
3. **Wheel Installation:** Attach the wheels to one side of the base for mobility.
4. **Propane Tank Holder:** Install the propane tank support bracket.
5. **Main Grill Body Placement:** Carefully place the pre-assembled main grill body onto the frame.
6. **Side Table Installation:** Attach the left and right side tables, including the side burner unit.
7. **Ignition System Connection:** Connect the igniter wires and gas lines as instructed.
8. **Grates and Warming Rack:** Place the porcelain-enameled cast-iron cooking grates and the warming rack inside the grill.
9. **Handle Attachment:** Secure the lid handle.

4. Operating Instructions

Your Feasto gas grill is designed for ease of use. Follow these steps for safe and effective grilling.

Your browser does not support the video tag.

Video Description: This video showcases the Feasto 4-Burner Gas BBQ Grill in operation. It demonstrates the ignition process for both the main burners and the side burner, highlighting the ease of use and temperature control. The video also shows food being cooked on the grill, emphasizing the even heat distribution and the functionality of the side tables and utensil hooks.

4.1. Pre-Operation Checklist:

- Ensure the LP cylinder is securely connected and the gas valve is open.
- Verify all gas connections are tight and free of leaks.
- Confirm the grill is on a level, stable surface.

4.2. Lighting the Main Burners:

1. Open the grill lid.
2. Turn one main burner control knob to the HIGH position.
3. Immediately press and hold the electronic igniter button until the burner lights.
4. Once lit, release the igniter button. If the burner does not light within 5 seconds, turn the knob to OFF, wait 5 minutes, and repeat the process.
5. Repeat for other main burners as needed. Adjust heat using the control knobs.

4.3. Lighting the Side Burner:

1. Open the side burner lid.
2. Turn the side burner control knob to the HIGH position.
3. Immediately press and hold the electronic igniter button until the burner lights.
4. Once lit, release the igniter button. If the burner does not light within 5 seconds, turn the knob to OFF, wait 5 minutes, and repeat the process.
5. Adjust heat using the control knob.

4.4. Temperature Control:

The built-in thermometer on the lid allows you to monitor the internal temperature of the grill. Adjust the burner control knobs to achieve your desired cooking temperature. The porcelain-enameled cookbox provides strong heat retention for consistent cooking.



Image Description: A close-up view of the Feasto grill's lid, showing the integrated thermometer for temperature monitoring and the textured stainless steel handle for a secure grip.

4.5. Cooking Areas:

- **Main Cooking Area (422 sq. in.):** Ideal for searing, grilling, and cooking larger items. The porcelain-enameled cast-iron grates ensure even heat distribution and minimize sticking.
- **Warming Rack (137 sq. in.):** Use this upper rack to keep cooked food warm or to gently toast buns.
- **Side Burner (12,000 BTU):** Perfect for preparing sauces, boiling water, or cooking side dishes in a pot or pan.



Keep Warm Area 137 SQ.IN

Primary Cooking Area 422 SQ.IN

• Porcelain-enameled Cast Iron Cooking Grate

Image Description: An interior view of the Feasto grill, highlighting the large main cooking area with porcelain-enameled cast-iron grates and the elevated warming rack above.

4.6. Utensil Hooks:

Three integrated tool hooks on the side table provide convenient storage for your grilling utensils, keeping them within easy reach.

5. Maintenance

Regular maintenance will prolong the life of your grill and ensure optimal performance.

5.1. Cleaning the Cooking Grates:

- After each use, while the grates are still warm, use a grill brush to remove food residue.
- For deeper cleaning, remove the grates and wash with warm, soapy water. Rinse thoroughly and dry completely before reinstalling.

5.2. Cleaning the Cookbox and Burners:

- Ensure the grill is cool and the gas supply is off.
- Remove cooking grates and heat deflectors.

- Scrape any loose debris from the bottom of the cookbox into the grease tray.
- Clean burner ports with a wire brush if clogged. Ensure burner tubes are free of insect nests or debris.

5.3. Exterior Cleaning:

- Wipe stainless steel surfaces with a soft cloth and a stainless steel cleaner.
- Clean painted surfaces with mild soap and water.

6. Troubleshooting

If you encounter issues with your grill, refer to these common troubleshooting tips:

- **Burner Fails to Light:** Check if the LP cylinder valve is fully open. Ensure the igniter electrode is clean and properly positioned. Verify gas flow to the burner.
- **Low Flame/Uneven Heat:** Check for low gas in the LP cylinder. Inspect burner ports for clogs. Ensure gas lines are not kinked.
- **Flare-ups:** Excessive grease buildup can cause flare-ups. Clean the grill thoroughly. Trim excess fat from meats before grilling.

For more detailed troubleshooting, consult the full owner's manual.

7. Specifications

Feature	Specification
Brand	Feasto
Model Number	GL4101S
Product Dimensions (D x W x H)	50.4"D x 24"W x 45.3"H
Fuel Type	Gas (Propane)
Main Burner Count	4
Side Burner Count	1
Total Heating Power	36,000 BTU (4 x 9,000 BTU main burners) + 12,000 BTU (side burner) = 48,000 BTU Total
Cooking Surface Area	559 Square Inches (422 sq. in. main, 137 sq. in. warming rack)
Cooking System	Porcelain-enameled cast-iron grates
Material Type	Stainless Steel
Special Features	Built-In Thermometer, Side Tables, Utensil Hooks, Wheels
Item Weight	64 Pounds
UPC	850038350963

Product Dimension



COOKING AREA
422 SQ. IN.

COOKING POWER
4×9,000 BTU

SIDE BURNER COOKING POWER
12,000 BTU

Image Description: A diagram illustrating the key dimensions of the Feasto GL4101S gas grill, including overall height, width, depth, and the specific measurements of the main cooking area and warming rack.

8. Warranty and Support

Your Feasto GL4101S Propane Gas Grill comes with a **1-year warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use.

For product, shipping, or assembly issues, or to make a warranty claim, please contact Feasto Outdoors customer support:

- **Customer Care Hotline:** 1-470-580-8732
- **Email:** service@feastoutdoors.com

Please have your model number (GL4101S) and proof of purchase ready when contacting support.