

[manuals.plus](#) /

› [Lisowod](#) /

› [Lisowod L02 Mini Projector User Manual](#)

Lisowod L02 (YG471)

Lisowod L02 Mini Projector User Manual

MODEL: YG471

Lisowod: Where Quality Meets Innovation

1. Introduction

Welcome to the comprehensive user manual for your Lisowod L02 Mini Projector. This guide provides detailed instructions on setting up, operating, maintaining, and troubleshooting your device to ensure an optimal viewing experience. The L02 is designed for portability and versatility, offering high-quality projection with advanced features like 360° adjustable stand, electric focus, and auto keystone correction.

2. What's in the Box

Upon unboxing your Lisowod L02 Mini Projector, please ensure all the following items are present:

- L02 Mini Projector (1 unit)
- Power Adapter
- HDMI Cable
- Remote Control
- User Manual
- Lens Cleaning Paper



Image: The Lisowod L02 Mini Projector with its detachable stand, remote control, power adapter, and cables.

3. Product Overview

The Lisowod L02 Mini Projector is designed for ease of use and portability. Below is an overview of its key physical features and connectivity options.

3.1. Front and Side View



Image: Front view of the Lisowod L02 Mini Projector, showing the lens and the Lisowod branding.

3.2. Rear Panel and Connectivity

The rear panel of the L02 projector features various ports for connecting external devices:

- **USB Port:** For connecting USB drives to play media files.
- **HDMI Port:** For connecting laptops, gaming consoles, TV sticks, and other HDMI-enabled devices.
- **3.5mm Audio Jack:** For connecting external speakers or headphones.
- **Power Input:** For connecting the power adapter.

360° Adjustable & Detachable & Tool-Free Stand

No tools required for quick setup and removal.



VS

Other 
Only rotate 180°
non-detachable
limited portability

Image: Rear view of the Lisowod L02 Mini Projector, highlighting the USB, HDMI, 3.5mm audio, and power input ports.

4. Setup

4.1. Placement and Stand Adjustment

The Lisowod L02 features a 360° rotating, detachable stand, allowing flexible placement on walls, tables, or ceilings. Position the projector on a stable, flat surface. Adjust the stand to achieve your desired projection angle. The detachable design also enhances portability for outdoor use.

1080P & 4K support

60% increase in brightness for the same size



20000:1



Super-resolution
Technique



100%
RGB Color



Blue Light
Protection




Image: The Lisowod L02 Mini Projector positioned to project onto a ceiling, demonstrating its 360° adjustable stand.

4.2. Powering On and Initial Focus/Keystone Adjustment

Connect the power adapter to the projector and a power outlet. Press the power button on the projector or remote control to turn it on. The L02 features automatic $\pm 30^\circ$ vertical keystone correction for a rectangular image. For fine-tuning, use the remote control for one-touch motorized electric focus to ensure a sharp image.

Easily Achieve Perfect Image

Auto Vertical Keystone & Electric Focus & Zoom



Image: A projected image showing the automatic keystone correction and electric focus features of the Lisowod L02 Mini Projector.

5. Operating Instructions

5.1. Connecting to Wi-Fi

The L02 portable projector supports dual-band WiFi 6 (both 5G and 2.4G networks) for fast and stable wireless streaming. Navigate to the Wi-Fi settings in the projector's menu and select your network to connect.



Image: A smartphone screen mirroring content to the Lisowod L02 Mini Projector, illustrating its Wi-Fi 6 capabilities.

5.2. Bluetooth Connectivity

Equipped with Bluetooth 5.2, the L02 allows for easy and stable connections with external speakers or headphones for an enhanced audio experience. Access the Bluetooth settings in the menu to pair your devices.

Two Way Bluetooth 5.2

Quick to Find Your Device and Reduce Signal Interference



Image: The Lisowod L02 Mini Projector connected wirelessly to headphones and a portable speaker via Bluetooth 5.2.

5.3. Content Playback and Streaming

The L02 supports various input methods for content playback:

- **USB:** Insert a USB drive into the USB port to access and play media files directly.
- **HDMI:** Connect your laptop, gaming console, or TV stick to the HDMI port for high-definition video and audio.
- **Screen Mirroring:** The projector supports screen mirroring from phones. However, due to HDCP copyright restrictions, direct mirroring for streaming services like Netflix or Amazon Prime is not supported. For these services, it is recommended to use a TV Stick (e.g., Fire TV Stick) connected to the HDMI port or connect a laptop to the HDMI port and stream from the laptop's browser.

The projector also supports 70% zoom and 4:3/16:9 aspect ratios, allowing you to adjust the projection size without moving the projector.

6. Maintenance

To ensure the longevity and optimal performance of your Lisowod L02 Mini Projector, follow these maintenance guidelines:

- **Lens Cleaning:** Use the provided lens cleaning paper or a soft, lint-free cloth specifically designed for optical lenses to gently wipe the projector lens. Avoid using abrasive materials or harsh chemicals.
- **Exterior Cleaning:** Wipe the exterior of the projector with a soft, dry cloth. Do not use liquid cleaners directly on the device.
- **Ventilation:** Ensure the projector's ventilation openings are not blocked to prevent overheating. Keep the projector in a well-ventilated area during operation.
- **Storage:** When not in use for extended periods, store the projector in a cool, dry place, away from direct sunlight and extreme temperatures.

The L02 features a latest-generation light source technology with a lifespan of over 70,000 hours, providing years of reliable performance with minimal maintenance.

7. Troubleshooting

If you encounter any issues with your Lisowod L02 Mini Projector, refer to the following common problems and their solutions:

Problem	Possible Cause	Solution
Blurry Image	Incorrect focus or keystone setting.	Use the remote control for electric focus adjustment. Utilize auto keystone correction or manually adjust vertical keystone ($\pm 50^\circ$).
No Signal/No Picture	Incorrect input source selected; loose cable connection; HDCP restrictions.	Ensure the correct input source (HDMI, USB) is selected. Check all cable connections. For streaming services (Netflix, Amazon Prime), use a TV Stick or connect a laptop via HDMI.
No Audio	Volume too low; external audio device not connected or paired correctly.	Increase the projector's volume. If using external speakers/headphones, ensure they are properly connected via Bluetooth or the 3.5mm audio jack and are powered on.
Wi-Fi/Bluetooth Connection Issues	Interference; incorrect password; device out of range.	Ensure the projector is within range of your Wi-Fi router or Bluetooth device. Re-enter Wi-Fi password. Try restarting the projector and your network device.

8. Technical Specifications

Feature	Specification
Brand	Lisowod
Model Number	YG471
Display Resolution	Native 1920 x 1080 (1080P FHD)
Brightness	550 ANSI Lumens
Contrast Ratio	20,000:1
Connectivity Technology	Wi-Fi 6 (2.4G & 5G), Bluetooth 5.2, HDMI, USB

Feature	Specification
Keystone Correction	Automatic $\pm 30^\circ$ Vertical (Manual $\pm 50^\circ$)
Focus Adjustment	Electric Focus
Zoom Function	70%
Aspect Ratios	4:3 / 16:9
Built-in Speakers	Dual 8W Hi-Fi Speakers
Light Source Lifespan	Over 70,000 hours
Item Weight	1.54 pounds
Product Dimensions	6.77 x 5.65 x 3.13 inches

9. Warranty and Support

Lisowod is committed to providing ongoing support and assistance for your L02 Mini Projector. The product features a long-lasting light source designed for durability.

For any inquiries, technical assistance, or support needs, please contact our customer service team:

Email: support_us@lisowod.com

Our team is available 24/7 to ensure your experience remains efficient and seamless.