Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

3IngSeagulls DNZ006FUGU

3IngSeagulls Small Computer Desk with 4 Fabric Drawers

Model: DNZ006FUGU
Brand: 3IngSeagulls

Important Safety Information

Always assemble the desk according to the provided instructions. Adult supervision is required when children use the desk. The desk can support up to 16.64 pounds (7.5 kg) on the desktop. Do not overload the desk to prevent accidents. Ensure all connections are secure before use.

Package Contents

Before assembly, please verify that all components are present and undamaged. If any parts are missing or damaged, contact customer support.

- Desktop Panel
- Metal Frame Components (legs, crossbars)
- 4 Fabric Drawers (2 large, 2 small)
- Hardware Pack (screws, bolts, adjustable feet)
- Assembly Tools (Allen wrench, screwdriver)
- Instruction Manual

Assembly Instructions

Follow these steps carefully for proper assembly. All necessary tools are included in the package. Each item is labeled to simplify the process.

1. **Unpack and Identify Parts:** Lay out all components on a clean, soft surface to prevent scratches. Refer to the parts list in your manual to identify each piece.
2. **Assemble the Metal Frame:** Connect the leg frames using the provided crossbars and screws. Ensure the X-shaped frame is securely attached for stability. Do not overtighten screws until all parts are aligned.
3. **Attach Adjustable Feet:** Screw the adjustable feet into the bottom of the desk legs. These help stabilize the desk on uneven surfaces and prevent floor scratches.
4. **Install the Desktop Panel:** Carefully place the desktop panel onto the assembled metal frame and secure it with the designated screws.
5. **Assemble Fabric Drawers:** Fold the fabric drawers into shape. Insert the bottom panel and attach the drawer pulls.

6. **Insert Drawers and Configure Storage:** Place the assembled fabric drawers into their respective slots. The open shelf unit can be positioned on either the left or right side of the desk, offering a reversible design to suit your space.




Image: Product Dimensions. This diagram illustrates the overall dimensions of the desk and the individual sizes of the two types of fabric drawers.



Image: Durable Fabric Drawers. This image provides a detailed look at the fabric drawers, including a three-step visual guide on how to fold and assemble them for use.



Image: Reversible Storage Shelf. This image demonstrates the desk's reversible design, allowing the open shelf and drawer unit to be installed on either the left or right side of the desktop to fit various room layouts.

Operating Instructions

This desk is designed for versatile use in home offices, bedrooms, or study areas.

- **Using the Desktop:** The 33.5-inch desktop provides ample space for a laptop, notebook, and other work or study essentials. Its smooth surface is suitable for writing and various tasks.
- **Utilizing Fabric Drawers:** The four fabric drawers (two large front drawers and two smaller side drawers) offer convenient storage for office supplies, books, tech accessories, and personal items. The smooth-gliding, soft-close design ensures quiet operation.
- **Reversible Storage:** The desk's design allows you to configure the open shelf and drawer unit on either the left or right side of the desk during assembly, adapting to your specific room layout and preferences.



Image: Home Office Desk in Use. This image displays the desk in a functional home office setup, highlighting the spacious desktop, the two front fabric drawers, and the side storage unit with an extra shelf and two additional fabric drawers.

Maintenance and Care

To ensure the longevity and appearance of your desk, follow these maintenance guidelines:

- **Cleaning:** Wipe the desktop and metal frame with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, which can damage the finish.
- **Fabric Drawers:** For the fabric drawers, spot clean with a mild detergent and allow to air dry. Do not machine wash.
- **Regular Checks:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary to maintain stability.
- **Avoid Overloading:** Do not exceed the recommended weight capacity of 16.64 pounds (7.5 kg) on the desktop to prevent structural damage.
- **Protect from Moisture:** Avoid prolonged exposure to moisture or direct sunlight, which can cause warping or fading.

Troubleshooting

If you encounter any issues with your desk, refer to the following common problems and solutions:

- **Desk is Unstable/Wobbly:**
  - Check that all screws are securely tightened.
  - Adjust the leveling feet at the bottom of the legs to compensate for uneven floors.
  - Ensure the X-shaped frame is correctly installed and tightened.
- **Drawers Do Not Slide Smoothly:**
  - Ensure the fabric drawers are correctly assembled and not overloaded.
  - Check for any obstructions in the drawer slots.
- **Missing Parts or Damaged Components:**
  - Review the package contents list. If parts are missing or damaged upon arrival, contact customer support immediately for assistance.

Specifications

Brand	3IngSeagulls
Model Number	DNZ006FUGU
Product Dimensions	15.35"D x 30.43"W x 33.46"H
Color	Rustic Brown
Material Type	Wood, Metal
Number of Drawers	4 (fabric)
Item Weight	16.64 Pounds
Special Feature	Adjustable, Reversible

Warranty Information

Specific warranty details for this product may vary. Please refer to the documentation included with your purchase or contact the retailer/manufacturer directly for comprehensive warranty information. Generally, products are covered against manufacturing defects for a limited period from the date of purchase.

Customer Support

For further assistance, questions, or to report missing/damaged parts, please contact 3IngSeagulls customer support through the retailer where the product was purchased. Have your model number (DNZ006FUGU) and purchase date ready for quicker service.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DXFFWFN8

More documents and user manuals: **https://manuals.plus/**