

SIBRILLE MF30021

SIBRILLE Upgraded 2-in-1 Torchiere Floor Lamp (Model MF30021) Instruction Manual

Brand: SIBRILLE

Model: MF30021

1. INTRODUCTION

Thank you for choosing the SIBRILLE Upgraded 2-in-1 Torchiere Floor Lamp. This versatile lighting solution is designed to enhance your living space with adjustable brightness, color temperature, and flexible light positioning. Please read this manual thoroughly before assembly and operation to ensure safe and optimal use of your new floor lamp.

2. PACKAGE CONTENTS

Verify that all components are present and undamaged upon opening the package:

- Floor Lamp (main pole sections, base, main light head, reading light head)
- Remote Control
- User Manual (this document)

3. SAFETY INSTRUCTIONS

- Ensure the lamp is placed on a stable, level surface to prevent tipping.
- This product is designed for **indoor use only**. Do not expose to water or high humidity.
- The lamp uses integrated LED modules which are **non-replaceable**. Do not attempt to disassemble the light heads.
- Keep the power cord away from heat sources, sharp edges, and wet areas.
- Unplug the lamp from the power outlet before cleaning or performing any maintenance.
- Avoid direct prolonged exposure to the light source.
- This lamp is designed with no blue light hazard, making it safe for use in children's rooms.

4. ASSEMBLY INSTRUCTIONS

Assembly of the SIBRILLE Floor Lamp is required and designed to be straightforward. Follow these steps:

1. Carefully unpack all components from the box.
2. Attach the main pole sections together by screwing them clockwise until secure. Ensure the power cable runs freely through the pole.
3. Securely attach the assembled pole to the heavy base by screwing it clockwise.
4. Attach the main light head to the top of the pole and the flexible gooseneck reading light to its designated port on the pole.
5. Plug the power adapter into a standard 110V AC outlet.



Figure 1: Lamp dimensions and components.

5. OPERATING INSTRUCTIONS

5.1 Remote Control Operation

The lamp comes with a remote control for convenient operation. The remote can be magnetically attached to the lamp pole for easy access.

- **Power Button (Main Light):** Press to turn the main torchiere light On/Off.

- **CCT Button (Main Light):** Short press to cycle through 4 color temperatures (3000K Warm White, 4000K Neutral White, 5000K Daylight, 6000K Cool White).
- **Brightness +/- Buttons (Main Light):** Adjust the brightness level (10%-100%).
- **Power Button (Reading Light):** Press to turn the gooseneck reading light On/Off.
- **CCT Button (Reading Light):** Short press to cycle through 4 color temperatures for the reading light.
- **Brightness +/- Buttons (Reading Light):** Adjust the brightness level (10%-100%) for the reading light.
- **1-Hour Timer Button:** Activates a 1-hour timer for automatic shut-off.



Figure 2: Remote Control Functions.

Your browser does not support the video tag.

Video 1: Demonstration of the SIBRILLE 2-in-1 Torchiere Floor Lamp with Remote Control, showcasing its features and ease of use.

5.2 Touch Control Operation

The lamp pole features touch-sensitive buttons for direct control:

- **Main Light Button:** Controls the main torchiere light (On/Off, color temperature, brightness).
- **Reading Light Button:** Controls the gooseneck reading light (On/Off, color temperature, brightness).



Figure 3: Touch Control Buttons on Lamp Pole.

5.3 Light Adjustments

- **Brightness Adjustment:** Both lights offer 10%-100% stepless dimming.
- **Color Temperature Adjustment:** Choose from 3000K (Warm White), 4000K (Neutral White), 5000K (Daylight), and 6000K (Cool White).
- **Flexible & Rotatable Design:** The main light head can be rotated up to 270° to function as an uplighter or downlight. The gooseneck reading light is 360° rotatable, allowing precise light direction.
- **Independent Control:** Each light can be controlled separately or together, providing versatile lighting options for various activities and moods.
- **Memory Function:** The lamp remembers your last brightness and color temperature settings when turned off and on.



Figure 4: Four Adjustable Color Temperatures.

Handy Controller



Figure 5: Independent Control of Main and Reading Lights.

6. FEATURES OVERVIEW

- **Dual-Zone Smart Lighting:** Offers adjustable brightness (10%-100%) and color temperature (3000K-6500K) for both ambient and task lighting.
- **Flexible & Rotatable Design:** The main light rotates 270° and the gooseneck reading light rotates 360° for targeted illumination.
- **Bright & Independent Control:** Features two lights with a total output of 34 watts and 2050 lumens, each controllable via remote or touch.
- **Smart Control with Magnetic Attachment:** Convenient remote control that magnetically attaches to the lamp pole.
- **Integrated LED Technology:** Long-lasting 50,000-hour lifespan, eliminating the need for bulb replacements and reducing e-waste.
- **User-Friendly Features:** Includes a 1-hour timer and memory function to recall previous settings.

7. SPECIFICATIONS

Feature	Detail
---------	--------

Model Name	MF30021
Lamp Type	Floor Lamp
Light Source Type	LED (Integrated)
Wattage	34 watts
Light Output Maximum	2050 Lumens
Brightness Adjustment	10%-100% Dimmable
Color Temperature	3000K-6500K (Warm White, Neutral White, Daylight, Cool White)
Switch Type	Remote & Touch Button
Material	Metal, Plastic
Finish Type	Polished
Color	Black
Product Dimensions	9.84"D x 9.84"W x 71.65"H (approx. 10" Base Diameter, 72" Height)
Item Weight	11.27 Pounds (approx. 5.12 Kilograms)
Power Source	Corded Electric (110 Volts)
Special Features	1 Hour Timer, Adjustable Color Temperature, Dimmable, Memory Function
Assembly Required	Yes
Indoor/Outdoor Usage	Indoor
Water Resistance Level	Not Water Resistant

8. MAINTENANCE

- **Cleaning:** Ensure the lamp is unplugged before cleaning. Use a soft, dry cloth to wipe down the lamp pole and light heads. Avoid abrasive cleaners or solvents that may damage the finish.
- **LED Care:** The integrated LED modules are designed for a long lifespan (50,000 hours) and do not require bulb replacement.
- **Storage:** If storing the lamp, disassemble it carefully and keep all components in the original packaging or a protective container to prevent damage.

9. TROUBLESHOOTING

- **Lamp does not turn on:**
 - Check if the power cord is securely plugged into a working outlet.
 - Ensure the lamp is switched on using either the remote or the touch controls.
- **Remote control is not working:**
 - Verify that the remote control has working batteries.
 - Ensure there are no obstructions between the remote and the lamp's receiver.

- Try operating the lamp using the touch controls on the pole to confirm lamp functionality.
- **Light flickers or is inconsistent**
 - Check the power connection for any looseness.
 - Ensure the lamp is not connected to a dimmer switch other than its built-in dimming function.

10. WARRANTY AND SUPPORT

The SIBRILLE Upgraded 2-in-1 Torchiere Floor Lamp comes with a **2-year coverage** for manufacturing defects and a **30-day return policy** from the date of purchase. For warranty claims, technical support, or any questions not covered in this manual, please contact SIBRILLE customer support through your retailer or the official SIBRILLE website.

Please retain your proof of purchase for warranty purposes.