

WMARK NG-2025

WMARK NG-2025B Professional Cordless Hair Clipper User Manual

1. INTRODUCTION

Thank you for choosing the WMARK NG-2025B Professional Cordless Hair Clipper. This manual provides essential information for the safe and effective use of your new hair clipper. Please read these instructions carefully before first use and keep them for future reference.

2. PRODUCT OVERVIEW

Key Features

- **Professional Blades:** Zero Overlap High Carbon Stainless steel blades with R-angle processing for skin protection. Self-sharpening precision blades cut through all hair types.
- **Multiple Cutting Lengths:** Includes 6 attachment combs (1.5mm, 3mm, 4.5mm, 6mm, 10mm, 13mm) and an adjustable taper lever for customized cutting lengths.
- **Digital Display:** LED display shows remaining battery charge.
- **Cordless/Corded Operation:** Powered by a 2000mAh Li-ion battery, offering up to 240 minutes of cordless runtime after a 4-hour charge. Can also be used corded.
- **Powerful Motor:** 8W heavy-duty motor with 6500 RPM for efficient cutting, operating at a low noise level (below 60 dB).

Components and Accessories

The WMARK NG-2025B hair clipper comes with the following components:

- WMARK NG-2025B Hair Clipper
- 6 Attachment Guide Combs (1.5mm, 3mm, 4.5mm, 6mm, 10mm, 13mm)
- Power Adapter (110-220V dual-voltage)
- Cleaning Brush
- Lubricating Oil (typically included)

WMARK

PROFESSIONAL HAIR CLIPPER

NG-2025B



Image: Overview of the WMARK NG-2025B hair clipper highlighting its battery capacity, blade material, motor speed, and included accessories.

ACCESSORIES



Image: All accessories included with the WMARK NG-2025B hair clipper, showing the different sized guide combs, power adapter, and cleaning brush.

3. SETUP

Initial Charging

1. Before first use, fully charge the clipper for approximately 4 hours.
2. Connect the power adapter to the clipper's charging port and plug it into a suitable electrical outlet (110-220V).
3. The LED display will indicate the charging status. A full charge provides up to 240 minutes of cordless operation.

SHARP BLADES



Image: Battery specifications for the WMARK NG-2025B, showing 2500mAh capacity, 3-4 hours for a full charge, and 240 minutes of usage time.

Attaching Guide Combs

1. Ensure the clipper is turned off before attaching or detaching guide combs.
2. Select the desired guide comb length (1.5mm, 3mm, 4.5mm, 6mm, 10mm, or 13mm).
3. Align the comb with the clipper blade and push it firmly until it clicks into place.
4. To remove, gently pull the comb away from the blade.

4. OPERATING INSTRUCTIONS

Basic Operation

1. Press the power button to turn the clipper ON. The LED display will illuminate.
2. To turn OFF, press the power button again.

Cutting Hair

- For best results, ensure hair is clean and dry.
- Attach the desired guide comb for the desired hair length. For a closer cut, use without a comb.
- Use the adjustable taper lever on the side of the clipper to fine-tune cutting lengths between comb sizes or for blending. Push the lever up for a closer cut, and down for a longer cut.
- Hold the clipper with the blade teeth pointing upwards.

- Start cutting from the bottom of the head, moving upwards against the direction of hair growth.
- Use smooth, overlapping strokes.
- Regularly clear hair from the blades during use to maintain cutting efficiency.

POWERFUL MOTOR



- 8W Heavy-Duty Motor: Powerful and efficient cutting.
- 6500rpm: High-speed cutting for various hair types.
- Quiet Operation: Noise level below 60dB.
- Adjustable Taper Lever: Customizable cutting lengths.
- Variable Cutting Lengths: Enables close cuts to longer styles.

Image: Detailed view of the clipper blades, highlighting features such as zero overlap, high carbon stainless steel construction, precision, self-sharpening capability, zero-gapped design, and R-angle processing for safety.

LONG LASTING BATTERY



- 2000mAh Li-ion Battery: Long-lasting cordless power.
- 240 Minutes Cordless Runtime: Extended use on a single charge.
- 4 Hour Full Charge: Reasonable charging time.
- Corded Operation: All-day continuous use.
- 110-220V Dual Voltage: Worldwide compatibility.
- 2000mA Power Cord: Quick charging capability.
- Complimentary Power Adapter: Included for convenience.

Image: Illustration of the clipper's motor, emphasizing its 6500 RPM speed for powerful and efficient cutting.

5. MAINTENANCE

Cleaning the Blades

1. After each use, turn off the clipper and disconnect it from the power source if charging.
2. Use the provided cleaning brush to remove loose hairs from the blades.
3. For a more thorough cleaning, the blades can be carefully detached (refer to specific instructions if provided in packaging, otherwise proceed with caution).
4. Do not rinse the entire clipper under water. Only the blades may be rinsed if they are designed to be detachable and washable. Ensure they are completely dry before reattaching.

Oiling the Blades

1. After cleaning and before each use (or regularly), apply 1-2 drops of lubricating oil (typically included) to the teeth and heel of the blades.
2. Turn the clipper on for a few seconds to allow the oil to distribute evenly.
3. Wipe off any excess oil with a soft cloth.
4. Oiling helps maintain blade sharpness, reduces friction, and prevents rust.

Storage

Store the clipper in a cool, dry place, away from direct sunlight and moisture. Keep it out of reach of children.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Clipper does not turn on.	Battery is depleted.	Charge the clipper for 4 hours.
Clipper runs slowly or pulls hair.	Blades are dirty or not oiled.	Clean and oil the blades.
Clipper is not cutting effectively.	Hair buildup in blades; blades dull.	Clean blades thoroughly. Ensure blades are properly oiled. If blades are dull after extended use, consider professional sharpening or replacement.
Clipper gets hot during use.	Extended continuous use; blades need lubrication.	Allow the clipper to cool down. Ensure blades are properly oiled. Avoid excessively long continuous operation.

If you encounter issues not listed here or if solutions do not resolve the problem, please contact customer support.

7. SPECIFICATIONS

Feature	Detail
Model Number	NG-2025
Blade Material	High Carbon Stainless Steel

Feature	Detail
Motor Speed	6500 RPM
Power Source	Battery Powered (Cordless/Corded)
Battery Type	2000mAh Li-ion
Charging Time	Approx. 4 hours
Runtime	Up to 240 minutes
Voltage	110-220V (Dual Voltage)
Noise Level	Below 60 dB
Dimensions (LxWxH)	23.7 x 13.8 x 7.2 cm
Item Weight	790 g
Included Combs	1.5mm, 3mm, 4.5mm, 6mm, 10mm, 13mm

8. WARRANTY AND SUPPORT

The WMARK NG-2025B Professional Cordless Hair Clipper comes with a **12-month quality warranty** from the date of purchase. This warranty covers manufacturing defects under normal use.

For warranty claims, technical support, or any product-related inquiries, please contact WMARK customer service. Refer to your purchase documentation for specific contact details or visit the official WMARK website.

Please retain your proof of purchase for warranty validation.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question