

- Manuals.plus /
- › [Kircuit](#) /
 - › Kircuit AC/DC Adapter User Manual

Kircuit AC/DC Adapter for TechPlay Turntables and Devices

Kircuit AC/DC Adapter User Manual

Universal Power Supply for TechPlay Turntables and Compatible Devices

INTRODUCTION

This manual provides essential information for the safe and effective use of your Kircuit 12V AC/DC Adapter. This adapter is designed to provide reliable power to a range of compatible TechPlay devices, including various turntable and record player models. Please read this manual thoroughly before use.

The Kircuit AC/DC Adapter converts standard AC electrical power into the DC power required by your device, enabling operation or battery charging from any compatible electrical outlet.

PRODUCT OVERVIEW



Figure 1: Kircuit 12V AC/DC Adapter. This image shows the main adapter unit with its integrated power cord ending in a barrel connector, ready for connection to a compatible device.

The Kircuit AC/DC Adapter is a compact and portable power solution. It features a standard US plug for wall outlets and a barrel connector for device input. Its robust design ensures stable power delivery.



Figure 2: Adapter with 6.5 ft cord length. This image highlights the generous cord length of the adapter, providing flexibility in placement.

SETUP AND CONNECTION

1. **Verify Compatibility:** Before connecting, ensure your device requires a 12V DC input and has a compatible barrel connector. Refer to your device's original specifications or manual. This adapter is compatible with models such as TechPlay ODC17, ODC18, ODC19, ODC19BT, ODC26WD, ODC28SPK, ODC128, ODC128BT, ODC194, ODC38WD, TCP2916, and TCP2916WD.
2. **Connect to Device:** Insert the barrel connector of the Kircuit AC/DC Adapter firmly into the power input port of your compatible device.
3. **Connect to Power Outlet:** Plug the adapter's two-prong plug into a standard 100-240V AC electrical wall outlet. Ensure the outlet is easily accessible.



Figure 3: Adapter in use. The image shows the adapter plugged into a power strip, demonstrating a typical setup scenario on a desk.

Once connected, your device should power on or begin charging, depending on its design.

OPERATING INSTRUCTIONS

The Kircuit AC/DC Adapter operates automatically once connected to a power source and a compatible device. It provides a stable 12V DC output to power your device or charge its internal battery.

- Ensure the adapter is not covered to allow for proper ventilation during operation.
- Avoid placing the adapter in direct sunlight or near heat sources.
- Disconnect the adapter from the power outlet when not in use for extended periods.

MAINTENANCE AND CARE

To ensure the longevity and optimal performance of your Kircuit AC/DC Adapter, follow these simple maintenance guidelines:

- **Cleaning:** Disconnect the adapter from all power sources before cleaning. Use a soft, dry cloth to wipe the surface. Do not use liquid cleaners or aerosols.
- **Storage:** Store the adapter in a cool, dry place away from direct sunlight and extreme temperatures. Avoid tightly winding the cable to prevent damage.
- **Handling:** Do not drop, disassemble, or attempt to repair the adapter. This can cause damage and void any potential warranty.
- **Cable Integrity:** Regularly inspect the power cord and connector for any signs of fraying, cuts, or damage. If damage is observed, discontinue use immediately.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Device not powering on/charging.	Adapter not properly plugged in. Power outlet is not active. Device is not compatible. Adapter or device is faulty.	Ensure adapter is fully inserted into wall outlet and device. Test the outlet with another device. Verify your device's voltage and connector type match the adapter's specifications. If possible, test with another known-good adapter or device.
Adapter feels excessively hot.	Poor ventilation. Overload or short circuit. Faulty adapter.	Ensure adapter is in a well-ventilated area and not covered. Disconnect immediately. Ensure the device is not drawing excessive power. Discontinue use and replace the adapter.
Loose connection at device.	Incorrect connector size. Worn connector.	Confirm the barrel connector size is correct for your device. If the connector is worn, the adapter may need replacement.

If troubleshooting steps do not resolve the issue, please contact customer support.

SPECIFICATIONS

Feature	Detail
Brand	Kircuit
Manufacturer	Shenzhen Waweis Technology Co., Ltd
Input Voltage	100-240V AC (50/60Hz 0.3A)
Output Voltage	12V DC
Connector Type	BARREL
Compatible Devices	TechPlay ODC17, ODC19BT, ODC28SPK, ODC128, ODC128BT, ODC194, ODC38WD, TCP2916WD, and other compatible models.
Color	Black
Special Feature	100% Brand New, High Quality AC/DC Power Charger (non-OEM)

Feature	Detail
Cord Length	Approximately 6.5 ft

WARRANTY INFORMATION

Specific warranty details for this Kircuit product are not provided in this manual. For information regarding warranty coverage, terms, and conditions, please refer to the product packaging, the seller's website, or contact the seller directly.

CUSTOMER SUPPORT

For technical assistance, product inquiries, or support, please contact the seller or manufacturer through the platform where the product was purchased. Please have your product model number (if applicable) and purchase details ready when contacting support.

Manufacturer: Shenzhen Waweis Technology Co., Ltd

© 2025 Kircuit. All rights reserved. Information in this manual is subject to change without notice.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question

Open the live page

<https://manuals.plus/asin/B0DXK94W8Q>

More documents and user manuals: <https://manuals.plus/>