



[Manuals.plus](#) /

› [Sweetcrispy](#) /

› Sweetcrispy Executive Home Office Desk Chair Instruction Manual - Model 6002WT-H2sun

## Sweetcrispy 6002WT-H2sun

# Sweetcrispy Executive Home Office Desk Chair Instruction Manual

Model: 6002WT-H2sun

## INTRODUCTION

---

Thank you for choosing the Sweetcrispy Executive Home Office Desk Chair. This manual provides essential information for the proper assembly, operation, and maintenance of your new chair. Designed for comfort and support, this ergonomic chair features a high back, footrest, and lumbar support, making it suitable for extended periods of use in home or office environments. Please read these instructions carefully before assembly and retain them for future reference.



Image: Front view of the Sweetcrispy Executive Home Office Desk Chair in White.

## COMPONENTS OVERVIEW

Before beginning assembly, please ensure all components are present and undamaged. Refer to the assembly video for a visual guide to the parts included.

Video: This video demonstrates the installation steps and displays the accessories included with the executive chair.

Typical components include:

- Backrest and Seat Cushion
- Armrests (Left and Right)

- Chair Base with Casters
- Gas Lift Cylinder and Cover
- Mechanism Plate
- Retractable Footrest
- Lumbar Support Pillow
- Assembly Hardware (Screws, Allen Wrench)

## SETUP AND ASSEMBLY

---

Assembly of the Sweetcrispy Executive Home Office Desk Chair is designed to be straightforward. The chair comes with all necessary installation tools, instructions, and spare screws. It typically takes approximately 25 minutes to complete the assembly independently. For a visual guide, please refer to the installation video in the 'Components Overview' section.

### Assembly Steps:

1. Attach the casters to the chair base by firmly pressing them into the holes at the end of each leg.
2. Insert the gas lift cylinder into the center hole of the chair base. Place the cylinder cover over the gas lift.
3. Secure the armrests to the seat cushion using the provided screws and Allen wrench. Ensure they are firmly attached.
4. Attach the mechanism plate to the underside of the seat cushion, aligning the holes and tightening all screws. Ensure the front of the mechanism faces the front of the seat.
5. Connect the retractable footrest assembly to the designated points on the underside of the seat cushion, following the specific instructions for its attachment.
6. Carefully place the assembled seat onto the gas lift cylinder, ensuring it is centered and stable.
7. Attach the backrest to the seat assembly using the remaining screws.
8. Adjust the lumbar support pillow to your preferred height on the backrest.

Always ensure all screws are securely tightened before using the chair. Do not overtighten.

## OPERATING INSTRUCTIONS

---

Your Sweetcrispy Executive Home Office Desk Chair offers multiple adjustment features to customize your seating experience for optimal comfort and support.

### Key Adjustments:

- **Seat Height Adjustment:** Use the smooth lift lever located under the seat to adjust the seat height by approximately 3.2 inches. Pull the lever up while seated to lower, or pull up while standing to raise.
- **360° Swivel:** The chair is designed for full 360-degree rotation, allowing for easy movement and access within your workspace.
- **Reclining Backrest:** The backrest can be tilted and locked at various angles between 90° and 135°. Use the recline lever to adjust the angle and lock it into your desired position.
- **Rocking Function:** The chair features a rocking pressure adjustor. Turn the knob located under the seat to loosen or tighten the rocking tension according to your preference.
- **Retractable Footrest:** Pull out the footrest from beneath the seat to extend your legs for relaxation. Push it back in when not in use.
- **Adjustable Lumbar Support Pillow:** The lumbar support pillow can be moved up or down along the backrest to provide targeted support for your lower back.
- **Height Adjustable Armrests:** The armrests can be adjusted in height to suit different user preferences and desk heights.

# High Quality Interior Exterior Materials



Double Sponge Cushion  
High resilient



Eco-friendly  
PU leather



Waterproof  
Easy to wipe

Image: Multi-function Dynamic Adjustment features including detachable lumbar support, smooth lift lever, and retractable footrest.

# Multi-function Dynamic Adjustment



Image: Illustration of the 90-135 degree recline function and rocking pressure adjustor.

Video: This video demonstrates the ergonomic features and adjustments of the Sweetcrispy Executive Office Desk Chair.

Video: This video showcases the reclining function and footrest of the Sweetcrispy Home Office High Back Desk Chair.

## MAINTENANCE AND CARE

Proper care will extend the life and appearance of your Sweetcrispy chair.

- **Cleaning:** The premium PU leather can be cleaned by wiping with a soft, damp cloth to remove general dust and stains. Avoid harsh chemicals or abrasive cleaners.
- **Heat Exposure:** Keep the chair away from direct heat sources, such as radiators or direct sunlight, to prevent damage, cracking, or discoloration of the leather.
- **Regular Checks:** Periodically check all screws and bolts to ensure they remain tight. Retighten if necessary to maintain stability and safety.
- **Caster Care:** Keep the swivel wheels clean from debris (hair, dust, etc.) to ensure smooth and silent movement.

## TROUBLESHOOTING

If you encounter any issues with your Sweetcrispy Executive Home Office Desk Chair, please consider the following common solutions:

- **Chair is Wobbly:** Ensure all assembly screws are securely tightened. Check that the chair base is properly seated on the gas lift cylinder.
- **Gas Lift Not Functioning:** Verify that the gas lift lever is correctly engaged. If the issue persists, the gas lift cylinder may need replacement.
- **Difficulty Rolling:** Check casters for accumulated debris (hair, lint) and clean them thoroughly. Ensure casters are fully inserted into the base.
- **Recline Mechanism Stuck:** Ensure no obstructions are preventing the mechanism from moving freely. Check the tension knob for proper adjustment.

If these steps do not resolve the issue, please contact Sweetcrispy customer service for further assistance.

## SPECIFICATIONS

<b>Brand</b>	Sweetcrispy
<b>Model Name</b>	Sweetcrispy Executive Home Office Desk Chair
<b>Item Model Number</b>	6002WT-H2sun
<b>Color</b>	White
<b>Product Dimensions</b>	33.5"D x 32.28"W x 47.6"H
<b>Item Weight</b>	55.5 pounds
<b>Back Style</b>	High Back
<b>Special Features</b>	Adjustable Backrest, Adjustable Height, Arm Rest, Ergonomic, Foot Rest
<b>Reclining Position Count</b>	2 (90°-135°)
<b>Fill Material</b>	Sponge
<b>UPC</b>	717242940222

## IMPORTANT SAFETY INFORMATION

- Always assemble the chair strictly according to the instructions provided in this manual.
- Exercise caution when handling the chair due to its weight during assembly and relocation.
- Keep the chair away from heat sources to prevent damage to the leather and internal components.
- Do not stand on the chair or use it as a step stool.
- Ensure the chair is on a stable, level surface before use.
- Do not exceed the recommended weight capacity (not explicitly stated in provided data, but generally implied by 'Big Tall' and '300 lbs' in images/reviews, so I will omit a specific number to avoid hallucination, but keep the general warning).

## WARRANTY AND CUSTOMER SUPPORT

For any questions, concerns, or issues regarding your Sweetcrispy Executive Home Office Desk Chair, please do not hesitate to contact our customer service team. We are committed to providing support and ensuring your satisfaction.

Please refer to your purchase documentation or the Sweetcrispy official website for specific warranty details and contact information.

