

PRETZI PB70-8COL-BLK

PRETZI 70-inch Modern Fireplace TV Stand with 36-inch Electric Fireplace Instruction Manual

Model: PB70-8COL-BLK | Brand: PRETZI

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your PRETZI 70-inch Modern Fireplace TV Stand with a 36-inch Electric Fireplace. Please read all instructions carefully before beginning assembly or operation to ensure safe and proper use of the product.

Important Safety Information

- **Two-Package Delivery:** The product is shipped in two separate packages (fireplace insert and TV stand), which may arrive on different days. Verify that both packages are received before starting assembly.
- **Weight and Stability:** This product is heavy and large. Incorrect assembly may lead to tipping, posing a risk to children or pets. Always follow assembly instructions precisely.
- **Small Parts:** This product contains small parts, including the remote control, which can be a choking hazard for young children. Keep all small components out of reach of children.
- **Assembly:** Two-person assembly is recommended for safety and ease.

SETUP AND ASSEMBLY

Before you begin, ensure you have received both packages containing the TV stand components and the electric fireplace insert. Unpack all parts and verify against the included parts list. Lay out all components on a soft, clean surface to prevent scratches. Detailed step-by-step instructions are provided in the assembly manual included with your product. Please refer to that document for specific diagrams and hardware identification.

Key Assembly Considerations:

- **Two-Person Assembly:** Due to the size and weight of the components, assembly by two individuals is strongly recommended.
- **LED Lighting Connections:** When installing the under-panel LED lighting, ensure the USB lighting connections are positioned inward to reach the fireplace insert for proper connection. It is advisable to test the lighting strips and fireplace

functionality before fully securing them.

- **Fireplace Crystal Placement:** Before inserting the electric fireplace into the TV stand, place the decorative crystals (often labeled as "decorative stuff") inside the glass frame of the fireplace. This usually involves removing one screw to access the interior. Distribute the crystals evenly for the best visual effect. This step is easier to complete before the fireplace is fully installed into the stand.

PRODUCT SIZE




Figure 1: Product dimensions and illustration of two-package delivery.



Figure 2: Features of the TV stand including cable management and storage.

Your browser does not support the video tag.

Video 1: Overview of the 70-inch Modern Fireplace TV Stand with 36-inch Electric Fireplace, demonstrating its features and design.

OPERATION

Your PRETZI Fireplace TV Stand features both ambient LED lighting and a functional electric fireplace. Both can be controlled via the included remote control or the control panel on the fireplace unit.

Electric Fireplace Operation

The 36-inch electric fireplace offers realistic flame effects and heating functions. Use the remote control or the buttons on the fireplace unit to adjust settings.

- **Power:** Press the power button to turn the fireplace on or off.

- **Heat Settings:** Select between 750W (low heat) and 1500W (high heat) modes for optimal warmth and energy efficiency.
- **Timer:** Set an automatic shut-off timer for 1 to 8 hours.
- **Flame Effects:** Choose from 12 realistic 3D flame effects to create your desired ambiance.
- **Flame Brightness:** Adjust the flame brightness through 5 levels (V1 to V5) from darkest to brightest.




Figure 3: Electric fireplace controls and available flame effects.

LED Ambient Lighting Operation

The TV stand features integrated LED lighting with 20 color combinations to enhance your viewing experience. Use the remote control to cycle through colors and modes.



Figure 4: Demonstration of the 20 color LED lights for ambient illumination.

MAINTENANCE AND CARE

Proper care will extend the life and appearance of your TV stand and electric fireplace.

- **Cleaning Surfaces:** Use a soft, damp cloth to wipe down the MDF and particle board surfaces. Avoid abrasive cleaners or harsh chemicals that could damage the finish.
- **Mirrored Doors:** Clean mirrored surfaces with a glass cleaner and a lint-free cloth to prevent streaks.
- **Electric Fireplace:** Ensure the fireplace is turned off and unplugged before cleaning. Wipe the glass and exterior surfaces with a soft, damp cloth. Do not spray water directly into the unit.
- **Dusting:** Regularly dust all surfaces to prevent buildup.

TROUBLESHOOTING

If you encounter issues with your PRETZI Fireplace TV Stand, refer to the common problems and solutions below. For persistent issues, please contact customer support.

Problem	Possible Cause	Solution
Fireplace or TV Stand components missing upon delivery.	Product ships in two separate packages.	Verify receipt of both packages. If one is still missing after a reasonable delivery period, contact customer support with your order details.
Electric fireplace not functioning (e.g., faulty circuit board).	Internal component malfunction.	Contact customer support for troubleshooting assistance or a replacement part. Provide your order number and a description of the issue.
LED lights not working or not reaching connection.	Incorrect wiring or placement during assembly.	Ensure USB lighting connections are positioned correctly (inward) to reach the fireplace unit. Recheck all connections. Test before final assembly.
Decorative crystals not visible or difficult to place.	Crystals were not placed before fireplace insertion.	The crystals should be placed inside the fireplace glass frame before the fireplace is fully inserted into the TV stand. This may require temporarily removing the fireplace if already installed.

SPECIFICATIONS

Feature	Detail
Brand	PRETZI
Model Number	PB70-8COL-BLK
Material	Alloy Steel, Wood (MDF, Particle Board)
Product Dimensions (L x W x H)	70 x 14 x 24 inches (177.8 x 35.5 x 61 cm)
Item Weight	76.7 pounds (approx. 34.8 kg)
TV Compatibility	Supports TVs up to 80 inches
Electric Fireplace Size	36 inches (width)
Fireplace Heat Settings	750W / 1500W
Fireplace Timer	1-8 hours
Fireplace Flame Effects	12 colors, 5 brightness levels
LED Ambient Lighting	20 color combinations
Special Features	Adjustable Flame, Adjustable Thermostat, Dimmer, Multicolor Flame, Cable Management, Mirrored Doors, Stainless Steel Brackets

Feature	Detail
Load Capacity of Tabletop	250 lbs

WARRANTY AND SUPPORT

For any questions, concerns, or issues regarding your PRETZI Fireplace TV Stand, please contact our customer support team. We offer 24-hour customer support to assist you.

Refer to your purchase documentation for specific warranty details. Extended protection plans may also be available for purchase.

Contact Information: Please refer to the contact details provided in your product packaging or on the official PRETZI website for the most up-to-date support options.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question