Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Aspes AR855500E

Aspes AR855500E Refrigerator User Manual

Model: AR855500E | Brand: Aspes

1. Important Safety Information

Please read this manual carefully before using your new Aspes AR855500E refrigerator. Keep it for future reference. This manual contains important information regarding the installation, operation, and maintenance of the appliance. Failure to follow these instructions may result in injury or damage to the appliance.

- Ensure the appliance is unplugged before cleaning or performing any maintenance.
- Do not damage the refrigerant circuit. The refrigerant R600a is flammable.
- Do not use electrical appliances inside the food storage compartments unless they are of the type recommended by the manufacturer.
- This appliance is intended for household use only.
- Keep ventilation openings clear of obstruction.

2. Product Overview

The Aspes AR855500E is a compact refrigerator designed for efficient food preservation. It features a 127-liter capacity, a reversible door for flexible placement, and an energy efficiency class E rating. The appliance operates with a low noise level of 39 dB and utilizes R600a refrigerant.



Figure 2.1: Front view of the Aspes AR855500E refrigerator. This image shows the appliance's exterior, highlighting its white finish and the Aspes logo on the door.



Figure 2.2: Interior view of the Aspes AR855500E refrigerator. The image displays the internal layout, including three shelves, a crisper drawer, and door compartments, along with the LED interior lighting.




Figure 2.3: Energy label for the Aspes AR855500E refrigerator. This label indicates the appliance's energy efficiency class E, annual energy consumption of 90 kWh, 127-liter capacity, and a noise level of 39 dB. For more details, refer to the official EPREL database: EPREL Product Information.

3. Setup and Installation

3.1 Unpacking

Carefully remove all packaging materials. Inspect the refrigerator for any damage. Report any damage to your retailer immediately. Keep packaging materials out of reach of children.

3.2 Placement

- Place the appliance on a firm, level surface to ensure stability and proper operation.
- Allow adequate ventilation space around the refrigerator (at least 10 cm at the back and sides) to ensure efficient cooling and prevent overheating.
- Avoid placing the refrigerator in direct sunlight or near heat sources such as stoves, radiators, or heaters, as this will increase energy consumption.
- Do not install the appliance in areas where the temperature is likely to fall below 10°C or rise above 32°C.

3.3 Door Reversal

The door of the Aspes AR855500E refrigerator is reversible, allowing it to open from either the left or the right side. If you wish to change the door's opening direction, please consult a qualified technician or refer to detailed instructions typically found in a separate door reversal guide (not included in this general manual). This procedure usually involves moving hinges and covers.

3.4 First Use

- Before plugging in, clean the interior of the refrigerator with a damp cloth and a mild detergent. Dry thoroughly.
- After cleaning, wait at least 2-4 hours before plugging the appliance into the power outlet. This allows the refrigerant to settle.
- Once plugged in, set the thermostat to a medium setting and allow the refrigerator to cool for several hours before placing food inside.

3.5 Electrical Connection

Ensure the voltage and frequency indicated on the rating plate (located inside the appliance) match your household power supply. The appliance is designed to operate on 220 Volts. Use a properly grounded outlet. Do not use extension cords or multiple adapters.

4. Operating Instructions

4.1 Temperature Control

The Aspes AR855500E features a manual temperature control system, typically a dial located inside the refrigerator compartment. Turn the dial to adjust the cooling intensity:

- **Lower numbers (e.g., 1-2):** Less cooling, suitable for lighter loads or cooler ambient temperatures.
- **Higher numbers (e.g., 4-5):** More cooling, suitable for heavier loads or warmer ambient temperatures.
- **Recommended setting:** Start with a medium setting (e.g., 3) and adjust as needed based on food quantity and desired temperature.

Allow several hours for the temperature to stabilize after making an adjustment.

4.2 Food Storage Guidelines

- Store raw meat and fish in sealed containers on the lowest shelf to prevent dripping onto other foods.
- Dairy products, cooked foods, and leftovers should be stored on middle shelves.
- Fruits and vegetables are best kept in the crisper drawer to maintain freshness.
- Door shelves are suitable for bottles, jars, and eggs.
- Ensure all food is covered or sealed to prevent drying out and odor transfer.

4.3 Automatic Defrosting

This refrigerator features an automatic defrosting system in the refrigerator compartment. Frost that forms on the back wall will periodically melt and drain through an outlet at the back of the appliance. Ensure this drain hole is kept clear to prevent water accumulation.

5. Maintenance and Cleaning

Regular cleaning and maintenance will ensure optimal performance and extend the lifespan of your refrigerator.

5.1 Cleaning the Interior

- **Always unplug the appliance before cleaning.**
- Wash the interior with a solution of warm water and a mild, neutral detergent. Avoid abrasive cleaners or solvents.
- Rinse thoroughly and dry with a soft cloth.
- Clean the drain hole at the back of the refrigerator regularly to prevent blockages.

5.2 Cleaning the Exterior

- Wipe the exterior surfaces with a soft, damp cloth. For stubborn stains, use a mild detergent.
- Clean the condenser coils at the back of the appliance periodically (e.g., every 6-12 months) using a soft brush or vacuum cleaner. This improves efficiency.

5.3 Extended Absence

If the refrigerator will not be used for an extended period:

1. Unplug the appliance from the power outlet.
2. Remove all food items.
3. Clean and dry the interior thoroughly.
4. Leave the door slightly ajar to prevent odors and mold growth.

6. Troubleshooting

Before contacting customer service, please check the following common issues and solutions:

Problem	Possible Cause	Solution
Refrigerator does not operate.	No power supply. Power cord not properly plugged in. Thermostat set to '0' or 'OFF'.	Check power outlet. Ensure plug is firmly inserted. Adjust thermostat to a higher setting.
Temperature inside is not cold enough.	Door not closed properly. Frequent door opening. Large amount of warm food placed inside. Thermostat setting too low. Appliance near a heat source.	Check door seal and ensure it's closed. Reduce frequency of door opening. Allow food to cool before placing in refrigerator. Adjust thermostat to a higher setting. Relocate appliance away from heat sources.
Unusual noises.	Appliance not level. Parts vibrating. Normal operating sounds.	Adjust leveling feet. Check for loose items inside or on top. Gurgling, humming, or clicking sounds are normal for refrigerators.
Water on the bottom of the refrigerator compartment.	Drain hole blocked.	Clear the drain hole at the back of the compartment.

7. Specifications

Technical specifications for the Aspes AR855500E refrigerator:

Brand	Aspes
Model Number	AR855500E
Type	Refrigerator (Cyclic Technology)
Total Capacity	127 Liters
Energy Efficiency Class	E
Noise Level	39 dB
Refrigerant	R600a
Defrost System	Automatic (Refrigerator Compartment)

Door Type	Single, Reversible
Interior Lighting	LED
Control System	Manual
Number of Shelves	3
Dimensions (W x D x H)	55 cm x 58 cm x 85 cm
Weight	27 kg
Voltage	220 Volts
Plug Type	Type C/EF (2 pins)

8. Warranty and Support

Your Aspes AR855500E refrigerator comes with a manufacturer's warranty. Please refer to the warranty card included with your purchase for specific terms and conditions, including the warranty period and coverage details. For technical assistance, spare parts, or to report a fault, please contact your retailer or the official Aspes customer support. Contact information can typically be found on the manufacturer's website or in your purchase documentation.
When contacting support, please have your model number (AR855500E) and serial number (if applicable) ready.

© 2024 Aspes. All rights reserved. Information in this manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DXKQZL3Y

More documents and user manuals: **https://manuals.plus/**