

T22

User Manual: T22 2.4G+BT5.1 Dual Mode Vertical Mouse

Model: T22 | Brand: Generic

1. INTRODUCTION

Thank you for choosing the T22 2.4G+BT5.1 Dual Mode Vertical Mouse. This ergonomic mouse is designed for comfort and efficiency, featuring dual-mode connectivity (2.4G wireless and Bluetooth 5.1), a rechargeable battery, and adjustable DPI settings. Please read this manual carefully to ensure proper use and maintenance of your device.



Image: The T22 Dual Mode Vertical Mouse in black, showcasing its ergonomic design, red accents, and the included USB charging cable.

2. PACKAGE CONTENTS

Please verify that all items listed below are included in your package:

- 1 x T22 2.4G+BT5.1 Dual Mode Vertical Mouse
- 1 x USB Receiver (for 2.4G wireless connection)
- 1 x USB Charging Cable (Type-C, 1 meter)

- 1 x User Manual



Image: A visual representation of the T22 Vertical Mouse, its packaging, USB receiver, and charging cable, along with dimensions.

3. SETUP

3.1 Charging the Mouse

The T22 mouse comes with a built-in 600mAh lithium battery. Before first use, it is recommended to fully charge the mouse.

1. Connect the supplied USB Type-C charging cable to the charging port on the front of the mouse.
2. Connect the other end of the USB cable to a USB power source (e.g., computer USB port, USB wall adapter).
3. The mouse's indicator light will show charging status. A full charge typically takes approximately 1.5 hours and provides 1-2 months of usage.

Rechargeable Ergonomic Mouse

Long life to meet your office/gaming needs



Image: An illustration demonstrating the T22 Vertical Mouse being charged via its Type-C port, highlighting the 600mAh battery capacity and charging time.

3.2 Connecting the Mouse

The T22 mouse supports two connection modes: 2.4G Wireless and Bluetooth 5.1.



Image: The underside of the T22 Vertical Mouse, showing the optical sensor, product labels, and the switch for selecting between Bluetooth and 2.4G wireless modes.

3.2.1 2.4G Wireless Connection

1. Locate the USB receiver, usually stored in a compartment on the bottom of the mouse.
2. Plug the USB receiver into an available USB port on your computer.
3. Flip the switch on the bottom of the mouse to the "2.4G" position.
4. The mouse should automatically connect to your computer.

3.2.2 Bluetooth 5.1 Connection

1. Flip the switch on the bottom of the mouse to the "BT" position.
2. On your computer or device, open Bluetooth settings.
3. Search for new devices. The mouse should appear as "T22 Mouse" or similar.
4. Select the mouse to pair. Once paired, the connection is established.

4. OPERATING INSTRUCTIONS

The T22 Vertical Mouse is designed for intuitive use with standard mouse functions and additional features.

4.1 Button Functions

- **Left Click Button:** Standard left-click function.
- **Right Click Button:** Standard right-click function.
- **Scroll Wheel:** Scroll up/down, and middle-click function.
- **Forward/Backward Buttons:** Located on the side, typically used for navigating web pages or folders.
- **DPI Button:** Located near the scroll wheel, used to adjust cursor sensitivity.

4.2 DPI Adjustment

The mouse features four adjustable DPI levels: 800, 1200, 1600, and 2400 DPI. Press the DPI button to cycle through these settings. A higher DPI setting means the cursor moves faster across the screen with less physical mouse movement.

4.3 RGB Lighting

The mouse features seven-color lighting for an enhanced user experience. The lighting is typically active when the mouse is in use or charging.



Image: The T22 Vertical Mouse being used with both a laptop and a desktop computer, demonstrating its universal

5. MAINTENANCE

To ensure the longevity and optimal performance of your T22 Vertical Mouse, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe the surface of the mouse. For stubborn dirt, a slightly damp cloth can be used, but ensure no moisture enters the device.
- **Storage:** Store the mouse in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** Avoid fully discharging the battery frequently. Charge the mouse when the battery indicator suggests low power.
- **Avoid Drops:** Protect the mouse from drops and impacts, which can damage internal components.

6. TROUBLESHOOTING

If you encounter issues with your T22 Vertical Mouse, please refer to the following common solutions:

Problem	Possible Solution
Mouse not responding	<ul style="list-style-type: none"> ◦ Ensure the mouse is charged. ◦ Check the connection mode switch (2.4G/BT) on the bottom of the mouse. ◦ For 2.4G: Ensure the USB receiver is securely plugged in. Try a different USB port. ◦ For Bluetooth: Ensure Bluetooth is enabled on your device and the mouse is paired. Try re-pairing. ◦ Restart your computer.
Cursor movement is erratic or slow	<ul style="list-style-type: none"> ◦ Clean the optical sensor on the bottom of the mouse. ◦ Ensure you are using the mouse on a suitable surface (non-reflective, non-transparent). ◦ Adjust the DPI setting using the DPI button. ◦ Check for low battery.
Buttons not working	<ul style="list-style-type: none"> ◦ Check for low battery. ◦ Ensure the mouse is properly connected. ◦ Restart your computer.
Bluetooth pairing fails	<ul style="list-style-type: none"> ◦ Ensure the mouse is in Bluetooth pairing mode (switch set to BT). ◦ Make sure your device's Bluetooth is on and discoverable. ◦ Remove any previous pairings of the mouse from your device's Bluetooth list and try again. ◦ Ensure the mouse is sufficiently charged.

7. SPECIFICATIONS

Parameter	Value
Item Type	T22 2.4G+BT5.1 Dual Mode Vertical Mouse
Wireless Technology	2.4G + Bluetooth 5.1
Available Colors	Black, Grey, White
Return Rate	125Hz
Moving Speed	28 IPS
Refresh Rate	3000 FPS
Acceleration	10G
Resolution (DPI)	800 / 1200 / 1600 / 2400 DPI
Rated Voltage / Current	3.7V / 8-10mA
Battery Type	600mAh Lithium Battery
Button Click Life	5 Million times (Mute switch)
Mouse Interface	Type-C (for charging)
Maximum Operating Range	10m
Material	ABS
Product Size	12.5 * 7.5 * 6.5 cm
Net Weight	92g

3 colors available

There's always a color you like,
Make your life more exciting



Image: The T22 Vertical Mouse displayed in its three available color options: black, grey, and white.

8. SYSTEM REQUIREMENTS

The T22 Vertical Mouse is compatible with a wide range of operating systems:

- Windows 98 / Me / 2000 / XP / Vista / Win 7 / Win8 / Win10 / Win11
- Mac OS
- Linux (latest versions)

9. WARRANTY AND SUPPORT

For any questions or issues not covered in this manual, please contact the seller or manufacturer for assistance. Specific warranty details may vary by region and retailer. Please retain your proof of purchase for warranty claims.

Warning: Not for Children under 3 yrs.

Nicht für Kinder unter 3 Jahren

Avertissement : Ne convient pas aux enfants de moins de 3 ans.

Attenzione: Non adatto a bambini di età inferiore a 3 anni.

Advertencia: No apto para niños menores de 3 años.

MADE IN CHINA

GEFERTIGT IN CHINA

FABRIQUÉ EN CHINE

FATTO IN CINA

FABRICADO EN CHINA



MJCM Limited
Room A8.2, Liffey Building, Dublin 1, Ireland



Image: Product warning labels indicating "Not for Children under 3 yrs." and various international certifications (CE, UKCA, RoHS).