

OHAYO X10 MAX

OHAYO X10 MAX Portable Bluetooth Speaker User Manual

Model: X10 MAX | Brand: OHAYO

1. INTRODUCTION

This manual provides detailed instructions for the proper use, setup, operation, and maintenance of your OHAYO X10 MAX Portable Bluetooth Speaker. Please read this manual thoroughly before using the product to ensure optimal performance and longevity. The OHAYO X10 MAX is designed to deliver powerful sound with dazzling light effects, IPX7 waterproofing, and versatile connectivity options for various environments.

2. WHAT'S IN THE BOX

Carefully unpack your OHAYO X10 MAX speaker and ensure all items are present:

- 1 x OHAYO X10 MAX Bluetooth Speaker
- 1 x USB-C Charging Cable (charging plug not contained)
- 1 x 3.5mm AUX Cable
- 1 x User Manual (this document)
- 1 x Lanyard



Image: The OHAYO X10 MAX Portable Bluetooth Speaker in glossy black, showcasing its cylindrical design and integrated LED

3. PRODUCT OVERVIEW

Familiarize yourself with the key components and features of your OHAYO X10 MAX speaker.

3.1. Controls and Ports

The speaker features intuitive controls and multiple input options:

- **Power Button:** For turning the speaker on/off.
- **Volume Buttons (+/-):** To adjust the playback volume.
- **Play/Pause Button:** To control audio playback.
- **Bass Button:** Activates or deactivates the Extra Bass technology for enhanced low frequencies.
- **Light Mode Button:** Cycles through the six different dazzling light effects or turns them off.
- **USB-C Charging Port:** For charging the speaker.
- **USB Audio Port:** For USB audio playback and charging while in use.
- **TF Card Slot:** For playing audio directly from a TF (microSD) card.
- **AUX-IN Port:** For wired audio connection via a 3.5mm AUX cable.
- **Built-in Microphone:** For hands-free calling.

4 INPUT MODES

BT, TF, AUX, USB-Audio to meet your diverse input needs



BT



AUX



TF



USB-AUDIO



Image: The side of the OHAYO X10 MAX speaker showing the control buttons and the various input ports: Bluetooth, AUX, TF card, and USB-Audio.

3.2. Sound and Lighting Features

- **25W Powerful Sound:** Features a racetrack-shaped woofer and a separate tweeter for clear highs and deep bass.
- **Extra Bass Technology:** Enhances bass output with a dedicated button.
- **Dazzling RGB Lights:** Six different lighting effects that pulsate and flash to the beat of the music. Lights can be turned off.



6 DAZZLING RGB LIGHT EFFECTS

With the unique flash design, following the music drum beat jump, bring you an immersive music experience.

Image: The OHAYO X10 MAX speaker displaying its vibrant RGB lighting effects, which can be customized or turned off.

4. SETUP

4.1. Charging the Speaker

Before first use, fully charge the speaker. Use the provided USB-C charging cable with a compatible USB power adapter (not included).

- Connect the USB-C cable to the speaker's charging port.

- Connect the other end to a USB power source.
- The battery indicator lights will show charging status.
- A full charge takes approximately 3 hours.

24H ULTRA-LONG BATTERY LIFE

Unleash the power of a 6600mAh battery with a handy indicator light - never worry about battery life again.



Image: The OHAYO X10 MAX speaker illustrating its 24-hour battery life and 6600mAh battery capacity, with a visual representation of charging and usage time.

4.2. Power On/Off

- **To Power On:** Press and hold the Power button until the indicator lights illuminate and you hear a power-on sound.

- **To Power Off:** Press and hold the Power button until the indicator lights turn off and you hear a power-off sound.

4.3. Bluetooth Pairing

The OHAYO X10 MAX uses Bluetooth 5.3 for a stable wireless connection.

- Ensure the speaker is powered on and in Bluetooth pairing mode (indicated by a flashing blue light).
- On your device (smartphone, tablet, laptop), enable Bluetooth and search for available devices.
- Select "OHAYO X10 MAX" from the list of devices.
- Once paired, the speaker will indicate a successful connection, and the blue light will become solid.
- The maximum transmission distance is 100 feet, with a stable connection over 66 feet in most conditions.

4.4. Wireless Stereo Pairing (TWS)

You can pair two OHAYO X10 MAX speakers for a true wireless stereo experience, providing separate left and right audio channels.

- Ensure both X10 MAX speakers are powered on and not connected to any other Bluetooth devices.
- On one speaker (this will be the primary speaker), press and hold the Bluetooth pairing button (or a dedicated TWS button if available, refer to speaker markings) until you hear a prompt.
- The two speakers will automatically search and connect to each other. Once connected, you will hear a confirmation sound.
- Now, connect your device to the primary speaker via Bluetooth as described in Section 4.3. Audio will play through both speakers in stereo.

TRUE WIRELESS STEREO

Bluetooth 5.3 guarantees a stable link between the two speakers, allowing you to enjoy 360-degree surround music.



Image: A visual representation of two OHAYO X10 MAX speakers paired together for True Wireless Stereo, providing an immersive audio experience for a listener.

5. OPERATING INSTRUCTIONS

5.1. Audio Playback

The OHAYO X10 MAX supports four input modes:

- **Bluetooth:** After successful pairing (Section 4.3), simply play audio from your connected device.

- **USB Audio:** Connect the speaker to a computer or compatible device via the USB audio port. The speaker will function as an external sound card, providing purer sound quality by avoiding analog signal noise.
- **TF Card:** Insert a TF (microSD) card loaded with audio files into the TF card slot. The speaker will automatically begin playback.
- **AUX-IN:** Connect an audio source (e.g., MP3 player, laptop) to the speaker's AUX-IN port using the provided 3.5mm AUX cable. The speaker will automatically switch to AUX mode.

5.2. Light Effects Control

Press the Light Mode button to cycle through the six available dazzling RGB light effects. Press and hold the button to turn the lights off or on.

5.3. Hands-Free Calling

When connected via Bluetooth to a smartphone, the built-in microphone allows for hands-free calls.

- **Answer Call:** Press the Play/Pause button once.
- **End Call:** Press the Play/Pause button once during a call.
- **Reject Call:** Press and hold the Play/Pause button.

5.4. Bass Boost

Press the dedicated BASS button to activate or deactivate the Extra Bass technology, enhancing the low-frequency output for a richer sound experience.

6. MAINTENANCE

Proper care will extend the life and performance of your OHAYO X10 MAX speaker.

- **Cleaning:** Use a soft, dry cloth to wipe the speaker's surface. Do not use abrasive cleaners, alcohol, or chemical solvents.
- **Waterproof Care:** While the speaker is IPX7 waterproof (can be submerged in up to 1 meter of water for 30 minutes), ensure all port covers are securely closed before exposure to water. After exposure to saltwater or chlorinated water, rinse the speaker with fresh water and dry thoroughly before charging.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures. If storing for an extended period, charge the battery to about 50% every few months to maintain battery health.

IPX7 WATERPROOF

Highly sealed design, no fear of rain and flooding.



Image: The OHAYO X10 MAX speaker being splashed with water, demonstrating its IPX7 waterproof rating, making it suitable for use near water.

7. TROUBLESHOOTING

If you encounter issues with your speaker, refer to the following common problems and solutions:

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Speaker does not power on.	Battery is depleted.	Charge the speaker fully.
Cannot pair via Bluetooth.	Speaker is not in pairing mode or already connected to another device. Device's Bluetooth is off.	Ensure speaker is in pairing mode. Disconnect from other devices. Turn on Bluetooth on your device and retry pairing. Move closer to the speaker.
No sound from speaker.	Volume is too low. Incorrect input mode selected. Audio source issue.	Increase speaker and device volume. Check the input mode (Bluetooth, AUX, TF, USB). Ensure audio is playing on the source device.
Sound distortion.	Volume too high. Low battery. Interference.	Reduce volume. Charge the speaker. Move speaker away from other electronic devices.
TWS pairing fails.	Speakers are too far apart or already connected to other devices.	Ensure both speakers are disconnected from other devices. Place them close together and retry TWS pairing.

8. SPECIFICATIONS

Detailed technical specifications for the OHAYO X10 MAX Portable Bluetooth Speaker:

Feature	Specification
Model Name	X10 MAX
Brand	OHAYO
Connectivity Technology	Bluetooth 5.3, Auxiliary (3.5mm), TF Card, USB Audio
Speaker Type	Portable, Waterproof, Wireless, Outdoor
Speaker Maximum Output Power	35 Watts (25W Bass + 10W Tweeter)
Audio Output Mode	Stereo
Water Resistance Level	IPX7 (fully sealed waterproof case)
Battery Life	Up to 24 Hours (at 50% volume, without lights)
Battery Capacity	6600 mAh (3300 mAh x2)
Charging Time	Approximately 3 Hours
Bluetooth Range	Up to 100 Feet (30 meters)
Product Dimensions	2.95"D x 2.95"W x 7.28"H (7.5cm x 7.5cm x 18.5cm)



Feature	Specification
Item Weight	1.29 pounds (0.58 kg)
Microphone	Built-in (for hands-free calling)
Special Features	Portable, Waterproof, Stereo Pairing, Built-in Microphone, Bass Boost, USB Audio, LED Light, Shockproof, Hi-Res Audio, Battery Level Display, Dustproof

9. WARRANTY AND SUPPORT

The OHAYO X10 MAX Portable Bluetooth Speaker comes with an extended warranty. For specific warranty terms, conditions, or to claim warranty service, please refer to the warranty card included in your product packaging or contact OHAYO customer support directly. Please retain your proof of purchase for warranty purposes. For technical support, troubleshooting assistance beyond this manual, or general inquiries, please visit the official OHAYO website or contact their customer service channels.

© 2025 OHAYO. All rights reserved.

Related Documents

	<p>OHAYO X3 Bluetooth Speaker Quick Start Guide</p> <p>Comprehensive quick start guide for the OHAYO X3 Bluetooth speaker, covering setup, TWS pairing, controls, charging, and technical specifications.</p>
	<p>OHAYO A7 Quick Start Guide</p> <p>A concise quick start guide for the OHAYO A7 wireless earbuds, covering powering on/off, pairing, music mode, call mode, factory reset, charging, specifications, and troubleshooting.</p>