Bemi BRCT5

Bemi Cognita Tab 5 E-Reader User Manual
Model: BRCT5

1. INTRODUCTION

This manual provides essential instructions for the setup, operation, and maintenance of your Bemi Cognita Tab 5 E-Reader. The Cognita Tab 5 is a lightweight e-reader designed for comfortable reading, featuring a 5.76-inch e-paper display, Android 8.1 operating system, and Wi-Fi connectivity. Please read this manual thoroughly to ensure proper use and to maximize your device's potential.

2. PACKAGE CONTENTS

Upon unpacking your Bemi Cognita Tab 5, please verify that all the following items are included:

- Bemi Cognita Tab 5 E-Reader
- USB Charging Cable
- Quick Start Guide
- User Manual (this document)
- Warranty Card

Image: Contents of the Bemi Cognita Tab 5 E-Reader package, including the device, charging cable, and documentation.

3. DEVICE OVERVIEW

Familiarize yourself with the physical components of your Bemi Cognita Tab 5.

3.1 Front View

Image: Front view of the Bemi Cognita Tab 5 E-Reader, showing the e-paper display and side buttons.

- **E-Paper Display:** 5.76-inch screen with 920x680 resolution (198 ppi) and anti-glare coating.

- **Page-Turn Buttons:** Located on the side for convenient navigation through content.

3.2 Back View

Image: Back view of the Bemi Cognita Tab 5 E-Reader, highlighting its textured surface and branding.

- **Rubberized Casing:** Provides a secure grip and durability.

3.3 Ports and Buttons

- **Power Button:** Used to turn the device on/off and put it to sleep.
- **USB Port:** For charging and data transfer.
- **MicroSD Card Slot:** For expanding storage up to 64GB.
- **Headphone Jack:** For audio output.

---

4. SETUP

4.1 Initial Charging

Before first use, fully charge your Bemi Cognita Tab 5. Connect the provided USB cable to the device's USB port and plug the other end into a compatible USB power adapter (not included) or a computer's USB port. The charging indicator will show the charging status.

4.2 Power On/Off

- **To Power On:** Press and hold the Power button until the screen activates.
- **To Power Off:** Press and hold the Power button, then select 'Power Off' from the options that appear on the

screen.

- **To Sleep/Wake:** Briefly press the Power button to put the device to sleep or wake it up.

4.3 Basic Navigation

The Cognita Tab 5 features a responsive touchscreen for navigation. Tap to select items, swipe to scroll, and use pinch-to-zoom where applicable. The dedicated page-turn buttons on the side can also be used for navigating through e-books.

4.4 Wi-Fi Connection

To access online content, transfer files wirelessly, or update software, connect your device to a Wi-Fi network:

1. Go to **Settings** from the main menu.
2. Select **Wi-Fi**.
3. Toggle Wi-Fi **On**.
4. Select your desired network from the list and enter the password if prompted.

5. OPERATING INSTRUCTIONS

5.1 Reading E-books

The Bemi Cognita Tab 5 supports various e-book formats including PDF, EPUB, and MOBI. To start reading:

1. Navigate to the **Books** section on your device.
2. Tap on the cover of the e-book you wish to read.
3. Use the touchscreen or the physical page-turn buttons to navigate through pages.

Image: A person holding the Bemi Cognita Tab 5 E-Reader, demonstrating the reading experience on its e-paper display.

5.2 Adjusting Backlight

The adjustable screen backlight allows for comfortable reading in various lighting conditions. Access backlight settings through the quick settings panel or the main Settings menu to adjust brightness levels.

5.3 File Transfer

You can transfer files to your Cognita Tab 5 via USB or Wi-Fi.

- **USB Transfer:** Connect the device to your computer using the USB cable. The device will appear as a removable storage drive, allowing you to drag and drop files.
- **Wi-Fi Transfer:** Ensure both your device and the transmission device are on the same local area network (LAN). On your Cognita Tab 5, navigate to the Wi-Fi Transfer option (often found in the 'Storage' or 'Settings' menu). An IP address will be displayed (e.g., http://172.20.10.8:12580). Enter this address into a web browser on your computer or phone to access the device's storage and transfer files. Do not close this page during transmission.

Image: Screenshots showing the Wi-Fi transfer interface with an IP address and a file management screen on the Bemi Cognita Tab 5 E-Reader.

5.4 Installing Additional Applications

Running on Android 8.1, the Cognita Tab 5 allows for the installation of additional reading applications. You can typically install apps by transferring their APK files to the device and installing them through a file manager, or by using a pre-installed app store if available.

5.5 Audio Features

The device supports audio files and features text-to-speech functionality. Connect headphones to the headphone jack to listen to audiobooks or have your e-books read aloud.

5.6 Special Reading Features

The Cognita Tab 5 includes features to enhance your reading experience:

- **PDF Reflow:** Optimizes PDF documents for better readability on the smaller screen.

- **Dictionary:** Look up definitions of words directly from your e-book.
- **Translator:** Translate words or phrases within your reading material.

6. MAINTENANCE

6.1 Cleaning

To clean the screen, use a soft, lint-free cloth. For stubborn smudges, slightly dampen the cloth with water or a screen cleaner specifically designed for electronics. Avoid harsh chemicals or abrasive materials. For the device body, use a dry, soft cloth.

6.2 Battery Care

To prolong battery life, avoid exposing the device to extreme temperatures. Charge the device regularly, but avoid leaving it fully discharged for extended periods. If storing the device for a long time, ensure it has a partial charge (around 50%).

6.3 Storage

Store your Bemi Cognita Tab 5 in a cool, dry place away from direct sunlight and moisture. Protect the screen from scratches by using a protective cover or case when not in use.

7. TROUBLESHOOTING

If you encounter issues with your Bemi Cognita Tab 5, refer to the following common solutions:

- **Device Not Turning On:** Ensure the battery is charged. Connect the device to a power source and try again. If unresponsive, perform a hard reset by holding the power button for 10-15 seconds.
- **Screen Unresponsive:** Restart the device. If the issue persists, ensure the screen is clean and free of debris.
- **Wi-Fi Connection Issues:** Verify your Wi-Fi password. Restart your router and the Cognita Tab 5. Ensure the device is within range of the Wi-Fi signal.
- **Slow Performance:** Close unused applications. Clear cache if available in settings. Consider performing a factory reset (this will erase all data).
- **Battery Drains Quickly:** Reduce screen brightness. Turn off Wi-Fi when not in use. Close background applications.

For persistent issues not covered here, please contact customer support.

8. SPECIFICATIONS

Feature	Specification
Model Name	Cognita Tab 5 (BRCT5)
Display	5.76-inch E-Paper, 920x680 resolution (198 ppi), Anti-glare
Processor	Cortex-A7 Quad-Core

RAM	1 GB
Internal Storage	16 GB
Expandable Storage	MicroSD card up to 64 GB
Operating System	Android 8.1
Connectivity	Wi-Fi, USB
Special Features	Text-to-speech, Smart Reading, Headphone Jack, Scratch Resistant, Card Support
Supported E-book Formats	PDF, EPUB, MOBI, and others
Battery Life	Up to 2 weeks (typical usage)
Weight	135g
Thickness	8mm

9. WARRANTY AND SUPPORT

9.1 Warranty Information

Your Bemi Cognita Tab 5 E-Reader comes with a warranty. Please refer to the included Warranty Card for specific terms, conditions, and duration of the warranty. Keep your proof of purchase for warranty claims.

9.2 Customer Support

For technical assistance, troubleshooting beyond this manual, or warranty inquiries, please contact the seller or manufacturer directly. Contact information may be available on the product packaging or the official Bemi website.

Related Documents - BRCT5

	[Bemi Cognita X E-book Reader User Manual](#) A comprehensive guide to the Bemi Cognita X e-book reader, covering device setup, safety precautions, navigation, features like the library, dictionary, notes, and settings. Learn how to manage your e-books and customize your reading experience.
	[Bemi Cognita X E-book Reader User Manual](#) This user manual provides comprehensive guidance for the Bemi Cognita X e-book reader, covering device features, operation, safety precautions, and settings.
	[Bemi CID Smartwatch User Manual: Features, Setup, and Operation](#) Comprehensive user manual for the Bemi CID Smartwatch. Learn about its features, how to set it up with the FitCloudPro app, device functions, maintenance, and specifications.
	[Bemi Racer RC1 Smartwatch User Manual](#) Comprehensive user manual for the Bemi Racer RC1 smartwatch, covering product description, maintenance, charging, app installation, device functions, basic parameters, and disposal information.
	[Bemi Tracker Smartwatch User Manual](#) Comprehensive user manual for the Bemi Tracker smartwatch, covering setup, features, maintenance, and specifications. Learn how to use your Bemi Tracker for fitness tracking, notifications, and more.

[Bemi 10.1" WiFi Digital Photo Frame with Frameo User Manual](#)

Comprehensive user manual for the Bemi 10.1" WiFi Digital Photo Frame, detailing setup, features, navigation, settings, and troubleshooting using the Frameo app. Includes safety information, device parts, and connectivity instructions.