

GTRACING GT205

GTRACING Gaming Chair User Manual

Model: GT205 | Brand: GTRACING

1. SAFETY INFORMATION

Please read all instructions carefully before assembly and use. Keep this manual for future reference.

- Maximum weight capacity: 300 lbs. Do not exceed this limit.
- Ensure all screws and bolts are tightened securely before use. Periodically check and re-tighten all fasteners.
- Avoid standing on the chair or using it as a step stool.
- Do not use the chair on uneven surfaces.
- Keep small parts away from children.
- For any assembly or usage instructions, contact customer support.

2. PARTS LIST

Before beginning assembly, ensure all parts are present and undamaged. Refer to the included hardware pack for labeled components.

A. Chair Backrest: Ergonomically designed with dual-layered foam.

B. Seat Cushion: Features pocket spring lumbar support and widened design.

C. Armrests (x2): Outward-extended and thickened with steel reinforcement.

D. Footrest: Retractable footrest for extended comfort.

E. Five-Star Base: BIFMA-tested for stability and durability.

F. Casters (x5): Multi-direction wheels for smooth gliding.

G. Gas Lift: SGS-3 certified for height adjustment.

H. Mechanism Plate: Connects seat to gas lift, includes recline and lift levers.

I. Hardware Pack: Contains all necessary screws, washers, and Allen wrench.



Figure 2.1: Overview of all GTRACING Gaming Chair components.

3. ASSEMBLY INSTRUCTIONS

Follow these steps carefully to assemble your GTRACING Gaming Chair. An Allen wrench tool is included. If you have a small drill without too much torque, it would be faster to assemble all of the parts.

Note: No official seller videos were available for embedding. Please refer to the detailed text instructions

and images provided.

3.1 Base Assembly

1. Insert the five casters (F) into the holes at the end of each leg of the five-star base (E). Push firmly until they click into place.
2. Insert the gas lift (G) into the central hole of the five-star base (E). Place the plastic cover over the gas lift.



Figure 3.1: Chair dimensions and recommended user specifications.

3.2 Footrest Installation

1. Attach the footrest (D) to the designated runners on the underside of the seat cushion (B) using the provided screws. Ensure the footrest is facing the correct direction as indicated in the manual.

3.3 Armrest Attachment

1. Align the armrests (C) with the pre-drilled holes on the underside of the seat cushion (B).

2. Secure each armrest using the appropriate screws and washers from the hardware pack (I). Tighten firmly.



Figure 3.2: Detail of the chair's armrests, highlighting padding and steel reinforcement.

3.4 Connecting Seat and Back

1. Attach the mechanism plate (H) to the underside of the seat cushion (B) using the designated screws. Ensure the 'FRONT' label on the mechanism faces the front of the seat.
2. Align the chair backrest (A) with the bracket on the mechanism plate (H). Slide the backrest down into the bracket until it is securely seated.
3. Secure the backrest to the mechanism using the remaining screws and washers.

ERGONOMIC DESIGN

Provides soft and comfortable support for the head and lower back, helping you maintain a good posture even during long hours of work and gaming.



Figure 3.3: The ergonomic design provides soft and comfortable support for the head and lower back.

3.5 Final Assembly

1. Carefully place the assembled seat and backrest onto the gas lift (G) inserted into the five-star base (E). Press down firmly to ensure a secure connection.



Figure 3.4: Your GTRACING Gaming Chair is now assembled.

4. OPERATING INSTRUCTIONS

Your GTRACING Gaming Chair offers several adjustable features for personalized comfort.

- **Height Adjustment:** Use the 'LIFT' lever located on the right side of the mechanism plate to adjust the chair's height. Pull the lever up while applying slight pressure to the seat to raise it, or lift your weight off the seat to lower it. The chair offers a 10cm height adjustment range.
- **Back Recline:** Use the 'RCL' lever on the left side of the mechanism plate to adjust the backrest recline. Pull the lever up to unlock the recline, lean back to your desired angle (90° to 135°), and push the lever down to lock it in place.
- **Footrest Usage:** The footrest can be manually pulled out from underneath the seat cushion for leg support. Push it back in when not in use.
- **Swivel Function:** The chair features a 360° swivel seat, allowing for free rotation.
- **Lumbar Pillow:** The oversized lumbar pillow is height-adjustable for personalized support.

5. MAINTENANCE AND CARE

Proper maintenance will extend the life and appearance of your GTRACING Gaming Chair.

- **Cleaning:** For PU leather surfaces, wipe with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners. For fabric parts, use a mild fabric cleaner as needed.
- **Inspection:** Periodically check all bolts and screws to ensure they are tight. Re-tighten if necessary to maintain stability and safety.
- **Movement:** Ensure casters are free of debris to allow smooth movement.
- **Storage:** Store the chair in a cool, dry place away from direct sunlight and extreme temperatures.

6. TROUBLESHOOTING

If you encounter any issues with your chair, refer to the table below. For problems not listed, please contact customer support.

Problem	Possible Cause	Solution
Chair wobbles or is unstable	Loose screws or uneven surface	Tighten all assembly screws. Ensure chair is on a flat, level surface.
Chair does not adjust height	Gas lift malfunction or lever not engaged	Ensure the 'LIFT' lever is fully engaged. If issue persists, contact support for gas lift replacement.

Problem	Possible Cause	Solution
Backrest does not recline or lock	Recline lever not engaged or mechanism issue	Ensure the 'RCL' lever is fully engaged. Check for obstructions in the recline mechanism.
Casters do not roll smoothly	Debris in wheels or damaged casters	Clean any hair or debris from the casters. If damaged, contact support for replacements.

7. SPECIFICATIONS

Feature	Detail
Brand	GTRACING
Model Name	GT205
Color	Deepblack
Product Dimensions (D x W x H)	19.7"D x 22"W x 45.1"H
Maximum Weight Recommendation	300 Pounds
Back Style	Pillow Back
Material	PU Leather, Foam, Fiber Batting/Fill
Item Weight	44 pounds
Recline Range	90° to 135°
Height Adjustment Range	10 cm (5'1" to 6'2" user height)

8. WARRANTY AND SUPPORT

GTRACING is committed to providing a 100% satisfactory solution for any issues with your office chair.

- **Free Replacement or Refund:** Available within 30 days of purchase.
- **Free Replacement or Repair:** Available within 1 year of purchase.
- **Customer Support:** For any questions or suggestions, please contact us directly. Our customer support team will respond within 24 hours.

Thank you for choosing GTRACING.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question