

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [KIGOTY](#) /

› [KIGOTY 71-Inch Furniture Style Double Dog Crate with Storage \(Model 21-4DC0002\) - Instruction Manual](#)

KIGOTY 21-4DC0002

KIGOTY 71-Inch Furniture Style Double Dog Crate with Storage (Model 21-4DC0002) - Instruction Manual

INTRODUCTION

Thank you for choosing the KIGOTY 71-Inch Furniture Style Double Dog Crate. This product is designed to provide a comfortable and secure space for your pets while also serving as a functional piece of furniture for your home. This manual provides detailed instructions for assembly, operation, maintenance, and troubleshooting to ensure safe and optimal use of your new dog crate.



Image: The KIGOTY 71-inch furniture style double dog crate in rustic brown, shown with a golden retriever comfortably resting inside one of the compartments. The crate also features a drawer and a tilt-out cabinet on the right side, with decorative items on top.

SAFETY INFORMATION

- Read all instructions carefully before assembly and use. Keep this manual for future reference.
- Ensure all parts are securely fastened before allowing pets to use the crate. Regularly check for loose screws or damaged components.
- Do not overload the top surface or drawers. Adhere to weight limits for stability.
- This product is intended for indoor use only.
- Keep small parts and packaging materials away from children and pets during assembly to prevent choking hazards.
- Ensure the crate size is appropriate for your pet. Measure your standing dog and add at least 4 inches to its height for optimal comfort. The minimum internal height of this crate is 22.5 inches.

PACKAGE CONTENTS

Verify that all components listed below are present before beginning assembly. If any parts are missing or damaged, please contact customer support.

- Wooden panels (various sizes for top, bottom, sides, back, and divider)
- Metal bars/grates for crate sections
- Sliding door mechanisms and hardware
- Drawer components and slides
- Tilt-out cabinet components and hardware
- Assembly hardware (screws, dowels, cam locks, etc.)
- Handles for drawers and cabinet
- Instruction manual

Note: Specific quantities of each component will be detailed in the included assembly guide.


SETUP AND ASSEMBLY

Assembly typically requires two adults. Please follow the step-by-step instructions provided in the separate assembly guide included with your product. Ensure you have a Phillips head screwdriver and possibly a hammer for dowels.

Key Assembly Considerations:

- **Product Dimensions:** Refer to the diagram below for overall and internal measurements to plan your space.
- **Removable Divider:** The crate includes a removable divider, allowing configuration for one large dog or two smaller dogs. Install or remove the divider as needed during assembly or later.

Removable Divider



One Large Room Style

Before purchasing, measure your dog's standing height to ensure the dog crate size is suitable. The middle divider height is 22.5".

Two Room Style



Easily replaceable between one and two high rooms by removing and installing screws.

Image: A detailed diagram illustrating the overall dimensions of the KIGOTY double dog crate (70.9"L x 23.6"W x 32.5"H) and the internal height of the divider (22.5"H). It also shows the dimensions of the drawer (24.7"L x 13"W x 3.2"H).



Image: This diagram demonstrates the versatility of the removable divider. It shows the crate configured as two separate rooms with the divider installed, and as one large room when the divider is removed. Instructions indicate the divider can be easily replaced by removing and installing screws.

OPERATING INSTRUCTIONS

Using the Crate Compartments:

- **Sliding Doors:** The crate features smooth-gliding barn-style doors. To open, slide the door horizontally along its track. To close, slide it back until it meets the center or side panel. Ensure the doors are fully closed and latched if your pet is to remain secured.
- **Removable Divider:** As mentioned in assembly, the divider can be installed or removed to create one large space or two smaller compartments. This allows flexibility for single or multiple pets, or to adjust space as a puppy grows.

Utilizing Storage Features:

- **Storage Drawer:** The integrated drawer provides convenient storage for pet accessories, leashes, toys, or personal items. Pull the handle to open and push to close.

- **Tilt-Out Cabinet:** The tilt-out cabinet is designed for easy access storage, such as a trash bin for pet waste or a container for pet food. Pull the handle to tilt the front panel open. Push to close securely.



Image: The KIGOTY double dog crate in rustic brown, showing a dog resting inside one compartment. The tilt-out cabinet on the right is open, revealing an internal bin, suitable for pet waste or food storage.



Image: A close-up view of the storage drawer and the tilt-out cabinet on the KIGOTY dog crate. The drawer is partially open, showing magazines and a pet food bag, while the tilt-out cabinet is open, revealing a trash bin. This illustrates the practical storage options.

Multi-functional Use:

Beyond its primary function as a pet enclosure, this furniture-style crate can serve as a TV stand, end table, or side table. The sturdy top surface can hold decorative items, books, or a television.

Drawers & 1 Trash Cabinet



Image: A graphic titled "3-in-1 Dog Crate Table" with icons representing a TV stand, a dog crate, and a side table, demonstrating the versatile uses of the KIGOTY furniture piece.

MAINTENANCE

- **Cleaning:** Wipe down wooden surfaces with a soft, damp cloth. Avoid harsh chemicals that may damage the finish or be harmful to pets. For metal bars, use a mild soap and water solution.
- **Hardware Check:** Periodically inspect all screws, bolts, and latches to ensure they are tight and secure. Tighten any loose hardware to maintain stability and safety.
- **Moving the Crate:** When moving the assembled crate, lift it rather than dragging to prevent damage to the legs or structural integrity.

TROUBLESHOOTING

- **Problem:** Doors are difficult to slide.
Solution: Check the sliding tracks for any obstructions or debris. Ensure the tracks are clean. A small amount of silicone-based lubricant can be applied to the tracks if needed, avoiding contact with pet areas.

- **Problem:** Crate feels wobbly after assembly.
Solution: Re-check all assembly hardware, ensuring every screw and cam lock is fully tightened. Make sure the crate is placed on a flat, level surface.
- **Problem:** Drawer or tilt-out cabinet does not close smoothly.
Solution: Inspect the drawer slides or cabinet hinges for proper alignment and any obstructions. Ensure no items inside are blocking the closing mechanism.
- **Problem:** Pet attempts to chew on the crate.
Solution: Provide appropriate chew toys for your pet. Consider applying a pet-safe bitter spray to the crate's wooden parts to deter chewing.

SPECIFICATIONS

Feature	Detail
Model Number	21-4DC0002
Overall Dimensions (L x W x H)	70.9" x 23.6" x 32.5"
Interior Height (min)	22.5" (at middle divider)
Material	Engineered Wood, Metal, Wood
Color	Rustic Brown
Item Weight	136 Pounds
Storage Features	1 Drawer, 1 Tilt-Out Cabinet
Special Features	Removable Divider, Sliding Barn Doors, Multi-functional Design
Recommended Breeds	Large Breeds, Medium Breeds

WARRANTY AND SUPPORT

This KIGOTY product comes with a **6-month warranty** from the date of purchase, covering manufacturing defects. Please retain your proof of purchase for warranty claims.

For technical assistance, missing parts, or warranty inquiries, please contact KIGOTY customer support through the retailer where the product was purchased or visit the official KIGOTY store page on Amazon: [KIGOTY Store](#).

When contacting support, please provide your model number (21-4DC0002) and a detailed description of the issue.

Related Documents - 21-4DC0002

<div data-bbox="126 105 298 134" data-label="Section-Header"><p>LARKOLLEN</p></div> <div data-bbox="188 161 300 351" data-label="Image"></div>	<div data-bbox="341 248 866 277" data-label="Section-Header"><p>IKEA LARKOLLEN Rail Assembly Instructions</p></div> <div data-bbox="341 288 1428 358" data-label="Text"><p>Step-by-step guide for assembling the IKEA LARKOLLEN rail system for sliding doors. Includes part identification and assembly procedures.</p></div>
<div data-bbox="137 573 288 835" data-label="Image"></div> <div data-bbox="137 873 288 1301" data-label="Text"><p>THRESHOLD</p><ul style="list-style-type: none">• Aluminum Alloy 6063, T5 Temper• 4" Wide x 1 1/2" Tall• Smooth Top• BHMA Certified to ANSI/BHMA A556.21• 1,000 Lb. Load Test• Typical Wall Thickness: .125"• Weight: 70 Lbs./Ft.• #10 x 1 1/2" FH Zinc Plated Wood Screws Included<p>BHMA</p><p>UP</p><p>POSITIVE PRESSURE TESTED CORROSIVE MATERIALS FOR FIRE DOORS FOR APPLICATION TO HOLLOW METAL-TYPE FIRE DOORS RATED UP TO 3-HOURS AND WOOD-TYPE FIRE DOORS RATED UP TO 1 1/2-HOURS CATEGORY 1</p><p>ngp.com 1-800-NGP-RUSH Fax: (800) 255-7974 QUOTER: quotes@ngp.com</p></div>	<div data-bbox="341 862 1088 891" data-label="Section-Header"><p>NGP 404 Carpet and Tile Divider: Features and Installation Guide</p></div> <div data-bbox="341 902 1476 1012" data-label="Text"><p>Detailed information on the NGP 404 Aluminum Carpet and Tile Divider, including its specifications, BHMA/UL certifications, fire door ratings, and step-by-step installation instructions. Features include durable aluminum alloy construction and a smooth top.</p></div>
<div data-bbox="132 1373 298 1603" data-label="Image"></div>	<div data-bbox="341 1538 1153 1568" data-label="Section-Header"><p>Troy-Bilt Lawn Tractor Parts Manual: Hoods, Frames, and Components</p></div> <div data-bbox="341 1579 1469 1688" data-label="Text"><p>Detailed parts list and exploded diagrams for Troy-Bilt lawn tractors, covering various hood styles (1, 2, K, 5, G), frame components, steering systems, transmissions, and deck assemblies. Includes part numbers and descriptions for MTD-manufactured equipment.</p></div>

