

[Manuals.plus](#) /

› [Carlett](#) /

› Carlett Lite Duo LETT430-L3 Shopping Trolley User Manual

Carlett LETT430-L3

Carlett Lite Duo LETT430-L3 Shopping Trolley User Manual

Model: LETT430-L3

1. PRODUCT OVERVIEW

The Carlett Lite Duo LETT430-L3 is a versatile and lightweight 4-wheel shopping trolley designed for ease of use and convenience. It features a convertible 4-wheel to 2-wheel design, 360° swivel front wheels for exceptional maneuverability, an ergonomic adjustable handle, and a safety brake for stability. The trolley includes a large main bag with 48 liters capacity and an integrated 10-liter insulated bag for temperature-sensitive items.



Image 1.1: Front view of the Carlett Lite Duo LETT430-L3 shopping trolley, showcasing its overall design and olive color.





Image 1.2: Side view of the trolley, illustrating its profile, wheels, and handle.



Image 1.3: Key features diagram, highlighting the main bag, insulated bag, adjustable handle, compact folding mechanism, and integrated brake.

2. SETUP

The Carlett Lite Duo LETT430-L3 is designed for quick and easy assembly. Follow these steps to prepare your trolley for use:

1. **Unfold the Frame:** Gently pull the frame apart until it locks into its open position. Ensure all locking mechanisms are securely engaged.
2. **Attach the Wheels:** If the wheels are detached for shipping, insert them into their designated slots on the frame until they click into place. Verify that all four wheels rotate freely.
3. **Secure the Bag:** Place the main shopping bag onto the frame. The bag is typically secured with Velcro straps or clips. Ensure it is firmly attached to prevent shifting during use.
4. **Adjust the Handle:** Press the release buttons on the handle and extend it to your desired height. Release the buttons to lock the handle in position.





Image 2.1: The trolley in its folded configuration, demonstrating its compact storage capability.

3. OPERATING INSTRUCTIONS

This section details how to effectively use your Carlett Lite Duo LETT430-L3 shopping trolley.

3.1. Using the 4-Wheel and 2-Wheel Modes

- **4-Wheel Mode:** For maximum stability and ease of pushing, use the trolley with all four wheels on the ground. The 360° swivel front wheels allow for effortless navigation in any direction.
- **2-Wheel Mode:** To convert to 2-wheel mode, tilt the trolley backward onto its two larger rear wheels. This mode is useful for navigating stairs, curbs, or uneven terrain.

3.2. Adjustable Handle

The ergonomic handle can be adjusted to suit your height for comfortable pushing. Press the buttons on the sides of the handle and slide it up or down. Release the buttons to lock it in place.

3.3. Safety Brake

The integrated safety brake provides stability when the trolley is stationary. Engage the brake by pressing the lever located near the handle or wheels (depending on model variation). Ensure the brake is disengaged before moving the trolley.

3.4. Using the Bags

- **Main Bag (48L):** Use the main compartment for general groceries and larger items. The bag is extensible to accommodate varying loads.
- **Insulated Bag (10L):** The front-mounted insulated bag is designed to keep frozen or fresh items at their optimal temperature during transport.



Image 3.1: Visual guide to the adjustable handle, compact folding, safety brake, and extensible bag features.

4. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your shopping trolley.

- **Cleaning the Bag:** The main bag is removable. Hand wash with mild soap and water, then air dry. Do not machine wash or tumble dry. The insulated bag can be wiped clean with a damp cloth.
- **Frame Cleaning:** Wipe the metal frame with a damp cloth. Avoid abrasive cleaners.
- **Wheel Maintenance:** Periodically check the wheels for debris (hair, string, etc.) and remove them to ensure smooth rotation. The wheels are made of rubber.
- **Brake Check:** Regularly test the safety brake to ensure it engages and disengages properly.
- **Storage:** When not in use, fold the trolley compactly and store it in a dry place away from direct sunlight.

5. TROUBLESHOOTING

If you encounter any issues with your Carlett Lite Duo LETT430-L3, refer to the following common troubleshooting steps:

- **Trolley does not fold/unfold smoothly:** Check for any obstructions in the folding mechanism. Ensure all joints are clean and free of dirt. Apply a small amount of silicone lubricant if necessary.
- **Wheels are stiff or not rotating:** Inspect the wheels for tangled hair, lint, or other debris. Remove any obstructions. Ensure the wheel axles are clean.
- **Brake is not engaging/disengaging:** Check the brake lever and cable (if applicable) for any damage or misalignment. Ensure no debris is blocking the brake mechanism.
- **Bag is loose on the frame:** Re-secure the bag using its Velcro straps or clips. Ensure they are properly fastened to the frame.

If the problem persists after attempting these steps, please contact customer support.

6. SPECIFICATIONS

Brand:	Carlett
Model Number:	LETT430-L3
Color:	Olive
Folded Dimensions (L x W x H):	42 x 30 x 62 cm
Item Weight:	5.59 Kilograms
Maximum Weight Capacity:	25 Kilograms
Main Bag Capacity:	48 Liters
Insulated Bag Capacity:	10 Liters
Material:	Rubber (wheels), Metal (frame and body)
Number of Wheels:	4
Special Features:	360° Swivel Front Wheels, Insulated Bag, Foldable, Adjustable Handle, Safety Brake



Image 6.1: Capacity and weight summary graphic, showing 48 liters for the main bag, 10 liters for the insulated bag, and a 5 kg light structure.

7. WARRANTY AND SUPPORT

7.1. Warranty Information

Specific warranty details for the Carlett Lite Duo LETT430-L3 are not provided in this manual. Please retain your proof of purchase and contact the retailer or Carlett customer service for information regarding warranty coverage and terms.

7.2. Customer Support

For further assistance, technical support, or inquiries about replacement parts, please visit the official Carlett website or contact your point of purchase. Spare parts availability information is currently unavailable through standard product listings.

© 2023 Carlett. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question