

[Manuals.plus](#) /

> [myCharge](#) /

> myCharge EcoHub 3-in-1 Magnetic Wireless Charger & Battery Pack User Manual (Model 3N160KA)

myCharge 3N160KA


myCharge EcoHub 3-in-1 Magnetic Wireless Charger & Battery Pack

Model: 3N160KA

[Introduction](#) [Safety Information](#) [Package Contents](#) [Product](#)
[Overview](#) [Setup](#) [Operation](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#) [Warranty & Support](#)

1. INTRODUCTION

The myCharge EcoHub is a versatile 3-in-1 magnetic wireless charger and portable battery pack designed for Apple devices. It functions as a charging station for iPhone, Apple Watch, and AirPods, and can also be used as a portable MagSafe power bank with a built-in 6000mAh battery. Its foldable design and integrated wall plug enhance portability and convenience.



The EcoHub transitions from a portable handheld charger to a stable charging stand.

2. SAFETY INFORMATION

Please read all safety instructions before using this product to prevent injury or damage.

- Do not expose the device to extreme temperatures, direct sunlight, or high humidity.
- Do not disassemble, modify, or attempt to repair the device.
- Keep the device away from water and other liquids.
- Use only compatible charging cables and adapters.
- Avoid dropping or subjecting the device to strong impacts.
- Keep out of reach of children.
- Ensure proper ventilation when charging.

3. PACKAGE CONTENTS

Verify that all items are present in your package:

- myCharge EcoHub 3-in-1 Magnetic Wireless Charger & Battery Pack
- User Manual

4. PRODUCT OVERVIEW

The EcoHub integrates multiple charging functions into a single compact unit.



The EcoHub replaces multiple chargers and cables for a streamlined charging experience.

Key Features:

- **3-in-1 Charging:** Simultaneously charges iPhone (MagSafe), Apple Watch, and AirPods.
- **Portable Power Bank:** Built-in 6000mAh battery for on-the-go charging.
- **Integrated Wall Plug:** Foldable AC wall prongs for direct wall charging and recharging the EcoHub.
- **Foldable Design:** Compact for travel and storage.
- **Qi2 Wireless Output:** Provides up to 15W wireless charging for compatible iPhones.
- **USB-C Port:** For additional wired charging.

5. SETUP

Initial Charging of the EcoHub:

The EcoHub ships partially uncharged to protect battery lifespan. Fully charge the device before first use.

1. Locate the foldable wall prongs on the EcoHub.
2. Flip out the prongs and plug the EcoHub directly into a standard AC wall outlet.
3. The LED indicators on the device will illuminate to show charging status. A full charge is indicated when all LEDs are solid.
4. Allow several hours for a complete initial charge.



Recharge the EcoHub by plugging it directly into a wall outlet.

6. OPERATING INSTRUCTIONS

Using as a Charging Station:

When plugged into a wall outlet or fully charged, the EcoHub can charge multiple devices simultaneously.

1. **For iPhone (MagSafe):** Extend the MagSafe charging pad. Align your MagSafe-compatible iPhone with the magnetic pad. The magnets will secure the phone in place, and charging will begin automatically.
2. **For Apple Watch:** Place your Apple Watch on the dedicated charging puck. Ensure it is properly aligned for charging to initiate.
3. **For AirPods:** Place your AirPods charging case on the designated wireless charging area at the base of the unit.

Go From This (Literally)

To This



Nothing To Lose or Re-Buy

The EcoHub functions as a charging station for your Apple devices.

Using as a Portable MagSafe Charger:

When unplugged, the EcoHub acts as a portable power bank.

1. Ensure the EcoHub is charged. Check the LED indicators for battery level.
2. Fold the unit into its compact form.
3. Attach your MagSafe-compatible iPhone to the magnetic charging pad. The phone will begin charging wirelessly.

Charge by Day



Recharge by Night



Plug in to recharge — day or night.

The EcoHub provides portable MagSafe charging for your iPhone.

Using the USB-C Port:

A USB-C port is available for wired charging of other devices or for recharging the EcoHub itself if a wall outlet is not available.

- Connect a compatible USB-C cable to the EcoHub's USB-C port and to your device.
- To recharge the EcoHub via USB-C, connect it to a USB power adapter (not included).

7. MAINTENANCE

Proper care ensures the longevity of your EcoHub.


- **Cleaning:** Wipe the device with a soft, dry, lint-free cloth. Do not use abrasive cleaners or solvents.
- **Storage:** Store the EcoHub in a cool, dry place away from direct sunlight when not in use.
- **Battery Care:** For optimal battery health, fully charge the EcoHub at least once every three months if stored for extended periods.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Device not charging wirelessly.	Improper alignment, EcoHub battery low, or device not MagSafe compatible.	Ensure device is centered on the charging pad. Recharge EcoHub. Verify device compatibility.
EcoHub not recharging.	Wall plug not fully inserted, or outlet is not active.	Ensure the wall plug is securely inserted. Test the outlet with another device.
Slow charging speed.	Multiple devices charging simultaneously, or device case interfering.	Try charging fewer devices. Remove thick or non-MagSafe compatible cases.
LED indicators not working.	EcoHub completely discharged.	Plug the EcoHub into a wall outlet and allow a few minutes for the LEDs to activate.

9. SPECIFICATIONS

- **Model Number:** 3N160KA
- **Battery Capacity:** 6000mAh
- **iPhone Wireless Output:** Up to 15W (MagSafe/Qi2)
- **Apple Watch Wireless Output:** 5W
- **AirPods Wireless Output:** 5W
- **USB-C Output:** 20W
- **Input Voltage:** 9V (DC)
- **Output Current:** 2200mA
- **Power Source:** Corded Electric (via built-in plug) or USB Type C
- **Dimensions (Folded):** Compact for portability
- **Weight:** 9.5 Ounces (approx. 269g)
- **Material:** Plastic
- **Color:** Black
- **Safety Certification:** UL



The EcoHub features a built-in 6000mAh battery for extended power.

10. WARRANTY & SUPPORT

Warranty Information:

The myCharge EcoHub comes with a 30-day warranty from the date of purchase. This warranty covers manufacturing defects. It does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear.

Customer Support:

For technical assistance, warranty claims, or product inquiries, please visit the official myCharge website or contact their customer service department. Refer to the packaging or official website for the most current contact information.