

[Manuals.plus](#) /

› [Tefal](#) /

› T-fal Virtuo 30 Steam Iron User Manual

Tefal FV2C44U0

T-fal Virtuo 30 Steam Iron User Manual

Model: FV2C44U0

INTRODUCTION

Thank you for choosing the T-fal Virtuo 30 Steam Iron. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new appliance. Please read it thoroughly before first use and keep it for future reference.

SAFETY INSTRUCTIONS

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and personal injury.

- Read all instructions before use.
- Do not leave the iron unattended while it is connected or on an ironing board.
- Unplug the iron from the electrical outlet when filling with water, emptying, or when not in use.
- Do not operate the iron with a damaged cord or if the iron has been dropped or damaged.
- Keep the iron and its cord out of reach of children.
- Do not immerse the iron in water or other liquids.
- Use the iron only for its intended purpose.
- The soleplate can become extremely hot and cause burns. Do not touch hot surfaces.
- Always place the iron on a stable, heat-resistant surface when resting.

PRODUCT OVERVIEW

The T-fal Virtuo 30 Steam Iron is designed for efficient and effortless garment care. Key components include:

- Water Tank: For holding water for steam generation.
- Temperature Control Dial: To select the appropriate temperature for different fabrics.
- Steam Control Slider: To adjust steam output or select dry ironing.
- Steam Shot Button: For a powerful burst of steam to remove stubborn wrinkles.
- Spray Button: To mist fabric for easier ironing.
- Ceramic Soleplate: Provides smooth gliding and even heat distribution.
- Precision Tip: Allows access to difficult areas like collars and seams.



Image: The T-fal Virtuo 30 Steam Iron in green and white, showcasing its sleek design and steam functionality.

SETUP

1. **Unpacking:** Carefully remove the iron from its packaging. Retain packaging for future storage or transport.
2. **First Use Note:** Due to factory testing, it is normal to find a small amount of water condensation inside the water tank. This does not indicate a used or faulty product.
3. **Filling the Water Tank:**
 - Ensure the iron is unplugged.
 - Set the steam control to the 'Dry Ironing' position (no steam).
 - Open the water filling inlet.
 - Fill the tank with clean tap water up to the 'MAX' level indicator. Do not overfill.
 - Close the water filling inlet securely.
4. **Plugging In:** Plug the iron into a suitable grounded electrical outlet.

OPERATING INSTRUCTIONS

Temperature Selection

Turn the temperature control dial to select the appropriate heat setting for your fabric. Refer to the fabric care labels on your garments. The iron heats up quickly, reaching the desired temperature in approximately 30 seconds.

- **Low Temperature:** Synthetics, Silk
- **Medium Temperature:** Wool
- **High Temperature:** Cotton, Linen

Steam Ironing

1. Ensure the water tank is filled.
2. Set the temperature dial to a steam-suitable setting (usually wool, cotton, or linen). The iron will indicate when it's ready for steam.
3. Adjust the steam control slider to the desired steam output.
4. Begin ironing. The ceramic soleplate ensures easy gliding over fabrics.



Potente golpe de vapor

Image: The T-fal Virtuo 30 Steam Iron in action, highlighting its 1400W power for efficient ironing.

Steam Shot Function

For stubborn wrinkles, press the steam shot button. This delivers a powerful burst of 100 g/min steam. Wait a few seconds between shots to allow the iron to reheat.



Image: A close-up of the T-fal Virtuo 30 Steam Iron demonstrating its powerful steam shot capability.

Vertical Steaming

The iron can be used for vertical steaming of hanging garments, drapes, or upholstery. Hold the iron vertically, close to the fabric, and press the steam shot button.



Planchado eficiente
1400 watts de potencia

Image: Demonstrating the vertical steaming function of the T-fal Virtuo 30 Steam Iron on a hanging shirt.

Anti-Drip System

The integrated anti-drip system prevents water from leaking from the soleplate when ironing at low temperatures, ensuring your garments remain stain-free.

Planchado en vertical



Image: The T-fal Virtuo 30 Steam Iron highlighting its anti-drip system, preventing water stains on fabric.

Precision Tip

The specially designed precision tip allows you to easily iron around buttons, collars, pockets, and other intricate areas.



Image: A detailed view of the T-fal Virtuo 30 Steam Iron's precision tip, ideal for navigating around garment details.

ECO Mode

Activate the ECO mode to save up to 20% energy during ironing, contributing to energy efficiency without compromising performance.

MAINTENANCE

After Each Use

- Unplug the iron and allow it to cool completely.
- Empty any remaining water from the tank.
- Wipe the soleplate with a damp cloth to remove any residue. Do not use abrasive cleaners or scouring pads.

- Store the iron upright on its heel rest to protect the soleplate.

Descaling (Self-Clean Function)

Regular descaling helps maintain optimal steam performance. Refer to the iron's specific self-clean instructions, usually involving filling the tank, heating the iron, and then activating a self-clean button over a sink to flush out mineral deposits.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Iron does not heat up.	Not plugged in; power outlet issue; iron malfunction.	Check power connection; try another outlet; contact customer support if issue persists.
No steam or insufficient steam.	Water tank empty; temperature too low for steam; steam control set to dry; mineral buildup.	Fill water tank; set temperature to steam-suitable setting; adjust steam control; perform descaling.
Water leaks from soleplate.	Temperature too low for steam; water tank overfilled; anti-drip system issue.	Increase temperature; do not overfill tank; ensure anti-drip system is functioning (if persistent, contact support).
White flakes coming from soleplate.	Mineral deposits (limescale) in the water tank.	Perform descaling (self-clean function) thoroughly.

SPECIFICATIONS

Brand	Tefal
Model Name	Virtuo 30
Model Number	FV2C44U0
Power	1400 Watts
Steam Shot	100 g/min
Soleplate Material	Ceramic
Color	Green and White
Dimensions (approx.)	31.1 x 18.1 x 13.7 cm (12.2 x 7.1 x 5.4 inches)
Weight (approx.)	1.27 kg (2.8 lbs)

Sistema antigoteo



Image: The T-fal Virtuo 30 Steam Iron with its approximate dimensions indicated for reference.

WARRANTY AND SUPPORT

T-fal products are manufactured to high quality standards. For warranty information, please refer to the warranty card included with your purchase or visit the official T-fal website. Keep your purchase receipt as proof of purchase.

For technical assistance, spare parts, or repair services, please contact T-fal customer support. Contact details can typically be found on the official T-fal website or in the product packaging.

Online Support: www.tefal.com

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0DXLTGT25>

More documents and user manuals: <https://manuals.plus/>