

Swarovski SK2026D

Swarovski SK2026D Women's Square Prescription Eyewear Frames User Manual

INTRODUCTION

Thank you for choosing Swarovski SK2026D Women's Square Prescription Eyewear Frames. These frames are designed to hold prescription lenses, providing both style and clear vision when fitted by a qualified optician. This manual provides important information regarding the proper setup, use, maintenance, and care of your new eyewear frames.

SETUP

1. Unboxing Your Frames

Upon opening the packaging, you should find the following items:

- Swarovski SK2026D Eyewear Frames
- Protective Eyewear Case
- Cleaning Cloth

Inspect the frames for any visible damage. If you notice any issues, please contact your retailer immediately.

2. Lens Installation

Important: The lenses included with these frames are for demonstration purposes only and are not prescription lenses. They must be replaced with custom prescription lenses by a professional optician.

1. Take your Swarovski SK2026D frames to a certified optician.
2. Provide your current prescription to the optician.
3. The optician will professionally install your prescription lenses into the frames, ensuring proper fit and

alignment.

Do not attempt to install prescription lenses yourself, as this may damage the frames or lenses and void any warranty.

OPERATING (WEARING YOUR FRAMES)

1. Proper Wearing

Gently place the frames on your face, ensuring the nose pads rest comfortably on your nose and the temples extend over your ears without causing pressure. The frames should feel secure but not tight.

2. Adjustments

If your frames feel loose, too tight, or are not sitting correctly on your face, it is recommended to visit your optician for professional adjustments. Minor adjustments to the nose pads or temple arms can significantly improve comfort and fit. Avoid attempting to bend or adjust the frames yourself, as this can cause damage.

3. Handling

Always use both hands to put on and take off your frames to prevent bending or misalignment. Avoid placing your frames face down on hard surfaces to prevent scratching the lenses (once installed) or the frame itself.

MAINTENANCE

1. Cleaning Your Frames and Lenses

Regular cleaning will help maintain the appearance and longevity of your frames and lenses.

- **Daily Cleaning:** Use the provided soft cleaning cloth to gently wipe away smudges and dust from both the frames and lenses.
- **Deeper Cleaning:** For more thorough cleaning, rinse your frames under lukewarm running water. Apply a small drop of mild, pH-neutral dish soap to your fingertips and gently rub the frames and lenses. Rinse thoroughly to remove all soap residue.
- **Drying:** Gently shake off excess water and dry the frames and lenses with a clean, lint-free microfiber cloth. Avoid using paper towels or rough fabrics, as these can scratch lenses.

Do Not Use: Harsh chemicals, ammonia-based cleaners, window cleaner, or abrasive materials, as these can damage the frame finish and lens coatings.

2. Storage

When not wearing your frames, always store them in the protective case provided. This protects them from dust, scratches, and accidental damage. Avoid leaving your frames in direct sunlight or in areas with extreme temperatures, such as a car dashboard, as this can cause warping or damage to the materials.

3. Regular Inspections

Periodically check your frames for loose screws, especially at the hinges. If you notice any looseness, visit your optician for professional tightening to prevent parts from falling off or damage.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Frames feel loose or keep slipping	Temples or nose pads are out of adjustment.	Visit an optician for professional adjustment.
Frames feel too tight or cause discomfort	Frames are too narrow or require adjustment.	Consult an optician for fitting adjustments.
Screws are loose	Normal wear and tear.	Have an optician tighten the screws. Avoid overtightening yourself.
Lenses (once installed) are scratched	Improper cleaning or storage.	Follow proper cleaning and storage instructions. Scratched lenses may need replacement by an optician.

SPECIFICATIONS

- **Brand:** Swarovski
- **Model Number:** SK2026D
- **Frame Type:** Square, Oversized
- **Features:** Crystal hinges
- **Department:** Women's
- **Manufacturer:** Swarovski
- **ASIN:** B0DXNKV3C

WARRANTY AND SUPPORT

Swarovski eyewear frames sold by authorized sellers are eligible for manufacturer warranties. For specific warranty details, please refer to the documentation provided at the time of purchase or contact Swarovski customer support. For any product-related inquiries or support, please reach out to your authorized Swarovski retailer or visit the official Swarovski website.

PRODUCT IMAGE



This image is a placeholder indicating that a specific product image for the Swarovski SK2026D frames was not available at the time of manual creation. The actual product features an oversized square, black frame with crystal hinges.