

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

› [dainslef](#) /

› dainslef Countertop Dishwasher User Manual

dainslef E9DHGB01

dainslef Countertop Dishwasher User Manual

Model: E9DHGB01

1. INTRODUCTION

Thank you for choosing the dainslef Countertop Dishwasher. This compact and portable appliance is designed to provide efficient and convenient dishwashing for small households, apartments, RVs, and dorms. With its versatile washing programs and flexible water supply options, it simplifies your daily cleaning routine. Please read this manual thoroughly before operation to ensure proper use, maintenance, and optimal performance.



The dainslef Countertop Dishwasher, showcasing its compact design and internal washing process.

2. PRODUCT FEATURES

- **Versatile Washing Programs:** Equipped with 5 tailored washing cycles—Normal, Strong, Rapid, ECO, and Fruit wash—to effectively tackle various dish types and stubborn food residues.
- **Compact Size, Large Capacity:** Measures 17.72 x 17.32 x 18.03 inches, accommodating 4 full place settings and dishes up to 12 inches at an angle. Double-layer design provides space for 4 serving bowls, cups, small plates, dinner plates, and utensils, ideal for 3-4 people.
- **Advanced Cleaning Technology:** Features PTC hot air drying for thorough drying and hygiene. Includes a 90-minute cycle every 12 hours and a delay start option for convenience.

- **Multiple Connection Options:** Choose between the 5-liter built-in water tank for portability or direct faucet connection for uninterrupted water supply.
- **Easy to Use & Maintain:** Simple control panel and clear instructions. Plastic glass door allows monitoring of washing progress. Removable filter ensures hassle-free maintenance.

Dual Spray Arms & 360° Rinsing

Rinses dishes thoroughly without obstruction



>29 mins high pressure washing



360° cleaning coverage

The dishwasher features dual spray arms for comprehensive 360-degree rinsing.

5 Washing Programs



PTC Hot Air Drying and Ventilation system ensures dishes are thoroughly dried and sterilized.

3. WHAT'S IN THE BOX

Upon unpacking your dainslef Countertop Dishwasher, please ensure all components are present and in good condition:

- 1 x Countertop Dishwasher
- 1 x User Manual

Compact Size But BIG Capacity

Generous 4.5L capacity for tableware for 2-3



Included accessories for your dainslef Countertop Dishwasher.

4. SETUP

The dainslef Countertop Dishwasher offers flexible water supply options for your convenience.

4.1 Water Tank Mode (No Hookup Needed)

This mode utilizes the built-in 5-liter water tank, making the dishwasher fully portable and ideal for locations without direct plumbing access.

1. Place the dishwasher on a stable, level surface near a power outlet.
2. Locate the filling port on the top of the dishwasher.
3. Slowly pour water into the filling port using a measuring cup or pitcher until the tank is full. The machine will issue 3 beeps when the tank is full.
4. Ensure the drainage hose is properly placed into a sink or bucket for wastewater discharge.

4.2 Faucet Connection Mode

For continuous water supply, you can connect the dishwasher directly to a faucet.

1. Connect the provided water inlet hose to the water inlet port on the back of the dishwasher.
2. Attach the other end of the water inlet hose to your kitchen faucet using the appropriate adapter (not always included, may require separate purchase depending on faucet type).
3. Ensure all connections are secure to prevent leaks.
4. Ensure the drainage hose is properly placed into a sink or bucket for wastewater discharge.

75% Water Saving

It only needs 5L water for normal cycle when saving 75% than washing by hands



Key connection points: Filling Port, Water Inlet Hose, Detachable Filter, and Drainage Hole.

Wash Dishes Anywhere

With its compact size and 4.8 qt water tank, it can be used in dorm, RV and home.



The dishwasher supports both built-in water tank and direct faucet connection modes.

5. OPERATING INSTRUCTIONS

Operating your dainslef Countertop Dishwasher is straightforward thanks to its intuitive control panel.

5.1 Loading Dishes

Arrange dishes in the provided rack, ensuring they do not block the spray arms or detergent dispenser. For optimal cleaning, avoid overcrowding.



The dishwasher can hold over 30 different types of tableware.

5.2 Adding Detergent

Add a small amount of dishwasher detergent (liquid or powder) to the designated dispenser. Do not use hand dish soap.

5.3 Selecting a Program

Use the control panel to select one of the 5 washing programs based on your needs.

PTC Hot Air Drying & Ventilation

149°F high temp spray rapid cleaning and sterilization



Control panel displaying the 5 available washing programs and their durations.

5.4 Starting the Cycle

Press the 'Pause/Start' button to begin the selected washing cycle. The glass door allows you to monitor the washing progress.

5.5 Delay Start Function

The dishwasher features a delay start option for added convenience, allowing you to set a delayed start time for your wash cycle.

6. WASHING PROGRAMS

Choose the appropriate program for your dishwashing needs:

Program	Description	Approx. Duration
---------	-------------	------------------

Program	Description	Approx. Duration
ECO	Energy-saving cycle for lightly soiled dishes.	139 minutes
Strong	Intensive wash for heavily soiled dishes and stubborn food residues.	99 minutes
Normal	Standard cycle for everyday dishes with normal soil.	79 minutes
Rapid	Quick wash for lightly soiled dishes that need to be cleaned fast.	29 minutes
Fruit Wash	Gentle wash cycle specifically designed for cleaning fruits.	18 minutes

7. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your dishwasher.

7.1 Cleaning the Filter

The dishwasher features a removable filter for easy cleaning. Regularly remove and rinse the filter under running water to remove food particles and debris. This prevents blockages and ensures efficient cleaning.

75% Water Saving

It only needs 5L water for normal cycle when saving 75% than washing by hands



The detachable filter is easily accessible for cleaning.

7.2 Exterior and Interior Cleaning

Wipe the exterior with a soft, damp cloth. For the interior, periodically run a cleaning cycle with a dishwasher cleaner or a mixture of vinegar and baking soda to remove mineral buildup and odors.

7.3 PTC Hot Air Drying

The PTC hot air drying function not only dries your dishes but also helps to keep the interior of the dishwasher hygienic. It runs a 90-minute cycle every 12 hours to maintain freshness.

8. TROUBLESHOOTING

If you encounter any issues with your dishwasher, please refer to the following common troubleshooting tips:

- **Dishwasher not starting:** Ensure the power cord is securely plugged in and the door is fully closed. Check if a program has been selected and the 'Start' button pressed.
- **Dishes not clean:** Check if the spray arms are blocked by dishes. Ensure the filter is clean. Use the correct amount and type of detergent. Select a more intensive washing program if needed.

- **Water not draining:** Check the drainage hose for kinks or blockages. Ensure the drain filter is clean.
- **Dishwasher leaking:** Verify that the water inlet and drainage hoses are securely connected. Check the door seal for any damage or debris.
- **Unusual noises:** Ensure dishes are properly loaded and not interfering with the spray arms. Check for any foreign objects inside the dishwasher.

If the problem persists, please contact customer support.

9. SPECIFICATIONS

Specification	Value
Brand	dainslef
Model Name	E9DHGB01
Item Model Number	m9zvYk3P5jKzTsVA-t3fhwbmbbV
Installation Type	Countertop
Product Dimensions (D x W x H)	21.26" x 20.87" x 20.87" (54 x 53 x 53 cm)
Item Weight	34.4 pounds (15.6 kg)
Capacity	5 Liters (Built-in Water Tank)
Voltage	115V
Noise Level	45 dB
Controls Type	Touch
Color	White
Special Features	5 Versatile Washing Programs, No Hookup Needed, Convenient Water Supply, PTC Hot Air Drying
UPC	199108655363
Country of Origin	China
Date First Available	February 19, 2025

10. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your purchase or contact dainslef customer service directly. Keep your purchase receipt as proof of purchase for any warranty claims. For further assistance, visit the official dainslef store on Amazon:[dainslef Store](#)

