

[Manuals.plus](#) /

> [HP](#) /

> HP K270 Wireless Keyboard User Manual

HP K270

HP K270 Wireless Keyboard User Manual

Model: K270

INTRODUCTION

The HP K270 Wireless Keyboard is designed to provide a comfortable and efficient typing experience. This keyboard features a reliable 2.4 GHz wireless connection, vintage round keycaps, and integrated multimedia controls, making it suitable for various computing tasks. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your keyboard.



Image: HP K270 Wireless Keyboard, showcasing its full layout.

SETUP INSTRUCTIONS

Follow these steps to set up your HP K270 Wireless Keyboard:

1. **Insert Batteries:** Open the battery compartment on the underside of the keyboard. Insert the required batteries (typically AA or AAA, not specified in product data, assume standard for wireless keyboards) ensuring correct polarity.
2. **Connect the USB Receiver:** Locate the 2.4 GHz USB receiver, usually stored within the battery compartment or a dedicated slot on the keyboard. Plug this receiver into an available USB port on your computer.
3. **Power On:** Ensure the keyboard's power switch (if present) is in the 'ON' position.
4. **Automatic Connection:** The keyboard should automatically connect to your computer. No additional drivers are typically required for basic functionality.



Image: Visual representation of the 2.4 GHz wireless connection setup.

OPERATING THE KEYBOARD

The HP K270 keyboard offers standard typing functionality along with several convenient features:

- **Standard Keys:** All standard alphanumeric, symbol, and navigation keys function as expected.
- **Function (Fn) Key Combinations:** The keyboard integrates 12 shortcut combinations using the Fn key. These allow quick access to functions such as music control, movie playback, volume adjustment, homepage access, bookmark management, and email client launch. Refer to the key legends for specific combinations.
- **Numeric Keypad:** A dedicated numeric keypad is included for efficient data entry.
- **Indicator Lights:** The keyboard features illuminated indicators for Num Lock, Caps Lock, and Scroll Lock, providing clear visual feedback on their status.




Image: Close-up of the keyboard highlighting the function keys and their shortcuts.

Looks good, feels good, works great

HP K270 Wireless Keyboard



Image: Detail of the keyboard showing the illuminated status indicators.

MAINTENANCE

To ensure the longevity and optimal performance of your HP K270 Wireless Keyboard, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe the keyboard surface. For deeper cleaning, a slightly damp cloth with mild soap can be used, ensuring no liquid enters the key mechanisms. Avoid abrasive cleaners or solvents.
- **Battery Replacement:** When the keyboard's performance degrades or it stops responding, replace the batteries. Always use fresh batteries of the specified type. Dispose of old batteries responsibly.
- **Storage:** Store the keyboard in a cool, dry place away from direct sunlight and extreme temperatures.

Get back the control of your work

Designed to match your workflow, this keyboard offers all-day comfort. With an ergonomic build and effortless navigation, it's made to keep you in sync.



Image: Close-up of the keyboard's keycaps, illustrating its design for easy cleaning.

TROUBLESHOOTING

If you encounter issues with your HP K270 Wireless Keyboard, try the following solutions:

Problem	Possible Solution
---------	-------------------

Problem	Possible Solution
Keyboard not responding	<ul style="list-style-type: none"> Check if the USB receiver is securely plugged into a working USB port. Ensure the keyboard batteries are fresh and correctly inserted. Move the keyboard closer to the USB receiver to rule out range issues. Try plugging the USB receiver into a different USB port.
Lag or intermittent response	<ul style="list-style-type: none"> Reduce interference by moving other wireless devices away from the receiver. Replace batteries.
Specific keys not working	<ul style="list-style-type: none"> Clean around the affected keys to remove any debris. Ensure the keyboard is not in a special mode (e.g., gaming mode if applicable, though not specified for this model).

SPECIFICATIONS

Feature	Detail
Brand	HP
Model	K270
Item Model Number	AB3D4AA
Connectivity Technology	Wireless (2.4 GHz)
Keyboard Description	Multimedia
Color	Black
Product Dimensions (LxWxH)	44 x 14.1 x 2.6 cm
Item Weight	400 g
Compatible Devices	Laptops, PCs
Special Feature	Backlit LED (for indicators)

WARRANTY AND SUPPORT

HP products are backed by a limited warranty. For detailed warranty information, please refer to the warranty card included with your product or visit the official HP support website. For technical assistance, driver downloads, or further inquiries, please visit www.hp.com/support or contact HP customer service in your region.