

BR67050277 AS00004188

Instruction Manual

PLASTIC JAR JUG 1.25 L COMPATIBLE WITH BRAUN HAND HELD BLENDER

Model: BR67050277 AS00004188

1. Product Overview

This instruction manual provides essential information for the safe and effective use of your 1.25 L Plastic Jar Jug, designed as a compatible spare part for various Braun Hand Held Blenders. This jug is intended to replace a damaged or lost original jug, restoring the full functionality of your blender.



Image 1.1: The 1.25 L Plastic Jar Jug. This clear plastic jug features a sturdy handle and embossed measurement markings on its side, designed for use with compatible Braun hand-held blenders.

Please note that this product is supplied as a spare part and does not include commercial packaging or a retail box. You will receive the part exactly as depicted in the product images.

2. Setup

- Unpacking:** Carefully remove the jug from its protective packaging. Inspect the jug for any signs of damage that may have occurred during transit. If damage is observed, do not use the product and contact your seller immediately.
- Initial Cleaning:** Before first use, wash the jug thoroughly with warm, soapy water. Rinse it completely and allow it to air dry or dry with a clean cloth. This removes any manufacturing residues.
- Compatibility Check:** Ensure your Braun hand-held blender model is listed as compatible with this jug. Refer to the "Specifications" section for a list of compatible models.

3. Operating Instructions

This jug is designed to be used in conjunction with a compatible Braun hand-held blender. It does not contain any moving parts or electrical components itself.

- 1. Placement:** Place the jug on a stable, flat surface.
- 2. Ingredient Addition:** Add your desired ingredients into the jug. Do not exceed the maximum fill line indicated on the jug to prevent overflow during blending.
- 3. Blender Insertion:** Carefully insert the blending shaft of your compatible Braun hand-held blender into the jug, ensuring the blade is fully submerged in the ingredients.
- 4. Blending:** Operate your hand-held blender according to its own instruction manual. Maintain a firm grip on both the blender and the jug during operation.
- 5. Removal:** Once blending is complete, switch off and unplug the hand-held blender before carefully removing its blending shaft from the jug.

Safety Note: Always ensure the hand-held blender is switched off and unplugged before inserting or removing the blending shaft, or before cleaning. Avoid touching the blender blades.

4. Maintenance and Cleaning

Proper cleaning and maintenance will extend the life of your jug.

- After Each Use:** Immediately after each use, rinse the jug with water to prevent food residues from drying and sticking.
- Hand Washing:** Wash the jug with warm water and a mild dish soap. Use a soft sponge or cloth to clean the interior and exterior. Avoid abrasive cleaners or scouring pads, as these can scratch the plastic surface.
- Dishwasher Safe:** The jug is generally dishwasher safe. Place it on the top rack of your dishwasher to prevent potential warping from excessive heat.
- Drying:** Allow the jug to air dry completely before storing to prevent water spots and mildew.
- Storage:** Store the jug in a clean, dry place away from direct sunlight and extreme temperatures.

5. Troubleshooting

Problem	Possible Cause	Solution
Jug does not fit blender.	Incompatible blender model.	Verify your blender model against the compatible list in the "Specifications" section. This jug is designed for specific Braun hand-held blenders.
Jug appears cloudy or scratched.	Use of abrasive cleaners or hard water deposits.	Clean with soft cloth and mild soap. For hard water stains, a vinegar solution may help. Avoid abrasive materials.
Jug leaks during blending.	Jug is cracked or damaged; overfilling.	Inspect the jug for cracks. Do not use if damaged. Ensure you do not exceed the maximum fill line.

6. Specifications

- Product Type:** Replacement Jar Jug for Hand-Held Blenders
- Capacity:** 1.25 Liters (L)
- Material:** Food-grade Plastic
- Color:** Clear

- **Compatible With Braun Models:**

- 4130-MQ940, 4130-MR740
- 4191-MQ5045, 4191-MQ5064, 4191-MQ5245, 4191-MQ5264, 4191-MQ545, 4191-MR40, 4191-MR540, 4191-MR5500, 4191-MR5550, 4191-MR6550
- 4192-MQ3045, 4192-MQ3048
- 4193-MQ314, 4193-MQ3145, 4193-MR4000, 4193-MR4050
- 4199-MQ745
- 4200-MQ9045, 4200-MQ9047, 4200-MQ9097
- HB701AI-MQ7046, HB701-MQ7045
- HB901AJ-MQ9145, HB901-MQ9145, HB901-MQ9147
- MQ40, MQ5

- **Known As / Part Number:** BR67050277 AS00004188

- **Approximate Package Dimensions:** 2.54 x 2.54 x 2.54 cm (Note: These are package dimensions, not product dimensions.)

7. Warranty and Support

As this product is supplied as a spare part, specific warranty terms may vary. For any questions regarding defects, compatibility, or returns, please contact the seller directly through your purchase platform. Retain your proof of purchase for any support inquiries.

This manual is for informational purposes only. The manufacturer and seller are not responsible for any damage or injury caused by improper use of this product or the associated appliance.

