Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

SUPERJARE 70301

SUPERJARE 39.4 inch Narrow Behind Couch Table with Charging Stations

Model: 70301 - Instruction Manual

1. Important Safety Information

Please read and understand all instructions before assembling and using this product. Keep this manual for future reference.

- **Weight Capacity:** Do not exceed the maximum weight capacity of 200 pounds (90.7 kg) for the tabletop. Distribute weight evenly.
- **Stability:** To prevent tipping, always attach the provided anti-tipping kit to a wall stud. Ensure the table is placed on a flat, stable surface.
- **Electrical Safety:**
  - Do not overload the charging station. Ensure total power draw does not exceed the rated capacity (125V/12A).
  - Do not expose the charging station or power cord to water or excessive moisture.
  - Do not use if the power cord or plug is damaged.
  - Keep children away from electrical outlets.
- **Assembly:** Ensure all screws and fasteners are securely tightened before use. Periodically check and re-tighten as necessary.
- **Children:** Do not allow children to climb on or play with the table. Small parts can be a choking hazard.



Image: Illustration of anti-tipping kit installation. The kit secures the table to the wall to prevent accidental tipping.

2. Package Contents

Before assembly, verify that all parts listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Tabletop Panels (3 sections)
- Metal Frame Components (Legs, Crossbars)
- Charging Station Unit (with power cord)
- Screws and Fasteners
- Hex Key / Allen Wrench (Installation Tool)
- Anti-Tipping Kit
- Assembly Guide

3. Assembly Instructions

Assembly typically takes approximately 15 minutes. A Phillips head screwdriver (not included) may be helpful in addition to the provided tools.

1. **Unpack and Identify Parts:** Carefully remove all components from the packaging. Lay them out on a soft, clean surface to prevent scratches. Refer to the included assembly guide to identify each part.
2. **Assemble the Metal Frame:** Attach the crossbars to the leg frames using the provided screws and hex key. Do not fully tighten screws until all components are loosely assembled.
3. **Attach Tabletop Panels:** Place the tabletop panels onto the assembled metal frame. Align the pre-drilled holes on the panels with the holes on the frame. Secure the panels using the appropriate screws.
4. **Install Charging Station:** The charging station can be installed in one of the pre-cut slots on the tabletop (middle or side). Insert the charging station unit into your desired slot and secure it with the provided screws.
5. **Tighten All Screws:** Once all components are in place, go back and securely tighten all screws. Do not overtighten.
6. **Attach Anti-Tipping Kit:** Position the table in its desired location. Follow the instructions provided with the anti-tipping kit to secure the table to a wall stud. This is crucial for stability.
7. **Adjust Leveling Feet:** The table is equipped with adjustable feet. Turn them clockwise or counter-clockwise to level the table on uneven floors.



Image: Various assembly options for the outlet. The charging station can be positioned in the middle or on the side of the tabletop.



Image: Illustration of connecting two tables. A metal sheet can be used to join multiple tables for extended length.

4. Operating the Charging Station

The integrated charging station provides convenient power access for your devices.

1. **Power Connection:** Plug the charging station's power cord into a standard 120V AC wall outlet.
2. **AC Outlets:** Use the two standard AC outlets (125V/12A) to power lamps, laptops, or other small appliances.
3. **USB-A Port:** Connect your USB-A compatible devices (5V-2A) for charging.
4. **USB-C Port:** Connect your USB-C compatible devices (5V-2A) for charging.

Important: Always ensure your devices are compatible with the charging station's output specifications to prevent damage.



Image: Multiple charging options. The station includes two AC outlets, one USB-C port, and one USB-A port for versatile device charging.

5. Care and Maintenance

- **Cleaning:** Wipe the table surfaces with a soft, damp cloth. Avoid using harsh chemicals, abrasive cleaners, or furniture polish that may damage the finish.
- **Spills:** Clean up spills immediately to prevent staining or damage to the engineered wood.
- **Inspection:** Periodically check all screws and fasteners to ensure they remain tight. Re-tighten as needed.
- **Environment:** Avoid placing the table in direct sunlight or near heat sources, as this can cause fading or warping. Keep away from excessive moisture.

6. Troubleshooting

Table Wobbles or is Uneven

- Ensure all assembly screws are securely tightened.

- Adjust the leveling feet on the bottom of the legs to compensate for uneven floors.
- Verify the table is placed on a flat, stable surface.
- Ensure the anti-tipping kit is properly installed and secured to the wall.

Charging Station Not Working

- Check if the power cord is securely plugged into both the charging station and a working wall outlet.
- Test the wall outlet with another device to ensure it is supplying power.
- Ensure the total power draw of connected devices does not exceed the charging station's rated capacity.
- Verify that your device's charging cable is functional and properly connected.

7. Product Specifications

Brand	SUPERJARE
Model Number	70301
Product Dimensions	5.7"D x 39.4"W x 29.7"H (14.5 cm D x 100 cm W x 75.4 cm H)
Item Weight	9 pounds (4.08 kg)
Maximum Weight Recommendation	200 pounds (90.7 kg)
Frame Material	Metal
Top Material	Engineered Wood
Color	Rustic Brown
AC Outlets	2 (125V/12A)
USB-A Port	1 (5V-2A)
USB-C Port	1 (5V-2A)




Image: Product dimensions. The table measures 39.4 inches in width, 5.7 inches in depth, and 29.7 inches in height.

8. Warranty Information

This SUPERJARE product comes with a**Limited Warranty**. For specific details regarding warranty coverage, terms, and conditions, please refer to the warranty card included with your product or visit the official SUPERJARE website. Please retain your proof of purchase for warranty claims.

9. Customer Support

If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact SUPERJARE customer support:

- **Website:** Visit the official SUPERJARE website for FAQs, support resources, and contact information.
- **Email/Phone:** Refer to your product packaging or the SUPERJARE website for specific contact details.

Please have your model number (70301) and purchase information ready when contacting support.

© 2026 SUPERJARE. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DXQ4LJV5

More documents and user manuals: **https://manuals.plus/**