

[Manuals.plus](#) /

› [HOgardenME](#) /

› HOgardenME Electric Scooter Display Dashboard User Manual for M365/1S/PRO/PRO2/MI3

HOgardenME TO3J66246Z1766ZQ6C1Z

HOgardenME Electric Scooter Display Dashboard User Manual

Model: TO3J66246Z1766ZQ6C1Z

INTRODUCTION

This manual provides detailed instructions for the installation, operation, and maintenance of your HOgardenME Electric Scooter Display Dashboard. This product is designed as a replacement kit for Xiaomi M365, 1S, PRO, PRO2, and MI3 electric scooters, offering an upgraded panel for enhanced user experience. Please read this manual thoroughly before installation and use to ensure proper function and safety.

IMPORTANT SAFETY INFORMATION

WARNING: It is illegal to ride electric scooters on public roads, pavements, or cycle paths in many regions. They are intended only for use on private land with the owner's permission. Always check local regulations before use. Ensure the scooter is powered off before performing any installation or maintenance.

PACKAGE CONTENTS

Verify that all items listed below are present in your package:

- 1 x Bluetooth Circuit Board
- 1 x Dashboard Display
- 1 x Adhesive Sticker
- 1 x Installation Tool (Screwdriver)
- 3 x Screws



Image: All components included in the package, including the circuit board, dashboard, sticker, tool, and screws.

SETUP AND INSTALLATION

This display dashboard is designed for easy installation. Follow these steps to replace your old or broken dashboard:

1. **Prepare the Scooter:** Ensure your electric scooter is powered off and disconnected from any charging source.
2. **Remove Old Dashboard:** Carefully remove the existing dashboard and its cover from your scooter. This may involve unscrewing a few fasteners.
3. **Disconnect Wiring:** Gently disconnect the wiring harness from the old circuit board. Note the orientation of the connectors.
4. **Install New Circuit Board:** Connect the new Bluetooth circuit board to the scooter's wiring harness. Ensure connections are secure.



Image: The Bluetooth circuit board with its wiring harness, ready for connection.

5. **Attach Dashboard Display:** Place the new dashboard display into its housing.





Image: The new dashboard display unit and the red adhesive sticker for secure mounting.

6. **Secure with Cover and Screws:** Apply the provided adhesive sticker if necessary, then place the dashboard cover over the display. Use the included screws and tool to secure the cover and dashboard in place.



Image: The screwdriver and three screws provided for installation.

7. **Test Functionality:** Power on your scooter to verify that the new display dashboard is functioning correctly.

OPERATING INSTRUCTIONS

The upgraded display panel provides clear and accurate information essential for your ride. Once installed and powered on, the dashboard will display key metrics:

- **Speed:** Shows current speed in km/h or mph.
- **Battery Level:** Indicates the remaining battery charge.
- **Riding Mode:** Displays the current riding mode (e.g., D for Drive, S for Sport).
- **Headlight Indicator:** Shows if the headlight is on or off.
- **Bluetooth Connection:** Indicates Bluetooth status.
- **Temperature:** May display internal temperature.





Image: A detailed view of the display dashboard showing various indicators like speed, battery, and riding mode.

Refer to your scooter's main user manual for specific instructions on how to switch riding modes or control other functions via the dashboard interface.

MAINTENANCE

To ensure the longevity and optimal performance of your display dashboard, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe the display screen. Avoid abrasive cleaners or solvents that could damage the plastic.
- **Protection:** Keep the dashboard free from excessive moisture, direct sunlight, and extreme temperatures.
- **Inspection:** Periodically check the connections and screws to ensure they remain tight and secure.
- **Storage:** If the scooter is stored for an extended period, ensure it is in a dry, temperate environment.

TROUBLESHOOTING

If you encounter issues with your display dashboard, try the following solutions:

- **Display Not Turning On:**
 - Ensure the scooter's battery is charged.
 - Check all wiring connections to the circuit board for looseness.
 - Verify the scooter's main power switch is on.
- **Incorrect Readings:**
 - Restart the scooter.
 - Ensure the dashboard is securely seated and connections are firm.
- **Loose Dashboard:**
 - Tighten the screws holding the dashboard cover.
 - Reapply the adhesive sticker if it has lost its grip.

If problems persist after attempting these steps, please contact customer support.

SPECIFICATIONS

Product Dimensions	4.72 x 3.94 x 0.39 inches
Item Weight	1.55 ounces (approx. 50g/set)
Material	Plastic + Metal
Compatible Models	Xiaomi M365, 1S, PRO, PRO2, MI3 Electric Scooters
Model Number	TO3J66246Z1766ZQ6C1Z

WARRANTY AND SUPPORT

This product is covered by a standard manufacturer's warranty against defects in materials and workmanship. For specific warranty terms and conditions, please refer to the product packaging or contact your retailer.

For technical support, troubleshooting assistance, or warranty claims, please contact HOgardenME customer service through the retailer's platform or the contact information provided with your purchase.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question