

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Shark](#) /

› [Shark FlexBreeze HydroGo Fan Instruction Manual - Model FA052BL](#)

Shark FA052BL

Shark FlexBreeze HydroGo Fan Instruction Manual

Model: FA052BL

Brand: Shark

INTRODUCTION

Thank you for choosing the Shark FlexBreeze HydroGo Fan. This ultra-powerful, ultra-portable fan is designed to provide personal evaporative misting both indoors and outdoors. With its versatile features and long-lasting battery, you can enjoy cooling and misting wherever you need it. Please read this manual thoroughly before use to ensure safe and optimal operation of your device.

IMPORTANT SAFETY INFORMATION

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and personal injury.

- Read all instructions before using the fan.
- Do not immerse the fan, cord, or plug in water or other liquids.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use, before cleaning, or before moving the fan.
- Do not operate any fan with a damaged cord or plug, or after the fan malfunctions or has been dropped or damaged in any manner.
- Do not use outdoors or in wet conditions unless specifically designed for such use. This fan is designed for both indoor and outdoor use, but avoid charging in the rain.
- Do not let the cord hang over the edge of a table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always place the fan on a stable, flat surface during operation.
- Ensure the water tank is empty and dry completely after every use to prevent mold or mildew growth.

WHAT'S INCLUDED

- Shark FlexBreeze HydroGo Fan
- Charging Cable



The ultra-powerful,
portable fan that **cools**
and **mists** anywhere

Image: Shark FlexBreeze HydroGo Fan and its charging cable, illustrating the complete package contents.

SETUP

1. Initial Charging

Before first use, fully charge your Shark FlexBreeze HydroGo Fan using the provided charging cable. The battery indicator lights on the top of the fan will show the charging status. A full charge can provide up to 12 hours of runtime on speed 1 without mist.



Lightweight portability
to bring the breeze on the go

Image: The top panel of the Shark FlexBreeze HydroGo Fan displaying the battery indicator lights, which illuminate green to show charge level.

2. Misting Setup

The fan features an integrated misting tank for evaporative cooling.

1. Locate the water tank cap on the top of the fan, near the handle.
2. Open the cap and carefully fill the tank with clean water. Do not overfill.
3. Close the cap securely.

Dynamic colors for every style



Image: A close-up of the Shark FlexBreeze HydroGo Fan's top, showing the misting tank cap open for water refill.

3. Positioning

Place the fan on a stable, flat surface. The adjustable tilt feature allows you to direct airflow as needed. It is suitable for both indoor and outdoor environments.

Battery runtime*



12 Hours

Speed 1



4 Hours

Speed 3



1.5 Hours

Speed 5



*Without mist.

Image: The Shark FlexBreeze HydroGo Fan placed on a bedside table, demonstrating its compact size and suitability for indoor use.

OPERATING INSTRUCTIONS

1. Power On/Off

Press the power button located on the top panel to turn the fan on or off.

2. Fan Speed Adjustment

The fan offers 5 speed settings. Press the fan speed button (indicated by a fan icon) repeatedly to cycle through the speeds. The LED indicators on the top panel will show the current speed setting.

Your browser does not support the video tag.

Video: An official product video demonstrating the Shark FlexBreeze HydroGo Fan's features, including its portability and misting function. This video highlights the fan's use in various settings and its ability to drop temperatures.

3. Misting Function

To activate the evaporative misting function, ensure the water tank is filled. Press the mist button (indicated by a water droplet icon) on the top panel. The fan will begin to emit a fine mist, reducing ambient temperatures by up to 5°F.



Image: The Shark FlexBreeze HydroGo Fan providing evaporative mist to a child outdoors, illustrating its cooling effect.

4. Corded & Cordless Operation

The fan can be operated corded by plugging it into an AC outlet, or cordless using its internal rechargeable battery. The battery provides long-lasting runtime, making it ideal for on-the-go cooling.

5. Vertical Tilt

Adjust the angle of the fan head manually to direct the airflow precisely where it's needed.

KEY FEATURES

- **Ultra-Portable Design:** Weighing only 3.86 pounds with an easy-carry handle, the fan is designed for ultimate portability.

- **Powerful Cooling:** Delivers up to 70 feet of portable cooling power.
- **Long-Lasting Battery:** Up to 12 hours of battery runtime on speed 1 (without mist).
- **Evaporative Misting:** Built-in HydroGo misting tank reduces personal temperatures by up to 5°F.
- **Indoor & Outdoor Use:** Durable and water-resistant design suitable for various environments.
- **Quiet Operation:** Operates at a low noise level of 36 Decibels.
- **Multiple Speeds:** 5 fan speed settings for customized airflow.



Image: A person carrying the Shark FlexBreeze HydroGo Fan by its integrated handle, highlighting its lightweight and portable design.

MAINTENANCE

1. Cleaning

- Always unplug the fan before cleaning.
- Wipe the exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- For the misting nozzle, gently wipe with a soft cloth to prevent mineral buildup.

2. Water Tank Care

After every use of the misting function, it is crucial to empty the water tank and let it dry completely to prevent mold or mildew growth and maintain optimal performance.

3. Storage

When not in use, store the fan in a cool, dry place. Ensure the water tank is empty and dry before storing.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Fan does not turn on.	No power, low battery, or power button not pressed.	Ensure the fan is charged or plugged in. Press the power button firmly.
Misting function not working.	Water tank empty, misting nozzle clogged, or mist button not activated.	Fill the water tank. Clean the misting nozzle. Press the mist button.
Reduced airflow.	Fan blades are dirty or obstructions.	Clean the fan blades. Ensure no objects are blocking the fan's intake or output.
Battery not holding charge.	Battery degradation or improper charging.	Ensure you are using the original charging cable. Contact customer support if the issue persists.

SPECIFICATIONS

Feature	Detail
Model Name	FlexBreeze HydroGo Fan
Model Number	FA052BL
Brand	Shark
Power Source	AC/DC (Corded & Cordless)
Product Dimensions	8.65"D x 8.35"W x 11.47"H
Item Weight	3.86 Pounds
Noise Level	36 Decibels
Number of Power Levels	5
Air Flow Capacity	425 Cubic Feet Per Minute
Special Features	Adjustable Tilt, Lightweight, Misting, Portable, Quiet Operation
Indoor/Outdoor Usage	Indoor, Outdoor
Control Method	Touch
Reusability	Rechargeable

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your product or visit the official Shark website. Keep your purchase receipt as proof of purchase for any warranty claims.

© 2025 SharkNinja. All rights reserved.