

[Manuals.plus](#) /

› [BoxWave](#) /

› BoxWave ClearTouch Anti-Glare Screen Protector User Manual for Tranya ES10 Smartwatch

BoxWave ClearTouch Anti-Glare (for Tranya ES10 Smartwatch)

BoxWave ClearTouch Anti-Glare Screen Protector User Manual

For Tranya ES10 Smartwatch

1. INTRODUCTION

This manual provides instructions for the installation and care of your BoxWave ClearTouch Anti-Glare Screen Protector, designed specifically for the Tranya ES10 Smartwatch. This product is engineered to reduce glare, resist fingerprints, and protect your device's screen from scratches.

2. PACKAGE CONTENTS

Verify that all items are present in your package:

- Two (2) BoxWave ClearTouch Anti-Glare Screen Protectors
- One (1) Microfiber Cleaning Cloth
- One (1) Applicator Card (Squeegee)
- One (1) Dust Removing Sticker

Anti-Smudge Surface

Protects Against Fingerprints



Other Brands



Image: Contents of the BoxWave ClearTouch Anti-Glare Screen Protector package, showing two screen protectors, a microfiber cloth, an

3. INSTALLATION INSTRUCTIONS

Follow these steps carefully for optimal screen protector application. Perform installation in a clean, dust-free environment.

1. **Prepare Your Device:** Ensure your Tranya ES10 Smartwatch screen is powered off and completely clean. Use the provided microfiber cloth to remove all dust, smudges, and fingerprints. For stubborn marks, a screen cleaner (not included) can be used, followed by thorough drying.
2. **Remove Dust:** Use the dust-removing sticker to lift any remaining dust particles from the screen surface. Inspect the screen carefully under light to ensure it is spotless.
3. **Align the Protector:** Carefully peel back a small portion of the protective film labeled "Step 1" or similar from one end of the screen protector. Align the exposed edge of the screen protector with the corresponding edge of your smartwatch screen. Ensure precise alignment with all cutouts (if any) and edges.
4. **Apply the Protector:** Once aligned, slowly and steadily peel back the rest of the "Step 1" film while simultaneously using the applicator card to smooth the screen protector onto the smartwatch screen. Apply gentle, even pressure to push out any air bubbles as you go. Work from the aligned edge towards the opposite end.
5. **Remove Air Bubbles:** If air bubbles remain, gently push them towards the nearest edge using the applicator card. Small bubbles may disappear over 24-48 hours.
6. **Remove Top Film:** Once the screen protector is fully applied and smoothed, carefully peel off the top protective film labeled "Step 2" or similar.
7. **Final Cleaning:** Use the microfiber cloth to gently wipe the newly installed screen protector, removing any smudges from the application process.



Image: Illustration showing the initial cleaning of a device screen before applying the screen protector.



Image: Illustration demonstrating the alignment of the screen protector onto the device screen.



Image: Illustration showing the use of an applicator card (squeegee) to smooth the screen protector and remove air bubbles during application.

4. OPERATING YOUR DEVICE WITH THE SCREEN PROTECTOR

The BoxWave ClearTouch Anti-Glare Screen Protector is designed to integrate seamlessly with your Tranya ES10 Smartwatch, maintaining full touch screen functionality and responsiveness. The matte finish reduces glare and minimizes fingerprints, enhancing visibility in various lighting conditions.

- **Touch Sensitivity:** The screen protector is engineered to preserve the original touch sensitivity of your device. If you experience any reduction in responsiveness, ensure the protector is applied smoothly without air gaps.
- **Anti-Glare Feature:** The matte surface disperses light, reducing reflections from bright light sources or direct sunlight. This improves screen readability outdoors and in brightly lit indoor environments.
- **Anti-Fingerprint Feature:** The oleophobic coating on the protector helps repel smudges and fingerprints, keeping your screen cleaner for longer.




Image: A visual comparison showing a device screen with distracting glare on the left and the same screen with reduced glare on the right, illustrating the anti-glare effect.




Image: An illustration demonstrating how the anti-smudge surface of the screen protector resists fingerprints compared to a standard screen.

5. CARE AND MAINTENANCE

To ensure the longevity and effectiveness of your screen protector, follow these maintenance guidelines:

- **Cleaning:** Use the provided microfiber cleaning cloth to gently wipe the screen protector. For more thorough cleaning, slightly dampen the cloth with water or a mild, non-abrasive screen cleaner. Avoid harsh chemicals or abrasive materials.

- **Avoid Sharp Objects:** While the protector offers scratch resistance, avoid contact with sharp objects that could damage the film.
- **Reusability:** The ClearTouch screen protector is designed to be reusable. If removal is necessary, carefully peel it off. To reapply, ensure both the screen and the protector's adhesive side are clean and free of dust.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Air bubbles after installation	Dust particles trapped underneath; uneven application.	Gently push bubbles towards the edge with the applicator card. For persistent bubbles, carefully lift the nearest edge of the protector, remove dust with a sticker, and reapply. Small bubbles may dissipate over 24-48 hours.
Screen protector not adhering properly	Screen not clean; protector misaligned; adhesive compromised.	Ensure the screen is thoroughly cleaned before application. Realign the protector carefully. If the adhesive is compromised, use the second protector provided.
Reduced touch sensitivity	Air gaps between protector and screen; improper installation.	Ensure the protector is applied smoothly and firmly. Re-smooth any areas with air gaps. If issues persist, consider reapplying with the second protector.
Fingerprints or smudges visible	Normal use; excessive oil/dirt.	Wipe gently with the microfiber cleaning cloth. The anti-fingerprint coating reduces, but does not entirely eliminate, smudges.

7. PRODUCT SPECIFICATIONS

- **Product Name:** BoxWave ClearTouch Anti-Glare Screen Protector
- **Compatibility:** Tranya ES10 Smartwatch
- **Material:** Polyethylene Terephthalate (PET)
- **Surface Finish:** Matte, Anti-Glare, Anti-Fingerprint
- **Features:** Reduces 90% UV rays, Glueless adhesive, Precision-cut, Reusable
- **Package Quantity:** 2 Screen Protectors

8. WARRANTY AND SUPPORT

BoxWave products are designed for quality and performance. For warranty information or technical support, please refer to the contact details provided on the product packaging or visit the official BoxWave website. Please retain your proof of purchase for warranty claims.

For further assistance, you may contact BoxWave customer support directly.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0DXRKQ7B9>

More documents and user manuals: <https://manuals.plus/>