

BLU K30

BLU Bold K30 Smartphone User Manual

Model: K0150WW

1. INTRODUCTION

Welcome to the BLU Bold K30 user manual. This guide provides essential information to help you set up, operate, maintain, and troubleshoot your new smartphone. Please read this manual thoroughly to ensure optimal performance and longevity of your device.

2. WHAT'S IN THE BOX

Upon opening your BLU Bold K30 package, you should find the following items:

- BLU Bold K30 Smartphone
- Rugged Case
- Charger (22.5W Fast Charging compatible)
- Quick Guide
- Sticker
- Type C Cable
- SIM Key



Image: The BLU Bold K30 retail box contents, including the smartphone, rugged case, charger, Type-C cable, quick guide, sticker, and SIM key.

3. PRODUCT OVERVIEW

3.1 Design and Display

The BLU Bold K30 features an elegant design crafted with premium materials. Its 6.7-inch HD+ Infinity Dot Display offers a captivating edge-to-edge view with 16 million colors and a smooth 120Hz refresh rate for an immersive visual experience. A convenient side-mounted fingerprint scanner is integrated for secure and quick access.






Image: Front and back view of the BLU Bold K30 smartphone in purple, highlighting its sleek design and camera module.

Image: The BLU Bold K30's 6.7-inch HD+ Infinity Dot Display showcasing vibrant colors with a fruit image.

3.2 Performance and Storage

Powered by a 2.0GHz Octa-Core Processor and 6GB of RAM, the K30 is designed for efficient multitasking. It comes with a massive 256GB of internal storage, providing ample space for your apps, photos, and videos without the need for frequent deletion.




Image: The BLU Bold K30 screen showing various applications open, demonstrating its multitasking capabilities.

3.3 Camera System

Capture life's moments with precision using the K30's advanced camera system. It features a remarkable triple 108MP main camera for stunning clarity and a 13MP selfie camera for high-quality self-portraits.



Image: The back of a green BLU Bold K30 smartphone, emphasizing the triple 108MP camera setup.

3.4 All-Day Battery

The Bold K30 is equipped with a long-lasting 5,000mAh battery, ensuring you stay powered throughout the day and into the night. When a recharge is needed, the 22.5W Fast Charging technology quickly gets your device back to 100%.

3.5 Connectivity

This device is GSM unlocked, offering flexibility to switch between compatible carriers such as T-Mobile and Metro PCS. Please note that a SIM card is not included, and for network compatibility, it is recommended to consult your service provider. This device is not compatible with AT&T/Cricket new activations or CDMA networks like Verizon.

4. SETUP

4.1 Inserting the SIM Card

1. Locate the SIM card tray on the side of your BLU Bold K30.
2. Insert the provided SIM key into the small hole next to the tray to eject it.
3. Place your Nano-SIM card(s) into the tray with the gold contacts facing down.
4. Carefully reinsert the tray into the phone.

4.2 Powering On/Off

- To power on: Press and hold the Power button (located on the side) until the BLU logo appears.
- To power off: Press and hold the Power button, then select 'Power off' from the options on the screen.

4.3 Initial Configuration

Follow the on-screen prompts to complete the initial setup of your device. This includes selecting your language,

connecting to Wi-Fi, setting up your Google account, and configuring security features like the fingerprint scanner.

5. OPERATING YOUR DEVICE

5.1 Display Navigation

Navigate your device using touch gestures on the 6.7-inch HD+ Infinity Dot Display. The 120Hz refresh rate ensures smooth scrolling and responsiveness.

5.2 Fingerprint Sensor

The side-mounted fingerprint sensor allows for quick and secure unlocking of your device. To set up, go to **Settings > Security > Fingerprint** and follow the instructions.



Image: A hand holding the BLU Bold K30, with an overlay illustrating the location and function of the side-mounted fingerprint sensor.

5.3 Camera Usage

Open the Camera app to utilize the triple 108MP main camera or the 13MP selfie camera. Tap the screen to focus and press the shutter button to capture photos or videos. Explore various modes and settings for enhanced photography.

5.4 Charging Your Device

Connect the Type C cable to your phone and the 22.5W Fast Charging adapter to a power outlet. The device supports rapid charging to minimize downtime.

5.5 Network and Connectivity

Your BLU Bold K30 supports 4G LTE connectivity. Ensure your SIM card is properly inserted and activated with a compatible GSM carrier for mobile data and calls.

6. MAINTENANCE

6.1 Battery Care

- Avoid extreme temperatures, as they can degrade battery performance.
- For optimal battery health, try to keep the charge level between 20% and 80%.
- Use only the provided charger and cable for safe and efficient charging.

6.2 Cleaning Your Device

Use a soft, lint-free cloth to clean your phone. Avoid abrasive materials or harsh chemicals that could damage the screen or finish. For stubborn smudges, slightly dampen the cloth with water.

6.3 Software Updates

Regularly check for and install software updates to ensure your device has the latest security patches, features, and performance improvements. Go to **Settings > System > System update** to check for updates.



Image: The Android 14 logo, indicating the operating system version of the BLU Bold K30.

7. TROUBLESHOOTING

7.1 Network Connectivity Issues

- Ensure your SIM card is correctly inserted and activated.
- Verify that your carrier is a compatible GSM network (e.g., T-Mobile, Metro PCS). The device is not compatible with AT&T/Cricket new activations or CDMA networks like Verizon.
- Restart your device.

7.2 Device Performance Lag

- Close unnecessary background applications.
- Clear the cache of frequently used apps.
- Ensure sufficient storage space is available.

7.3 Camera Focus Problems

- Ensure adequate lighting conditions.
- Keep your hand steady while taking photos.
- Clean the camera lens with a soft cloth.

7.4 Charging Issues

- Check if the charging cable and adapter are securely connected.
 - Ensure the charger and cable are not damaged.
 - Try using a different compatible charger and cable.
-

8. SPECIFICATIONS

Below are the detailed technical specifications for the BLU Bold K30 smartphone:

Feature	Detail
Model Name	K30
Item Model Number	K0150WW
Display Size	6.7 Inches
Display Resolution	1920 x 1080 (HD+)
Refresh Rate	120Hz
Operating System	Android 14
CPU Speed	2.0 GHz Octa-Core
RAM Memory Installed Size	6 GB
Memory Storage Capacity	256 GB
Main Camera	Triple 108MP
Selfie Camera	13MP
Battery Capacity	5000 Milliamp Hours
Charging	22.5W Fast Charging
Connectivity Technologies	4G
Wireless Carrier	Unlocked (GSM)
Item Weight	1 pounds
Package Dimensions	7.4 x 3.9 x 1.9 inches

Key Selling Points

-  6.7" HD+ 90Hz Infinity Dot Display
720 x 1600 Resolution | 262ppi
-  Triple 108MP Main with Flash
13MP Selfie Camera
-  256GB Internal Storage
6GB RAM
MicroSD for Expandable Storage
-  Unisoc T7255 | 12nm
ARM Cortex A75
2.0GHz Octa-Core
-  5,000mAh Super Battery
22.5W Quick Charge
-  Side-Mounted
Fingerprint Sensor
-  Premium Finish Battery
Cover Design



Image: A graphic displaying key selling points and specifications of the BLU Bold K30, including display, camera, storage, RAM, processor, battery, and fingerprint sensor.

9. WARRANTY AND SUPPORT

9.1 US Warranty

The BLU Bold K30 comes with a US Warranty. For specific terms and conditions of your warranty, please refer to the warranty card included in your product packaging or visit the official BLU website.

9.2 Protection Plans

Additional protection plans may be available for your device, such as 2-Year Protection Plans or Complete Protect plans. These plans offer extended coverage beyond the standard manufacturer's warranty.

9.3 Customer Support

For further assistance, technical support, or service inquiries, please visit the official BLU website or contact their customer service department. You can find contact information in your Quick Guide or on the BLU website.