

WLIVE ASNG126DK2

WLIVE ASNG126DK2 TV Stand User Manual

Model: ASNG126DK2 | Brand: WLIVE

1. INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your WLIVE ASNG126DK2 TV Stand. This entertainment center is designed to accommodate TVs up to 65 inches and features integrated LED lighting, a built-in charging station, and multiple fabric storage drawers. Please read this manual thoroughly before beginning assembly or operation to ensure safe and correct usage.

2. SAFETY INFORMATION

- **Anti-Tilt Device:** For safety, always install the included anti-tilt device to secure the TV stand to the wall. This prevents accidental tipping, especially important in households with children or pets.
- **Electrical Safety:** The built-in power outlet is UL/ETL certified. Do not overload the outlets. Ensure the power cord is not pinched or damaged during assembly or placement.
- **Weight Capacity:** The media stand is designed to bear up to 150 lbs (68 kg). Do not exceed this weight limit to maintain stability and prevent damage.
- **Assembly:** Follow all assembly steps carefully. Do not skip steps or use unauthorized parts. Two people are recommended for assembly.

3. PACKAGE CONTENTS

Before assembly, verify that all components listed below are present and undamaged. If any parts are missing or damaged, contact customer support.

Component	Quantity	Description
Metal Steel Frame	1 set	Main structural support.
Wood Top Panel	1	Top surface for TV and display items.

Component	Quantity	Description
Fabric Drawers	9	Detachable storage drawers.
LED Light Strip	1	Integrated lighting system.
Power Outlet Unit	1	Includes 2 AC sockets and 2 USB ports.
Assembly Hardware	1 set	Screws, bolts, and tools for assembly.
Anti-Tilt Device	1 set	Wall anchoring hardware.
Adjustable Feet	6	For leveling and floor protection.
Instruction Manual	1	This document.

4. ASSEMBLY INSTRUCTIONS

Assembly is estimated to take approximately one hour. All necessary tools and hardware are included. Follow the detailed assembly guide provided in the package. Ensure all parts are correctly oriented before tightening screws.

- Unpack and Identify:** Carefully unpack all components and lay them out. Refer to the parts list to identify each piece.
- Assemble Frame:** Begin by assembling the metal steel frame according to the diagrams in the separate assembly guide. Ensure cross support rods are securely attached for stability.
- Attach Wood Top:** Secure the P2 grade artificial wood top panel to the assembled frame.
- Install Power Outlet:** Integrate the power outlet unit into its designated slot on the top panel. Route the power cord as instructed.
- Install LED Lights:** Adhere the LED light strip to the specified areas. Connect the light strip to its controller and power source.
- Insert Drawers:** Assemble the fabric drawers and insert them into the designated slots. The drawers feature a 3-tier structure for durability.
- Adjust Feet:** Install and adjust the 6 all-directional adjustable feet to level the stand on uneven surfaces and protect your floor.
- Secure Anti-Tilt Device:** Attach the anti-tilt device to the back of the TV stand and secure it to a wall stud using appropriate hardware. This step is crucial for safety.

STURDY STEEL FRAME



Anti-Tilt Device



Solid Drawer Slides



Adjustable feet

Figure 1: Structural components including the sturdy steel frame, anti-tilt device, solid drawer slides, and adjustable feet.



Figure 2: Proper installation of the anti-tilt device to prevent tipping.

5. OPERATING INSTRUCTIONS

5.1. LED Lighting System

The integrated LED lighting system offers 60,000 color rhythm options and various modes to enhance your environment.

- **Control Methods:** The LED lights can be controlled via a remote control (if included) or through a dedicated smartphone application.
- **App Control:** Download the free application to access full features, including adjusting light intensity, speed, and color. The app also supports music synchronization for dynamic lighting effects.
- **Modes:** Explore various modes such as Mic Mode, Music Mode, and Timing Mode for personalized lighting experiences.



Figure 3: Overview of LED light control options and available modes.

5.2. Built-in Charging Station

The TV stand includes a convenient charging station to power your electronic devices.

- **AC Outlets:** Two (2) 125V/12A AC sockets are available for standard power plugs.
- **USB Ports:** Two (2) 5V/2A USB ports are provided for charging smartphones, tablets, and other USB-powered

devices.

- **Power Cord:** The unit features a 5-foot flexible power cord. Ensure it is plugged into a grounded wall outlet.

Built-in Charging Station



2 AC Outlets
125V/12A



2 USB Ports
5V/2A



Power Cord
5-Ft

Figure 4: Details of the integrated power outlet and USB charging ports.

6. MAINTENANCE

- **Cleaning:** Use a soft, damp cloth to wipe down the wood top and metal frame. Avoid harsh chemicals or abrasive cleaners. The fabric drawers can be spot cleaned with a mild detergent and air-dried.
- **Drawer Care:** The fabric drawers are detachable. If they become soiled, remove them and clean as needed. Ensure they are completely dry before reinserting.
- **Structural Check:** Periodically check all screws and connections to ensure they remain tight. Re-tighten if necessary.
- **Anti-Tilt Device:** Regularly inspect the anti-tilt device to ensure it is still securely fastened to both the stand and the wall.



Figure 5: Illustration of the durable drawer construction and easy-to-clean surface.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
LED lights not working.	Loose connection, power issue, app malfunction.	Check all power connections. Ensure the power outlet is functioning. Restart the control app or try the remote control.
Charging station not providing power.	Power cord unplugged, device not compatible, outlet overloaded.	Verify the main power cord is securely plugged into a live outlet. Test with a different device. Ensure total power draw does not exceed limits.
Stand feels unstable.	Uneven floor, loose connections, anti-tilt device not installed.	Adjust the leveling feet. Re-tighten all assembly screws. Ensure the anti-tilt device is properly installed and secured to the wall.

Problem	Possible Cause	Solution
Drawers do not slide smoothly.	Obstruction, misaligned, damaged slide.	Check for any items obstructing the drawer path. Ensure drawers are inserted correctly. Inspect drawer slides for damage.

8. SPECIFICATIONS

Model Name	ASNG126DK2
Brand	WLIVE
Dimensions (L x W x H)	59.06" x 11.73" x 32.87" (150cm x 29.8cm x 83.5cm)
Item Weight	29.5 lbs (13.4 kg)
Material	Metal Steel Frame, P2 Grade Artificial Wood Top, Non-Woven Fabric Drawers
Color	Charcoal Black Wood Grain Print
Max. Weight Capacity	150 lbs (68 kg)
AC Outlets	2 (125V/12A)
USB Ports	2 (5V/2A)
Power Cord Length	5 ft (1.5 m)
LED Light Features	60,000+ RGB Colors, App/Remote Control, Music Sync, Timing Mode

PRODUCT SIZE



Figure 6: Detailed product dimensions and individual drawer capacities.

9. WARRANTY AND SUPPORT

WLIVE is committed to providing quality products and customer satisfaction. If you encounter any issues with your TV stand, or if you have questions regarding assembly, operation, or missing parts, please contact our professional after-sales support team. Refer to your purchase documentation for specific warranty details and contact information. For guidance on the LED light application or any other inquiries, our support team is available to assist you.