

[Manuals.plus](#) /

> [WLIVE](#) /

> WLIVE White TV Stand ASNG126WXF User Manual

WLIVE ASNG126WXF

WLIVE White TV Stand ASNG126WXF User Manual

Model: ASNG126WXF

Brand: WLIVE

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your WLIVE White TV Stand. Please read this manual thoroughly before assembly and use to ensure proper function and safety. Keep this manual for future reference.

SAFETY INFORMATION

- Keep all small parts and packaging materials away from children.
- Ensure all connections are secure before use.
- Do not exceed the maximum weight capacity of the stand (150 lbs for the top surface).
- Use the included anti-tilt device to secure the stand to a wall, preventing accidental tipping.
- The built-in power outlet and USB ports are UL/ETL certified. Do not overload the power strip.
- Avoid placing liquids directly on the wood top to prevent damage.
- If any parts are missing or damaged, contact customer support immediately.



The anti-tilt device is crucial for securing the TV stand to the wall, preventing it from tipping over and ensuring safety, especially in households with children or pets.

PACKAGE CONTENTS

Verify that all components are present before beginning assembly. If any parts are missing or damaged, please contact customer support.

- Metal Steel Frame components
- Wood Top Panel
- Fabric Drawers (15 units)
- LED Light Strip with remote/app control
- Built-in Power Strip (2 AC outlets, 2 USB ports)
- Assembly Hardware (screws, bolts, etc.)
- Anti-tilt Device
- Adjustable Feet (6 units)
- Assembly Manual




The complete WLIVE White TV Stand, showcasing its design with multiple fabric drawers, open shelves, and integrated LED lighting.

ASSEMBLY INSTRUCTIONS

Follow these steps carefully for proper assembly. It is recommended to have two people for assembly.

1. **Unpack and Identify Parts:** Carefully remove all components from the packaging. Lay them out on a clean, soft surface to prevent scratches. Refer to the parts list in the included assembly guide to identify each piece.
2. **Assemble the Frame:** Connect the metal steel frame components according to the diagrams in the assembly guide. Ensure all screws are tightened securely but do not overtighten.
3. **Attach Wood Top:** Secure the wood top panel to the assembled frame using the provided hardware.
4. **Install Shelves:** Place the adjustable shelves into their desired positions within the open compartments.
5. **Insert Fabric Drawers:** Unfold the fabric drawers and insert the bottom panels. Place the assembled drawers into their respective slots.
6. **Install LED Lights:** Adhere the LED light strip to the designated areas. Connect the power cable for the LED lights.

7. **Connect Power Strip:** Ensure the built-in power strip is correctly integrated and its power cord is accessible.
8. **Attach Anti-Tilt Device:** Secure the anti-tilt device to the back of the TV stand and then to a wall stud using appropriate hardware. This step is critical for safety.
9. **Adjust Feet:** Adjust the 6 adjustable feet at the bottom of the stand to ensure stability and level positioning on uneven floors.



The robust metal steel frame provides structural integrity. Note the cross support rods for enhanced stability and the designated area for the anti-tilt device.

OPERATING INSTRUCTIONS

LED Lights

The integrated LED lights offer multiple color and mode options.

- **Power On/Off:** Use the included remote control or the dedicated mobile application to turn the LED lights on or off.
- **Color Selection:** Choose from over 60,000 RGB colors via the remote or app.

- **Brightness and Speed:** Adjust the light intensity and speed of dynamic modes using the controls.
- **Modes:** Explore various modes including music synchronization, mic mode, and timing mode for personalized ambiance.
- **App Control:** Download the free mobile application (refer to the assembly guide for app details) for advanced control features.

★ Shelves + Drawers Adjustable ★



The LED lighting system can be controlled via a physical key remote or a smartphone application, offering a wide spectrum of colors and dynamic modes like music sync.

Charging Station

The built-in charging station provides convenient power access.

- **AC Outlets:** Two 125V/12A AC outlets are available for standard electronic devices.
- **USB Ports:** Two 5V/2A USB ports are provided for charging mobile devices.
- **Power Cord:** The 5-foot power cord allows flexible placement.
- **Safety:** The charging station is UL/ETL certified. Do not exceed the maximum electrical load.



The integrated power strip features two standard AC outlets and two USB ports, providing convenient charging for various electronic devices directly from the TV stand.

MAINTENANCE AND CARE

- **Cleaning:** Wipe the wood top and metal frame with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Fabric Drawers:** The fabric drawers are made of breathable non-woven fabric. Spot clean with a mild detergent and allow to air dry. Do not machine wash.
- **Spills:** Promptly wipe up any spills on the wood top to prevent staining or damage.
- **Inspection:** Periodically check all screws and connections to ensure they remain tight. Re-tighten if necessary.
- **Anti-Tilt Device:** Regularly inspect the anti-tilt device to ensure it is securely attached to both the stand and the wall.



The P2 grade artificial wood top is scratch-resistant and easy to clean. Promptly wipe spills with a soft cloth to maintain its appearance.

TROUBLESHOOTING

LED Lights Not Working

- **Check Power:** Ensure the LED light strip is properly connected to a power source and the power outlet is functional.
- **Remote/App Battery:** Replace batteries in the remote control if applicable. Ensure the mobile app is correctly paired and updated.
- **Connections:** Verify all connections of the LED strip are secure.

Charging Station Not Providing Power

- **Main Power:** Confirm the TV stand's main power cord is securely plugged into a functional wall outlet.
- **Device Compatibility:** Ensure your devices are compatible with the provided AC (125V/12A) and USB (5V/2A) specifications.
- **Overload:** Disconnect some devices to check if the power strip is overloaded.

Stand is Unstable

- **Adjust Feet:** Adjust the 6 adjustable feet at the bottom to level the stand on uneven surfaces.
- **Tighten Screws:** Re-tighten all assembly screws and bolts.
- **Anti-Tilt Device:** Ensure the anti-tilt device is correctly installed and securely fastened to a wall stud.

Drawers Do Not Slide Smoothly



- **Check Alignment:** Ensure the fabric drawers are correctly inserted into their slots and not obstructed.
- **Overloading:** Avoid overloading drawers beyond their capacity.
- **Obstructions:** Check for any foreign objects obstructing the drawer slides.

SPECIFICATIONS

Feature	Detail
Brand	WLIVE
Model	ASNG126WXF

Feature	Detail
Dimensions (D x W x H)	11.73" x 59.06" x 32.87"
Weight	29.5 Pounds
Material	Metal Steel Frame, P2 Grade Artificial Wood Top, Non-Woven Fabric Drawers
Color	White
Drawers	15 Fabric Drawers
Power Outlets	2 AC Outlets (125V/12A)
USB Ports	2 USB Ports (5V/2A)
Power Cord Length	5 feet
LED Lights	RGB, Key/App Control, Music Sync, Mic Mode, Timing Mode
Weight Capacity (Top)	150 lbs

PRODUCT SIZE



This diagram provides a visual representation of the TV stand's overall dimensions and the individual sizes of its various drawers and compartments.

WARRANTY AND SUPPORT

For any questions, missing parts, or issues not covered in this manual, please contact WLIVE customer support.

Refer to your purchase documentation for specific warranty details.

[Visit the WLIVE Store on Amazon](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0DXTH9D6Y>

More documents and user manuals: <https://manuals.plus/>