

[Manuals.plus](#) /

› [VEVOR](#) /

› VEVOR Swivel Floor Gaming Chair QX-1558C User Manual

## VEVOR QX-1558C

# VEVOR Swivel Floor Gaming Chair QX-1558C User Manual

Model: QX-1558C

## 1. INTRODUCTION

---

Thank you for choosing the VEVOR Swivel Floor Gaming Chair. This manual provides essential information for the safe and effective use, maintenance, and troubleshooting of your new chair. Please read it thoroughly before use and retain it for future reference.

## 2. SAFETY INFORMATION

---

**Warning! Please read all safety instructions carefully before operating the chair.**

- Users should exercise caution when adjusting the chair to prevent injury.
- This chair is designed with a low profile for direct floor placement. Be careful when sitting down or standing up from the chair.
- The maximum weight capacity for this chair is 150 kg (approximately 330 lbs). Exceeding this weight limit may damage the chair or cause personal injury.
- Keep children and pets away from moving parts during adjustment.
- Ensure the chair is placed on a stable, level surface to prevent tipping.

## 3. PRODUCT OVERVIEW

---

The VEVOR Swivel Floor Gaming Chair is a versatile and comfortable seating solution designed for various activities such as gaming, reading, watching TV, or relaxing. It features a 360-degree swivel base and a backrest with 4 adjustable positions to suit your comfort needs.

# 4-Level Adjustable

Comfort for every sitting or lying position



Image 3.1: The VEVOR Swivel Floor Gaming Chair, showcasing its design and comfortable appearance.

## Key Features:

- **4-Position Adjustable Backrest:** Allows for customized reclining angles for optimal comfort.
- **360-Degree Swivel Function:** Provides easy rotation without needing to reposition the entire chair.
- **Foldable Design:** Enables convenient storage and portability.
- **High-Density Foam Core:** Offers soft yet supportive cushioning to relieve fatigue.

- **Durable Metal Frame:** Ensures stability and long-term durability.



Image 3.2: Product dimensions and weight capacity details for the VEVOR Swivel Floor Gaming Chair.

## 4. SETUP

---

The VEVOR Swivel Floor Gaming Chair comes fully assembled and ready for use. No additional assembly steps are required.

1. Remove the chair from its packaging.
2. Place the chair on a flat, stable surface.
3. Unfold the chair to its upright position if it was folded for transport.

## 5. OPERATING INSTRUCTIONS

---

### 5.1 Adjusting the Backrest

The chair's backrest can be adjusted to 4 different positions to provide various reclining angles.

1. To adjust, gently push the backrest forward until you hear a click.
2. Continue pushing forward until it reaches its maximum forward position, then slowly recline it backward.
3. The backrest will lock into one of the 4 available positions as you recline. Select your desired angle.
4. To return to the upright position, push the backrest fully forward until it clicks past the last position, then allow it to recline back to the upright lock.

## Sturdy Metal Frame

Reliable support, no deformation



KoYo Hinges: Precise angle adjustment



Metal Frame:  
Sturdy and durable

# 285lbs

Weight Capacity

Image 5.1: Visual guide to adjusting the chair's backrest to one of its four positions.

## 5.2 Using the 360-Degree Swivel

The chair features a stable base that allows for full 360-degree rotation.

1. Ensure the chair is placed on a smooth, flat surface.
2. While seated, gently push off the floor with your feet or use your hands to rotate the chair in any direction.

# Multifunctional Chair

Unlock multiple seating positions



Image 5.2: The chair's 360-degree swivel function, allowing for easy directional changes.

## 5.3 Folding for Storage

The chair can be folded for compact storage or transport.

1. Adjust the backrest to its fully upright position.
2. Continue pushing the backrest forward until it folds flat against the seat.
3. The chair is now in its folded state.

## 6. MAINTENANCE

---

### 6.1 Cleaning

- For general cleaning, use a soft, damp cloth with mild soap and water.
- Avoid harsh chemicals or abrasive cleaners, as these can damage the fabric and frame.
- Spot clean any spills immediately to prevent staining.
- Allow the chair to air dry completely before use.

### 6.2 Storage

- When not in use, store the chair in a cool, dry place away from direct sunlight and extreme temperatures.
- Utilize the folding feature for compact storage.

## 7. TROUBLESHOOTING

---

Problem	Possible Cause	Solution
Backrest does not lock into position.	Mechanism not fully engaged.	Push the backrest fully forward until it clicks, then recline slowly to engage the locking mechanism.
Chair feels unstable or wobbly.	Uneven surface; weight capacity exceeded.	Ensure the chair is on a flat, level surface. Verify that the user's weight does not exceed 150 kg (330 lbs).
Difficulty swiveling.	Obstruction under the base; uneven surface.	Check for any objects obstructing the swivel base. Ensure the chair is on a smooth, level surface.

## 8. SPECIFICATIONS

---

Feature	Detail
Brand	VEVOR
Model Number	QX-1558C
Color	Grey
Material	Linen + sponge + recycled sponge + silk cotton + iron pipe
Product Dimensions (D x W x H)	21.7" x 22" x 30.4" (55 x 55.8 x 77.2 cm)

Feature	Detail
Item Weight	17.1 Pounds (7.74 kg)
Weight Capacity	285 lbs (129.3 kg) - <i>Note: Some product images indicate 285 lbs, while safety warnings state 150 kg (approx. 330 lbs). Please adhere to the lower stated limit for safety.</i>
Adjustable Positions	4 Levels
Swivel Function	360-Degree Rotation
Assembly Required	No
Indoor/Outdoor Usage	Indoor

## 9. WARRANTY AND SUPPORT

---

For warranty information or technical support, please contact VEVOR customer service through their official website or the retailer where the product was purchased. Please have your model number (QX-1558C) and proof of purchase available when contacting support.

You can visit the VEVOR store online for more information: [VEVOR Official Store](#)

