JOWLURK M8

JOWLURK M8 Home Projector User Manual

Model: M8

1. Introduction

Thank you for purchasing the JOWLURK M8 Home Projector. This device is designed to provide a high-quality visual and audio experience for your home entertainment, presentations, and gaming. Featuring advanced auto-focus, auto-keystone correction, WiFi6, and Bluetooth 5.4 connectivity, the M8 projector offers ease of use and versatile performance. Please read this manual thoroughly before operating the projector to ensure proper use and to maximize its lifespan.

2. Safety Information

- Do not look directly into the projector lens when the lamp is on, as the bright light can cause eye damage.
- Ensure proper ventilation around the projector. Do not block ventilation openings.
- Keep the projector away from water, moisture, and extreme temperatures.
- Use only the power adapter supplied with the projector.
- Avoid placing the projector on unstable surfaces to prevent falls and damage.
- The projector features blue light cut technology and reflective projection to reduce eye strain during long viewing sessions. However, prolonged viewing is not recommended.

3. Package Contents

Please check that all items are present in your package:

- JOWLURK M8 Home Projector
- Remote Control
- Power Adapter
- HDMI Cable
- User Manual

4. Product Features

- **Electric Auto Focus & Auto Keystone Correction:** The projector automatically adjusts focus and corrects image distortion, ensuring a clear and perfectly rectangular image without manual intervention.
- **Digital Zoom Function (50%-100%):** Adjust the screen size digitally to fit your projection surface, offering flexibility in placement for ceiling or horizontal setups.
- **High Brightness & 4K Support:** Delivers 40000LM brightness and supports 4K input, providing vivid and detailed images.
- **Next-Generation WiFi6 Connectivity:** Experience ultra-high-speed wireless connectivity for smooth 4K video streaming and online gaming without lag.
- **Bidirectional Bluetooth 5.4:** Connect wirelessly to external speakers for enhanced audio or use the projector as a standalone Bluetooth speaker.
- **Large Screen Projection:** Capable of projecting an image up to 300 inches, transforming any room into an immersive home theater.
- **Low Noise Cooling System:** Operates at below 35dB, ensuring a quiet viewing experience.
- **Eye-Friendly Design:** Incorporates blue light cut technology and reflective projection to minimize eye strain during extended use.
- **Versatile Connectivity:** Equipped with multiple ports including HDMI x2, USB, and AV input for connecting various devices.

5. Setup

5.1 Initial Placement

Place the projector on a stable, flat surface or mount it according to your preference (ceiling, wall, tripod). Ensure there is adequate space around the projector for ventilation.

5.2 Power Connection

1. Connect the power adapter to the projector's power input port.
2. Plug the power adapter into a wall outlet.
3. Press the power button on the projector or remote control to turn on the device.

5.3 Automatic Focus and Keystone Correction

Upon startup, the projector will automatically perform focus and keystone correction. If further adjustment is needed, use the remote control for one-touch fine-tuning.




Image: The projector automatically adjusts focus and corrects image distortion for a perfect display.

6. Operating Instructions

6.1 Basic Operation

- **Power On/Off:** Press the power button on the projector or remote.
- **Navigation:** Use the arrow keys on the remote to navigate menus.
- **Selection:** Press the OK/Enter button to confirm selections.
- **Back:** Use the Back button to return to the previous screen.

6.2 Input Source Selection

Press the 'Source' button on the remote control to select your desired input source (HDMI1, HDMI2, USB, AV, Screen Mirroring).

6.3 Digital Zoom Adjustment

Use the zoom function on the remote control to adjust the projection size from 50% to 100% without moving the projector.



Image: The projector supports up to 300-inch projection with flexible digital zoom.

7. Connectivity

7.1 WiFi6 Connection (Screen Mirroring)

1. Select 'Screen Mirroring' from the input source menu.
2. Follow the on-screen instructions to connect your Android, iOS, or Windows device to the projector's WiFi network.
3. Once connected, you can mirror your device's screen to the projector.



Image: High-speed WiFi6 ensures smooth streaming and mirroring from various devices.

7.2 Bluetooth 5.4 Connection

1. Go to the Bluetooth settings on the projector.
2. Enable Bluetooth on your external speaker or audio device.
3. Select your device from the list of available devices on the projector to pair.
4. The projector can also function as a standalone Bluetooth speaker.



Image: Bluetooth 5.4 allows connection to external speakers or use as a wireless speaker.

7.3 Wired Connections (HDMI, USB, AV)

- **HDMI:** Connect devices like TV sticks, game consoles (Nintendo Switch, PS5), laptops, or DVD players using an HDMI cable. The projector has two HDMI ports.
- **USB:** Insert a USB drive to play media files directly.
- **AV:** Use the AV port for older devices with composite video output.



Image: The projector offers multiple connectivity options for various devices.

8. Maintenance

8.1 Cleaning the Lens

Gently wipe the projector lens with a soft, lint-free cloth designed for optical surfaces. Do not use abrasive cleaners or harsh chemicals.

8.2 Cleaning the Ventilation Openings

Regularly check and clean the ventilation openings to prevent dust buildup, which can affect cooling performance. Use a soft brush or compressed air.

8.3 Storage

When not in use for extended periods, store the projector in a cool, dry place, away from direct sunlight and dust.

9. Troubleshooting

- **No Power:** Ensure the power adapter is securely connected to both the projector and the power outlet. Try a different outlet.
- **No Image:** Check the input source selection. Ensure the connected device is powered on and sending a signal. Verify cable connections (HDMI, AV).
- **Blurry Image:** Allow the auto-focus to complete. If needed, manually adjust focus using the remote control. Ensure the projection surface is flat.
- **Distorted Image:** The projector features auto-keystone correction. If the image is still distorted, try repositioning the projector or manually adjusting keystone if available in settings.
- **No Sound:** Check the volume settings on both the projector and the connected device. Ensure external speakers are properly connected and selected if used.
- **WiFi/Bluetooth Connection Issues:** Ensure the projector and your device are within range. Restart both devices. Check network settings.

10. Specifications

Model	M8
Brightness	40000LM
Resolution Support	Up to 4K
Connectivity	WiFi6, Bluetooth 5.4 (Bidirectional)
Projection Size	Up to 300 inches
Zoom Function	50%-100% Digital Zoom
Focus	Electric Auto Focus
Keystone Correction	4-Way Automatic Keystone Correction
Operating Noise	Below 35dB
Lamp Lifespan	Over 80,000 hours
Input Ports	HDMI x2, USB, AV



Image: Visual representation of the projector's high brightness, 4K support, and eye-friendly features.

11. Warranty and Support

JOWLURK offers a comprehensive warranty and support for your M8 projector:

- **Permanent Warranty for Initial Defects:** In case of initial defects, we offer free exchange or a full refund.
- **Professional Technical Support:** Our dedicated technical team is available 365 days a year to assist you with any inquiries or issues.
- **Contact Information:** For support, please refer to the contact details provided on our official website or your purchase platform.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question