

A520

Generic A520 True Wireless Earbuds Instruction Manual

Model: A520

1. WHAT'S IN THE BOX

Verify that all items are present in your product packaging:

- Generic A520 True Wireless Earbuds
- Wireless Charging Case
- Type-C Fast Charging Cable
- Extra Pair of Eartips



Image: The A520 True Wireless Earbuds shown outside their charging case, alongside the compact charging case.

2. PRODUCT OVERVIEW

The Generic A520 True Wireless Earbuds offer a cable-free audio experience, designed for comfort and performance. They feature Bluetooth 5.0 for stable connectivity, dynamic drivers for enhanced sound, and intuitive touch controls for easy management of music and calls. The earbuds are also IPX7 water-resistant, making them suitable for various activities.

Key Features:

- **True Wireless Freedom:** Enjoy audio without the constraints of cables.
- **High-Definition Sound:** Equipped with dynamic drivers for clear audio and rich bass.
- **Intuitive Touch Controls:** Manage playback, calls, and voice assistant with simple taps.
- **Extended Playtime:** Up to 4 hours of playback per charge, with an additional 5 full charges from the 1200 mAh charging case, totaling 24 hours.
- **Advanced Bluetooth 5.0:** Ensures a stable and efficient wireless connection.
- **IPX7 Water Resistance:** Provides protection against sweat and splashes.
- **ENC Noise Cancelling:** Enhances call clarity by reducing environmental noise.

Listen to songs and calls, leak sound worry-free, do not disturb the people around you

Effectively reduce sound leakage and protect privacy



Image: A close-up view of the A520 earbuds being worn, illustrating their ergonomic design for secure fit and effective sound isolation during use.

Video: An official product video showcasing the key features and contents of the Generic A520 True Wireless Earbuds package.

3. SETUP

3.1 Charging the Earbuds and Case

Before first use, fully charge the earbuds and charging case. The charging case provides multiple charges for the earbuds, extending their usage time significantly.

1. Place the earbuds into their respective slots in the charging case. Ensure they are correctly seated for magnetic connection.
2. Connect the Type-C charging cable to the charging port on the case and plug the other end into a USB power source (e.g., wall adapter, computer USB port).
3. The indicator lights on the case will show the charging status. Once fully charged, the lights will indicate completion or turn off.

A full charge of the case can provide up to 40 full charges for the earbuds, offering approximately 150 hours of extra music playback. Fast charging allows for quick power replenishment.

Mini magnetic suction charging bin

Automatic matching automatic connection Lasting life for you.

150 H
Extra music playing

30 Min
About fast charging time

40 Times
Full Charging



Image: The A520 charging case with earbuds inserted, displaying the digital battery indicator and illustrating the magnetic suction charging feature.

3.2 Pairing with a Bluetooth Device

Follow these steps to pair your A520 earbuds with your smartphone or other Bluetooth-enabled device:

1. Ensure the earbuds are charged and placed in the charging case.
2. Open the charging case. The earbuds will automatically enter pairing mode.
3. On your device, go to Bluetooth settings and turn Bluetooth on.
4. Search for available devices and select "A520" from the list.
5. Once connected, you will hear a confirmation tone, and the earbuds' indicator lights may change.

The earbuds will automatically reconnect to the last paired device when taken out of the case, if Bluetooth is enabled on the device.

4. OPERATING INSTRUCTIONS

4.1 Wearing the Earbuds

For optimal sound quality and comfort, ensure the earbuds are worn correctly:

1. Identify the left (L) and right (R) earbuds.
2. Gently insert each earbud into your ear canal.
3. Adjust the ear hook over your ear for a secure and comfortable fit. You may need to try different sized eartips for the best seal.




Image: A person engaged in exercise, wearing the A520 earbuds, demonstrating their secure fit during physical activity.

4.2 Touch Controls

The A520 earbuds feature intuitive touch controls on the outer surface of each earbud:

Function	Action
Play/Pause Music	Single tap on either earbud
Next Track	Double tap on the Right earbud
Previous Track	Double tap on the Left earbud
Answer/End Call	Single tap on either earbud
Reject Call	Long press on either earbud
Activate Voice Assistant	Triple tap on either earbud
Volume Up	Long press on the Right earbud
Volume Down	Long press on the Left earbud

5. MAINTENANCE

5.1 Cleaning

Regular cleaning helps maintain optimal performance and hygiene:

- Use a soft, dry, lint-free cloth to wipe the earbuds and charging case.
- Do not use abrasive cleaners, solvents, or aerosol sprays.
- Gently clean the charging contacts on both the earbuds and the case with a dry cotton swab if necessary.
- Remove eartips and clean them with mild soap and water, then dry thoroughly before reattaching.

5.2 Storage

When not in use, store the earbuds in their charging case to protect them and keep them charged.

5.3 Water Resistance (IPX7)

The A520 earbuds are IPX7 water-resistant, meaning they can withstand immersion in water up to 1 meter for 30 minutes. This makes them suitable for workouts and light rain. However, they are not designed for swimming or prolonged submersion. Ensure earbuds are dry before placing them back in the charging case to prevent damage.

6. TROUBLESHOOTING

If you encounter issues with your A520 earbuds, try the following solutions:

Problem	Possible Solution
Earbuds not pairing	Ensure earbuds are charged. Turn off and on Bluetooth on your device. Forget "A520" from your device's Bluetooth list and re-pair.
Only one earbud working	Place both earbuds back in the case, close it, then open it again. Ensure both are charged. Re-pair if necessary.
No sound or low volume	Check device volume and earbud volume. Ensure earbuds are properly connected. Clean any debris from the earbud speakers.
Charging case not charging	Check the Type-C cable and USB power source. Ensure the cable is securely connected.
Touch controls unresponsive	Ensure your fingers are clean and dry. Restart the earbuds by placing them in the case and taking them out.

7. SPECIFICATIONS

Brand	Generic
Model Name/Number	A520
Colour	Blue
Ear Placement	In Ear
Form Factor	In Ear
Impedance	32 Ohms
Wireless Technology	Bluetooth 5.0
Playback Time	Up to 4 hours (earbuds), 24 hours total with charging case
Charging Case Capacity	1200 mAh (approx. 5 full charges for earbuds)
Water Resistance	IPX7
Noise Control	Active Noise Cancellation (ENC for calls)
Control Type	Touch Control (Call Control, Volume Control)
Charging Interface	Type-C

8. WARRANTY AND SUPPORT

8.1 Warranty Information

The Generic A520 True Wireless Earbuds come with a **6-month warranty** from the date of purchase. This warranty covers manufacturing defects. Please retain your proof of purchase for

warranty claims.

8.2 Customer Support

For any questions, technical assistance, or warranty claims, please contact the seller or manufacturer directly. Refer to your purchase documentation for contact details.