IRONCK 1062782

IRONCK 70 Inch TV Stand with LED Lights and Power Outlet

Instruction Manual - Model: 1062782

Important Safety Information

Please read and understand all instructions before assembly and use. Keep this manual for future reference.

- Always unplug the power cord before installing or adjusting the TV stand.
- Do not overload the shelves or place heavy objects on the adjustable shelves.
- Keep the power cord out of reach of children and pets.
- Do not operate the LED lights if the TV stand is wet or damp.
- Always follow the assembly instructions carefully to avoid injury.

Product Overview

The IRONCK 70 Inch TV Stand is designed to accommodate televisions up to 75 inches, providing a modern entertainment solution with integrated LED lighting, a power outlet, and ample storage. Its dimensions are 70.1"W x 13.8"D x 24.8"H.



Figure 1: Front view of the IRONCK 70 Inch TV Stand with a television, illuminated LED strip, and visible storage areas.




Figure 2: Dimensional overview of the TV stand, indicating compatibility with various TV sizes.

Setup and Assembly

Assembly of the IRONCK TV Stand is required. It is recommended to have two people for assembly. All necessary hardware and pre-labeled parts are included.

Before You Begin:

- Unpack all components and verify against the parts list provided in the separate assembly guide.
- Ensure you have adequate space for assembly.
- Gather necessary tools (typically a screwdriver, not included).

Assembly Steps:

1. Follow the step-by-step instructions provided in the included assembly manual.
2. Attach the main frame components, ensuring all connections are secure.
3. Install the adjustable center shelf according to your desired height.
4. Mount the cabinet doors, ensuring proper alignment and magnetic closure.
5. Install the LED light strip and connect the power outlet unit.



Figure 3: Detailed measurements of the TV stand's compartments and overall structure.

Operating Instructions

LED Lighting System:

The integrated LED strip offers customizable lighting with 60,000 color options. Control the color and brightness using the dedicated app or the included remote control. A music mode is also available via the app for dynamic lighting effects.



Figure 4: Control options for the LED lighting system, including app and remote control.

Integrated Power Outlet and Charging Ports:

The TV stand features a built-in power strip with 4 AC outlets, 1 USB port, and 1 Type-C port. This allows for convenient charging of smartphones, tablets, and other accessories directly from the stand. The power cord is 4.9 feet long.



Figure 5: Detail of the power outlet and charging ports.

Utilize the hidden cord organization holes to maintain a tidy and clutter-free appearance for your cables.



Figure 6: Cable management hole for organized wiring.

Storage Cabinets and Adjustable Shelf:

The TV stand includes two magnetic-close cabinets (21.7"W x 15.9"H) for concealed storage. The central compartment features an adjustable shelf with three height levels, allowing customization for various media devices or decorative items.



Figure 7: Spacious storage with adjustable shelf in the center.

Maintenance

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the finish.
- **Dusting:** Regularly dust the stand to prevent buildup, especially around electronic components and LED lights.
- **Power Unit:** Ensure the power outlet unit is kept dry. Do not spill liquids on it.
- **LED Lights:** If LED lights dim or malfunction, check connections. Do not attempt to repair the LED strip yourself; contact customer support.

Troubleshooting

- **LED Lights Not Working:**
  - Check if the LED strip is properly connected to the power source.
  - Ensure the power outlet is functioning.
  - Verify the remote control battery or app connection.

- **Power Outlets/USB Ports Not Functioning:**
  - Confirm the main power cord for the stand is securely plugged into a wall outlet.
  - Test the wall outlet with another device.
  - Avoid overloading the power strip with too many high-power devices.
- **Cabinet Doors Not Closing Properly:**
  - Check for any obstructions preventing the door from closing.
  - Ensure the magnetic latches are correctly aligned and secured.

Specifications

Brand	IRONCK
Model Number	1062782
Product Dimensions	70.1"W x 13.8"D x 24.8"H
Material	Engineered Wood
Color	Black
Item Weight	88 Pounds
TV Size Compatibility	Up to 75 inches
Power Outlet	4 AC Outlets, 1 USB Port, 1 Type-C Port
Power Cord Length	4.9 feet
LED Lights	60,000 color options, App/Remote control, Music mode
Assembly Required	Yes

Warranty and Support

For warranty information or technical support, please refer to the documentation included with your purchase or contact IRONCK customer service directly. Contact details can typically be found on the manufacturer's website or your purchase receipt.

For online support, visit the IRONCK Store on Amazon.

© 2025 IRONCK. All rights reserved.