

[Manuals.plus](#) /

› [AKSOUL](#) /

› AKSOUL Sleeping Pad Camping Mat with Built-in Foot Pump - Classic Army Green

AKSOUL Sleeping Pad Green 3.94IN

AKSOUL Sleeping Pad Camping Mat Instruction Manual

Model: Sleeping Pad Green 3.94IN

INTRODUCTION

Thank you for choosing the AKSOUL Sleeping Pad Camping Mat. This ultralight and compact air mattress is designed to provide comfort and convenience for your outdoor adventures, including camping, hiking, and backpacking. It features a built-in foot pump for easy inflation and a connectable design for versatile use.

3.94IN THICKNESS WITH PILLOW

FOR BETTER COMFORT




Image: The AKSOUL Sleeping Pad unfolded, showcasing its design and integrated pillow.

SAFETY INFORMATION

- Keep the sleeping pad away from sharp objects, open flames, and extreme heat sources.
- Do not overinflate the pad.
- This product is not a flotation device and should not be used in water.
- Ensure the inflation and deflation valves are securely closed during use to prevent air leakage.

PACKAGE CONTENTS

Please check the package to ensure all items are present:

- 1 x AKSOUL Sleeping Pad Camping Mat

- 1 x Carry Bag

SETUP

1. Unroll the sleeping pad on a flat, clean surface, free from debris or sharp objects.
2. Locate the inflation valve (typically near the foot end of the pad).



Image: A visual guide showing the four steps for setting up and inflating the sleeping pad.

OPERATING INSTRUCTIONS

Inflation

1. Ensure the bleed valve (deflation valve) is closed.
2. Open the foot pump inflation port.
3. Place your foot on the built-in foot pump and press down repeatedly. The pad will inflate within 30 to 60 seconds.
4. Once fully inflated, close the inflation port immediately to prevent air from escaping.



Image: A person demonstrating the use of the built-in foot pump to inflate the sleeping pad.

Deflation

1. Locate the deflation valve (bleed valve) on the pad.
2. Open the deflation valve to release the air.
3. Roll the pad tightly from the end opposite the valve, pressing out any remaining air.
4. Once all air is expelled, close the deflation valve and secure the rolled pad with its strap or place it directly into the carry bag.

Connecting Multiple Pads

The AKSOUL Sleeping Pad features connection buttons on both sides, allowing you to seamlessly connect

multiple pads to create a larger sleeping area for groups or couples.

1. Align the side edges of two or more sleeping pads.
2. Fasten the connection buttons along the edges to secure the pads together.




Image: A close-up view showing how to connect multiple sleeping pads using the integrated side buttons.

MAINTENANCE

To ensure the longevity of your sleeping pad:

- **Cleaning:** Wipe the surface with a damp cloth and mild soap. Do not use harsh chemicals or abrasive cleaners.

- **Drying:** Allow the pad to air dry completely before storing. Do not expose to direct sunlight for extended periods.
- **Puncture Repair:** In case of a small puncture, use a standard inflatable repair kit (not included) to patch the affected area.



Image: A close-up of the 40D nylon with TPU coating, demonstrating its waterproof and puncture-proof qualities.

STORAGE

Proper storage helps maintain the pad's condition:

- After deflating and cleaning, roll the pad tightly and place it into the provided carry bag.

- Store the pad in a cool, dry place, away from direct sunlight and extreme temperatures.
- Avoid placing heavy objects on top of the stored pad.



Image: The AKSOUL Sleeping Pad in its compact, rolled-up state, highlighting its portability.

EASY TO CARRY & STORE

Weights only 1.79LB



Image: The compact sleeping pad being easily stored inside a backpack, demonstrating its travel-friendly design.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Pad does not inflate or inflates slowly.	Deflation valve is open; inflation port not fully open; foot pump not used correctly.	Ensure deflation valve is closed. Fully open inflation port. Press foot pump firmly and consistently.
Pad loses air quickly.	Inflation/deflation valves not securely closed; small puncture.	Check and securely close all valves. Inspect the pad for punctures and repair if necessary.

Problem	Possible Cause	Solution
Pillow is too firm/soft.	Air pressure in the pillow section.	Slightly open the pillow valve to release some air for a softer feel, or pump more air for firmness.

SPECIFICATIONS

- **Model Name:** Sleeping Pad Green 3.94IN
- **Brand:** AKSOUL
- **Color:** Classic Army Green
- **Material:** 40D Nylon with TPU coating
- **Product Dimensions (L x W x Th):** 78.74" x 27.56" x 3.94"
- **Item Weight:** 1.79 Pounds (approx. 810g)
- **Weight Capacity:** Up to 440 Pounds (200kg)
- **Special Feature:** Ultralight, Built-in Foot Pump, Connectable Design, Integrated Pillow, Waterproof, Puncture-Proof

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation included with your product or contact AKSOUL customer service directly. Keep your purchase receipt for warranty claims.