

[Manuals.plus](#) /

› [ENJOYWOOD](#) /

› ENJOYWOOD 60-Inch Workbench with Wheels and Pegboard Instruction Manual

ENJOYWOOD EN0301-Plus

ENJOYWOOD 60-Inch Workbench with Wheels and Pegboard Instruction Manual

Model: EN0301-Plus

INTRODUCTION

Thank you for choosing the ENJOYWOOD 60-Inch Workbench. This heavy-duty workbench is designed for versatility and durability, featuring a robust rubber wood tabletop, integrated pegboard, convenient drawers, and built-in power outlets. Its adjustable height and mobile design make it suitable for various applications in workshops, garages, offices, or homes. Please read this manual thoroughly before assembly and use to ensure safe and efficient operation.

SAFETY INFORMATION

Always follow basic safety precautions when using this workbench to reduce the risk of injury or damage.

- **Read all instructions:** Ensure you understand all assembly and operating instructions before use.
- **Weight Capacity:** Do not exceed the maximum load capacity of 2000 lbs for the tabletop and 50 lbs per drawer.
- **Stable Surface:** Assemble the workbench on a flat, stable surface.
- **Proper Tools:** Use appropriate tools for assembly as specified in the instructions.
- **Electrical Safety:** When using power outlets, ensure tools are in good working condition and avoid overloading the circuit. Disconnect power when not in use or during maintenance.
- **Children and Pets:** Keep children and pets away from the workbench during assembly and operation.
- **Personal Protective Equipment:** Wear appropriate safety gear, such as gloves and eye protection, during assembly and when working on the bench.
- **Regular Inspection:** Periodically check all bolts and fasteners to ensure they are tight.

PACKAGE CONTENTS

Verify that all components are present before beginning assembly. If any parts are missing or damaged, please contact customer support.

- Heavy-duty Rubberwood Tabletop (60 x 22 inches)
- Steel Leg Frames (H-shaped)

- Integrated Pegboard
- Drawers with slides
- Power Outlet Strip with On/Off Switch
- Adjustable Metal Feet
- Swivel Casters with Brakes
- Assembly Hardware (bolts, nuts, washers, Allen wrench)
- LED Light Strip
- Cord Organizers



Image: All components and hardware included for assembly.

SETUP AND ASSEMBLY

Assembly is required for this workbench. Follow the steps below and refer to the provided diagrams and video for detailed guidance. Pre-drilled holes simplify the process.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches.
2. **Assemble Leg Frames:** Attach the horizontal crossbars to the vertical steel legs to form the H-shaped frames. Ensure all bolts are finger-tight at this stage.
3. **Attach Tabletop:** Secure the rubberwood tabletop to the assembled leg frames using the provided hardware.
4. **Install Drawers:** Assemble the drawer components (back panel, front panel, bottom panel, divider) and attach the drawer slides to the drawer and the workbench frame. Ensure smooth operation.
5. **Mount Pegboard:** Attach the integrated pegboard to the rear of the workbench frame.
6. **Install Power Outlets and LED Light:** Secure the power outlet strip and LED light strip to their designated positions. Route the power cord using the cord organizers.
7. **Choose Feet or Casters:** Decide whether to use the adjustable metal feet for stationary use or the swivel casters for mobility. Attach the chosen option to the bottom of the leg frames.
8. **Final Tightening:** Once all components are in place and aligned, fully tighten all bolts and fasteners.

Assembly Video: Installing the Workbench Drawer

Your browser does not support the video tag.

Video: This video demonstrates the installation process for the workbench drawer, including attaching panels and slides. (Source: TANGERINEE)

Adjustable Workbench Size



Image: Workbench dimensions and adjustable height range.

60" Extra Large Space Desktop

-  Premium Rubber Wood
-  1.2 Inch Thicknesses
-  Safety Varnish



Image: Detail of the adjustable height mechanism.

OPERATING INSTRUCTIONS

Adjusting Height

The workbench height can be adjusted from 28 inches to 40 inches. To adjust, loosen the locking mechanisms on each leg, raise or lower the tabletop to the desired height, and then securely tighten the locking mechanisms. Ensure the workbench is empty or has minimal load during adjustment for safety.

Using Casters and Feet

If using swivel casters, engage the foot brakes when the workbench is in its desired position to prevent unintended movement. If using adjustable metal feet, ensure they are properly leveled to prevent wobbling on uneven surfaces.



Image: Adjustable metal feet and movable swivel casters.

Utilizing Storage Features

- **Drawers:** Use the integrated drawers for organized storage of smaller tools and accessories. Do not overload drawers beyond 50 lbs.
- **Pegboard:** The integrated pegboard and dual-sided pegboards provide convenient access and storage for frequently used tools. Utilize various peg hooks (not included) to customize your setup.
- **LED Light Strip:** Turn on the LED light strip for improved visibility in dimly lit work areas.
- **Power Outlets:** Plug in power tools or other electrical devices into the ETL-certified power outlets. Use the on/off switch to control power to the strip. Utilize the cord organizers to keep cables tidy and prevent tripping hazards.

Multi-storage for Efficient Organization



Side Integrated
Pegboard



Large Integrated
Pegboard



Under-table
Drawer



Image: Multi-storage features including pegboard and drawer.



Stable Metal Feet



Movable Swivel Casters

Image: Detail of the power outlets and switch.



Image: LED light strip providing illumination.

MAINTENANCE

- **Cleaning:** Wipe down the rubberwood tabletop with a damp cloth and mild cleaner. Avoid harsh chemicals that may damage the varnish. Clean steel components with a damp cloth.
- **Hardware Check:** Periodically inspect all bolts, screws, and fasteners to ensure they remain tight. Tighten as necessary to maintain stability.
- **Drawer Slides:** If drawers become stiff, apply a small amount of silicone lubricant to the drawer slides.
- **Tabletop Care:** The rubberwood tabletop has a protective safety varnish. To prolong its life, avoid prolonged exposure to moisture or extreme temperatures.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Workbench is wobbly.	Loose fasteners; uneven floor; adjustable feet not properly set.	Ensure all bolts are tightened. Adjust the metal feet to level the workbench on uneven surfaces. If using casters, ensure brakes are engaged.
Drawer sticks or does not slide smoothly.	Drawer slides misaligned; debris in slides; drawer overloaded.	Check that drawer slides are correctly installed and aligned. Clean any debris from the slides. Do not exceed the 50 lbs weight limit for the drawer. A small amount of silicone lubricant can improve slide action.
Power outlets not working.	Power switch off; power cord not plugged in; circuit breaker tripped.	Ensure the power strip's on/off switch is in the 'on' position. Verify the main power cord is securely plugged into a working wall outlet. Check your household circuit breaker.
Missing parts upon delivery.	Packaging error or transit damage.	Refer to the package contents list. Contact customer support immediately with your purchase details and a list of missing items.

SPECIFICATIONS

Feature	Detail
Model Number	EN0301-Plus
Dimensions (L x W)	60 inches x 22 inches
Adjustable Height Range	28 inches to 40 inches
Tabletop Material	Heavy-duty Rubberwood (30mm thick)
Frame Material	Alloy Steel (1.2mm thick, 2x2 inch legs)
Tabletop Load Capacity	Up to 2000 lbs
Drawer Load Capacity	Up to 50 lbs per drawer
Features	Integrated Pegboard, Drawers, Power Outlets (ETL-certified), LED Light Strip, Cord Organizers, Swivel Casters with Brakes, Adjustable Metal Feet
Color	Wood (tabletop), Black (frame)
Assembly Required	Yes

Rugged Construction for Superior Load Bearing



Image: Workbench load bearing capacities.

WARRANTY AND SUPPORT

ENJOYWOOD products are manufactured to high-quality standards. For warranty information, technical support, or to report missing/damaged parts, please contact ENJOYWOOD customer service through the retailer's platform or the official ENJOYWOOD website. Please have your model number (EN0301-Plus) and purchase date ready when contacting support.

For further assistance, visit the [ENJOYWOOD Store on Amazon](#).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question