Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

HUAWEI HWmate50 4g 8+512g

HUAWEI Mate 50 4G Mobile Phone User Manual

Model: HWmate50 4g 8+512g

Introduction

This manual provides essential information for setting up, operating, maintaining, and troubleshooting your HUAWEI Mate 50 4G Mobile Phone. Please read this guide thoroughly to ensure optimal performance and longevity of your device.



Figure 1: Front and back view of the HUAWEI Mate 50 4G Mobile Phone in purple.

Setup

Unboxing and Initial Inspection

Carefully unpack all components and verify that all items are present and undamaged. The package should include:

- Power Adapter
- USB Cable
- Phone Case
- Screen Protector

SIM Card Installation

Locate the SIM card tray on the side of the phone. Use the provided SIM ejector tool to open the tray. Insert your Nano SIM card(s) into the designated slots. Ensure the SIM card is correctly oriented as indicated on the tray. Gently push the tray back into the phone until it clicks into place.





Figure 2: Side view of the HUAWEI Mate 50, illustrating the location of the SIM card tray and buttons.

Initial Power On and Setup Wizard

Press and hold the power button located on the side of the device until the HUAWEI logo appears. Follow the on-screen instructions to complete the initial setup, including language selection, Wi-Fi connection, and account setup. Note that this device operates on HarmonyOS 3.0 and does not support Google Play Store services.

Operating

Basic Navigation

The HUAWEI Mate 50 features a 6.7-inch OLED display with a resolution of 2700x1224px. Navigate the interface using touch gestures: tap to select, swipe to scroll, pinch to zoom, and long-press for contextual menus. The device runs HarmonyOS 3.0, offering a fluid user experience.



Figure 3: Front view of the HUAWEI Mate 50, showcasing its vibrant OLED display.

Camera Usage

The device is equipped with an advanced camera system:

- **Rear Ultra Light Variable Lens:** 50 million pixels
- **Rear Ultra Wide Angle Lens:** 13 million pixels
- **Rear Periscope Telephoto Lens:** 12 million pixels
- **Front Ultra Wide Angle Camera:** 13 million pixels

Open the Camera app from the home screen. Select different modes (Photo, Video, Portrait, Night, etc.) by swiping across the bottom of the viewfinder. Tap the shutter button to capture images or start/stop video recording.


HUAWEI



Figure 4: Rear view of the HUAWEI Mate 50, highlighting the circular camera module.

Connectivity

The HUAWEI Mate 50 supports various connectivity options:

- **Wi-Fi:** Dual-band WiFi, WiFi6 (802.11 a/b/g/n/ac/ax), 2x2 MIMO, HE160, 4096 QAM, 8 Spatial-stream Sounding MU-MIMO.
- **Bluetooth:** Version 5.2 for connecting wireless accessories.
- **NFC:** Supports Near Field Communication for quick pairing and mobile payments.
- **Infrared:** Built-in infrared function for controlling compatible devices.
- **USB Type-C:** For charging and data transfer.

Charging

The device features a 4460mAh battery. It supports 66W wired fast charging (11V/6A) and 50W wireless charging. Wireless reverse charging is also supported, allowing you to charge other compatible devices using your phone.

Maintenance

Cleaning Your Device

To clean your phone, power it off and disconnect all cables. Use a soft, lint-free cloth slightly dampened with water or a screen cleaner. Avoid using harsh chemicals, abrasive materials, or excessive moisture. The device has an IP68 rating for dust and water resistance, but it is not waterproof.

Software Updates

Regularly check for and install software updates to ensure your device has the latest features, security patches, and performance improvements. Go to **Settings > System & updates > Software update**to check for available updates.

Battery Care

To prolong battery life, avoid extreme temperatures. Do not let the battery drain completely before recharging, and avoid keeping it at 100% charge for extended periods. Use the original charger and cable for optimal charging performance.

Storage Management

The phone comes with 512GB of internal storage, expandable up to 256GB. Regularly clear unnecessary files, cache data, and uninstall unused applications to free up storage space and maintain device performance. You can manage storage in **Settings > Storage**.

Troubleshooting

Common Issues and Solutions

- **Phone not turning on:** Ensure the battery is charged. Connect the phone to the charger for at least 15 minutes, then try powering it on again. If it still doesn't turn on, perform a forced restart by holding the power button for 10-15 seconds.
- **Apps crashing or freezing:** Close the problematic app and reopen it. If the issue persists, clear the app's cache and data in **Settings > Apps > [App Name] > Storage** As a last resort, uninstall and reinstall the app.
- **Poor network signal:** Check if your SIM card is properly inserted. Try restarting the phone. If the issue continues, contact your network provider to verify service in your area.
- **Battery drains quickly:** Reduce screen brightness, disable unnecessary background apps, turn off Wi-Fi/Bluetooth/GPS when not in use, and limit push notifications. Check battery usage in **Settings > Battery** to identify power-hungry apps.
- **Phone overheating:** Avoid using the phone while charging or during intensive tasks like gaming for extended periods. Close background apps. If overheating persists, power off the device and let it cool down.

Specifications

Feature	Detail
CPU Model	Qualcomm Snapdragon 8+ 4G Octa Core (3.2 GHz)
Operating System	HarmonyOS 3.0 (Note: Does not support Google Play Store)
RAM Capacity	8GB
ROM Capacity	512GB
Expansion Capacity	256GB
Screen Size	6.7 inches
Screen Resolution	2700x1224px
Screen Material	OLED
Rear Camera	50MP (Ultra Light Variable) + 13MP (Ultra Wide Angle) + 12MP (Periscope Telephoto)
Front Camera	13MP (Ultra Wide Angle)
Network Type	4G, 3G (Dual SIM Nano SIM)
WLAN Function	Dual band WiFi, WiFi6 (802.11 a/b/g/n/ac/ax)
Bluetooth	5.2
NFC	Supported
Infrared Function	Supported
Battery Capacity	4460mAh
Wired Charging	66W (11V/6A)
Wireless Charging	50W, Wireless Reverse Charging Supported
Water/Dust Resistance	IP68

Dimensions	8.66 x 5.51 x 3.94 inches (Package)
Item Weight	1.54 pounds

Warranty and Support

This HUAWEI Mate 50 4G Mobile Phone is sold as an Amazon Renewed product. For specific warranty details and support related to your renewed device, please refer to the Amazon Renewed program terms and conditions or contact Amazon Renewed customer service directly. For technical support related to the device's functionality, you may also refer to HUAWEI's official support resources.
Always keep your purchase receipt as proof of purchase for any warranty claims.

© 2025 HUAWEI. All rights reserved. Amazon Renewed is a registered trademark.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DY11CBYT

More documents and user manuals: **https://manuals.plus/**