

## RUIGE A6

# RUIGE A6 Automatic Watch User Manual

Model: A6

## INTRODUCTION

---

Thank you for choosing the RUIGE A6 Automatic Watch. This timepiece combines classic design with a reliable mechanical movement, offering both style and functionality. This manual provides essential information to help you set up, operate, and maintain your watch for optimal performance and longevity.



**Figure 1:** The RUIGE A6 Automatic Watch, showcasing its black dial, silver-tone hands and markers, and stainless steel bracelet. The watch features a day and date display at the 3 o'clock position.

## SETUP

### 1. Initial Winding

Your RUIGE A6 watch is powered by an automatic mechanical movement. Before wearing it for the first time, or if it has stopped due to inactivity, it requires manual winding.

1. Ensure the crown is in position 1 (fully pushed in, against the watch case).
2. Rotate the crown clockwise approximately 30-40 times. This will build up an initial power reserve.
3. Once wound, the watch will start ticking. Subsequent wearing will keep the watch wound through your natural wrist movements.

### 2. Setting Time and Date

The watch features a day and date display. Follow these steps to set the correct time and calendar.

1. **Setting the Date:** Gently pull the crown out to position 2 (first click). Rotate the crown clockwise to adjust the date. Rotate counter-clockwise to adjust the day of the week. *Avoid setting the date or day between 9 PM and 3 AM, as this can damage the movement. If the time falls within this period, first set the time outside this range, then adjust the date/day, and finally reset the time.*

2. **Setting the Time:** Pull the crown out to position 3 (second click). The second hand will stop. Rotate the crown to move the hour and minute hands. Advance the hands past 12 o'clock to ensure the AM/PM is correctly set for the date change.
3. Once the correct time is set, push the crown back into position 1 (fully pushed in) to start the watch and ensure water resistance.



Figure 2: A detailed view of the watch face, illustrating the crown's position for time and date adjustments.

### 3. Adjusting the Bracelet

The stainless steel bracelet is designed for comfort. If the bracelet is too loose or too tight, it may need adjustment.

- The bracelet features removable links. For precise adjustment, it is recommended to visit a professional watchmaker or jeweler.
- The clasp is a double-click butterfly buckle, providing a secure and smooth fit.



**Figure 3:** The double-click butterfly clasp mechanism, designed for secure and comfortable wearing.

**IT IS SUITABLE TO MASTER  
MOVEMENT AT ALL TIMES.**

**Youyan PICOOC redefines men's machinery**

REDEFINING MEN'S MACHINERY WITH BEAUTY AND QUALITY



Figure 4: A close-up of the 316L solid stainless steel bracelet links, highlighting their construction.

## Automatic Movement

The RUIGE A6 features an automatic mechanical movement. This means the watch is powered by the natural motion of your wrist. As you wear the watch, an oscillating weight inside the movement rotates, winding the mainspring and storing energy.

- **Power Reserve:** A fully wound automatic watch typically has a power reserve of approximately 36-40 hours. If the watch is not worn for an extended period, it will stop. Simply re-wind it manually (as described in the "Initial Winding" section) and wear it to resume operation.
- **Wearing Comfort:** The watch is designed with ergonomics in mind, ensuring a comfortable fit for daily wear.

# DESIGNED ACCORDING TO ERGONOMICS

The connection between each place is just right, and the  
comfort is doubled.


EVERYTHING IS PERFECTLY CONNECTED, AND THE COMFORT IS DOUBLED



Figure 5: The RUIGE A6 watch comfortably worn on a wrist, demonstrating its ergonomic design.



## MORE DETAILS ARE UNDER CONTROL



**316L stainless steel | 7 beads solid steel forged long-lasting mix-in**

**Figure 6:** The watch being worn during daily activities, highlighting its suitability for various movements.

### Water Resistance

Your RUIGE A6 watch has a water resistance rating of 30 meters (3 ATM). This rating indicates that the watch is suitable for everyday use and can withstand splashes, rain, and brief immersion in water.

- **Do NOT** wear the watch for swimming, diving, showering, or any activities involving prolonged water immersion or high-pressure water exposure.
- Ensure the crown is always fully pushed in to maintain water resistance.
- Avoid operating the crown while the watch is wet or submerged.

### MAINTENANCE

- **Cleaning:** Wipe the watch case and bracelet regularly with a soft, dry cloth to remove dust, sweat, and dirt. For stubborn grime, a slightly damp cloth can be used, followed by immediate drying. Avoid using harsh chemicals or abrasive materials.
- **Storage:** When not wearing your watch for an extended period, store it in a cool, dry place, away from direct sunlight and extreme temperatures. The original watch box is ideal for storage.

- **Avoid Magnetic Fields:** Mechanical watches can be affected by strong magnetic fields (e.g., from speakers, refrigerators, certain electronic devices), which can cause them to run inaccurately. Keep your watch away from such sources.
- **Professional Service:** Like any precision mechanical instrument, your watch will benefit from periodic professional servicing (typically every 3-5 years) to ensure its accuracy and longevity. This involves cleaning, lubricating, and adjusting the movement.

## TROUBLESHOOTING

---

- **Watch has stopped or is running slowly:**

As an automatic watch, it relies on motion. If it has stopped, manually wind the watch by rotating the crown clockwise 30-40 times (with the crown fully pushed in). Wear the watch regularly to keep it wound.

- **Date/Day is not changing at midnight:**

The watch's time might be set to PM when it should be AM, or vice-versa. Pull the crown to position 3 and advance the time by 12 hours. Then, re-check the date/day change. Ensure you avoid setting the date/day between 9 PM and 3 AM.

- **Watch is running too fast or too slow:**

Minor variations in accuracy are normal for mechanical watches. However, if the deviation is significant, it might be due to exposure to strong magnetic fields or require professional adjustment. Consult a qualified watchmaker.

- **Condensation under the crystal:**

This indicates moisture has entered the watch. Immediately take the watch to a professional watchmaker for inspection and repair to prevent damage to the movement.

## SPECIFICATIONS

---

<b>Brand</b>	RUIGE
<b>Model Name</b>	A6
<b>Movement Type</b>	Automatic Mechanical
<b>Display Type</b>	Analog
<b>Case Material</b>	Stainless Steel
<b>Band Material</b>	Stainless Steel
<b>Crystal Material</b>	Mineral Glass
<b>Water Resistance Depth</b>	30 Meters (3 ATM)
<b>Clasp Type</b>	Double Click Butterfly Buckle
<b>Features</b>	Day and Date Calendar

## WARRANTY

---

Your RUIGE A6 Automatic Watch comes with a limited warranty. Please refer to the warranty card or documentation included with your purchase for specific terms, conditions, and duration of the warranty. The warranty typically covers manufacturing defects but does not cover damage resulting from improper use, accidents, or unauthorized repairs.

## SUPPORT

---

For further assistance, technical support, or warranty claims, please contact the retailer where you purchased your RUIGE A6 watch or refer to the contact information provided in your watch's packaging.