

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [EUHOMY](#) /

› [EUHOMY 7.4 Cu.Ft. Refrigerator with Freezer \(Model RF003-74\) Instruction Manual](#)

EUHOMY RF003-74

EUHOMY 7.4 Cu.Ft. Refrigerator with Freezer Instruction Manual

Model: RF003-74

1. INTRODUCTION

This manual provides essential information for the safe and efficient operation, installation, and maintenance of your EUHOMY 7.4 Cu.Ft. Refrigerator with Freezer, Model RF003-74. Please read these instructions thoroughly before using the appliance and retain them for future reference.

2. SAFETY INFORMATION

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury.

- Ensure the refrigerator is properly grounded.
- Do not operate the appliance with a damaged power cord or plug.
- Keep ventilation openings clear of obstruction.
- Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.
- Unplug the refrigerator before cleaning or performing any maintenance.
- Allow the refrigerator to stand upright for at least 24 hours before plugging it in for the first time.

3. PRODUCT OVERVIEW

The EUHOMY 7.4 Cu.Ft. Refrigerator with Freezer is a two-door compact appliance designed for efficient food storage and cooling. It features a separate freezer compartment and a refrigerator compartment, offering a total capacity of 7.4 cubic feet.

Key Features:

- **Dual Zone Design:** 1.8 Cu.Ft. freezer zone and 5.6 Cu.Ft. refrigerator zone.
- **7-Level Temperature Adjustment:** Allows precise control over cooling settings.
- **Adjustable Glass Shelves:** Customize storage space within the refrigerator compartment.
- **Crisper Drawer:** Dedicated storage for fresh fruits and vegetables.

- **Reversible Door:** Allows for flexible placement by changing the door swing direction.
- **Rear Wheels:** Facilitates easy movement of the appliance.
- **Low Noise Operation:** Equipped with an efficient compressor designed for quiet performance.
- **LED Interior Lighting:** Provides clear visibility inside the refrigerator.

Included Components:

- 7.4 Cu.Ft Refrigerator (1 unit)
- Glass Partitions (3 units)
- Shelf (1 unit)
- Fruit & Vegetable Box (1 unit)
- Ice Shovel (1 unit)
- Ice Tray (1 unit)
- User Manual (1 unit)



Image 3.2: Illustration of included accessories (ice tray, ice shovel, shelf divider, fruit & vegetable box, glass partitions) and key dimensions of the refrigerator.

7.4 ^{CU.FT}

Compact size but large capacity



(Below -11.2°F)

○ **1.8 Cu.Ft**
Freezing area

(32°F - 50°F)

○ **5.6 Cu.Ft**
Refrigerated area

Image 3.3: Visual representation of the 7.4 Cu.Ft. total capacity, showing 1.8 Cu.Ft. for the freezing area and 5.6 Cu.Ft. for the refrigerated area.

Cooling And Insulation Combination

✓ Fast cooling

✓ Long-term freshness




Image 3.4: Diagram illustrating the cooling and insulation combination, highlighting fast cooling, long-term freshness, circulation cooling, efficient compressor, and high-density foam layer.

Reversible Door



Equipped with Rear Wheels



Built-in Handle



5-ADVANTAGE OF EUHOMY



Removable Glass Shelves



Wide Temperature Range



Image 3.5: Overview of key features including reversible door, rear wheels for mobility, built-in handle, removable glass shelves for flexible storage, and a wide temperature range.

Low Noise & Automatic Lights




Image 3.6: Illustration demonstrating the low noise level (38 dB) of the refrigerator compared to other sounds, and the presence of automatic interior lights.

4. SETUP AND INSTALLATION

1. **Unpacking:** Carefully remove all packaging materials. Inspect the refrigerator for any shipping damage.
2. **Placement:** This is a freestanding unit. Place the refrigerator on a flat, stable surface. Ensure adequate clearance around the unit for proper ventilation (refer to specifications for dimensions). The adjustable feet allow for leveling the appliance.

3. **Initial Standby:** After transportation, allow the refrigerator to stand upright for at least 24 hours before plugging it into a power outlet. This allows the refrigerant to settle, preventing potential damage to the cooling system.
4. **Power Connection:** Connect the refrigerator to a dedicated, properly grounded electrical outlet.
5. **Door Reversal (Optional):** The door hinges are reversible, allowing you to change the direction the doors open to suit your space. Refer to the detailed instructions in the full user manual for this procedure.
6. **Internal Setup:** Install the glass shelves, crisper drawer, and any other internal components as desired. The shelves are adjustable to accommodate various item sizes.

5. OPERATING INSTRUCTIONS

Temperature Control:

Your EUHOMY refrigerator features a 7-level temperature adjustment system. The thermostat control is typically located inside the refrigerator compartment. Turn the dial or adjust the setting to your desired cooling level.

- Settings 1-2 are suitable for vegetables and fruits.
- Settings 3-4 are ideal for wine and beverages.
- Settings 5-6 are recommended for yogurt and ice cream.
- Setting 7 provides the coldest temperature, suitable for seafood and meats.

Adjust the thermostat gradually and allow several hours for the temperature to stabilize between adjustments.

7

Modes

Temperature Available

Precision Cooling



Mode 1-2

Vegetables and fruits




Mode 3-4

Wine and beverages



Mode 5-6

Yogurt and ice cream



Mode 7

Seafood and meats

(For Recommended)

MODE	1	2	3	4	5	6	7
COOLER (°F / °C)	50 °F (10 °C)	46 °F (7.7 °C)	46 °F (7.7 °C)	45 °F (7.4 °C)	44 °F (7.0 °C)	42 °F (5.4 °C)	32 °F (0.2 °C)
FREEZER (°F / °C)	14 °F (-10 °C)	11 °F (-11.7 °C)	8 °F (-13.3 °C)	5 °F (-15 °C)	0 °F (-17.8 °C)	-5 °F (-20.6 °C)	-11.2 °F (-24 °C)

* Temperature test results at room temperature of 66°F (18°C), for reference only.

Image 5.1: Guide to the 7 temperature modes available, with recommended uses for different food types and corresponding cooler/freezer temperatures.

Food Storage Guidelines:

- Store fresh produce in the crisper drawer to maintain humidity.
- Keep dairy products and eggs on the upper shelves.
- Meats and poultry should be stored on the lowest shelf to prevent drips onto other foods.
- Ensure all food items are properly sealed to prevent odor transfer and maintain freshness.
- Do not overload the refrigerator, as this can impede air circulation and cooling efficiency.

6. MAINTENANCE

Cleaning:

1. **Exterior:** Wipe the exterior surfaces with a soft cloth dampened with mild detergent and water. Dry thoroughly.
2. **Interior:** Clean the interior regularly with a solution of baking soda and water (1 tablespoon baking soda to 1 quart water). Rinse with clean water and dry thoroughly. Remove shelves and drawers for easier cleaning.
3. **Door Gaskets:** Clean door gaskets with mild soap and water to ensure a tight seal.
4. **Condenser Coils:** Periodically vacuum the condenser coils at the back or bottom of the refrigerator to maintain efficiency.

Defrosting (Manual):

This refrigerator features a manual defrost system for the freezer compartment. Frost buildup can reduce cooling efficiency and storage space. Defrost when frost accumulation reaches approximately 1/4 inch (6 mm) thick.

1. Unplug the refrigerator from the power outlet.
2. Remove all food items from the freezer and store them in a cooler or another refrigerator.
3. Leave the freezer door open to allow frost to melt naturally. Place towels or a shallow pan to collect water. Do not use sharp objects or heating devices to speed up defrosting, as this can damage the appliance.
4. Once all frost has melted, clean and dry the interior of the freezer.
5. Plug the refrigerator back in and allow it to cool down before returning food items.

7. TROUBLESHOOTING

Before contacting customer service, please check the following common issues and solutions:

Problem	Possible Cause	Solution
Refrigerator does not operate.	Not plugged in; circuit breaker tripped; power outage.	Check power cord connection; reset circuit breaker; check household power supply.
Temperature is not cold enough.	Thermostat set too warm; door opened too frequently; excessive food load; poor ventilation.	Adjust thermostat to a colder setting; ensure door is closed properly; reduce food load; ensure adequate space around the unit.
Unusual noises.	Refrigerator not level; items vibrating inside; normal compressor operation.	Level the refrigerator using adjustable feet; rearrange items; humming sounds from the compressor are normal.
Excessive frost buildup in freezer.	Freezer door not sealed properly; frequent door opening; high humidity.	Check door gasket for proper seal; reduce frequency of door opening; perform manual defrost as described in Section 6.
Water on floor.	Drain pan overflowing during defrost; door not closed properly.	Ensure drain pan is correctly positioned and emptied during defrost; check door seal.

8. SPECIFICATIONS

Specification	Value
Brand	EUHOMY
Model Number	RF003-74
Total Capacity	7.4 Cubic Feet
Refrigerator Fresh Food Capacity	5.6 Cubic Feet
Freezer Capacity	1.8 Cubic Feet
Product Dimensions (D x W x H)	22.2 x 20.6 x 56.4 inches
Item Weight	74.9 pounds
Installation Type	Freestanding
Number of Doors	2
Defrost System	Manual
Voltage	115 Volts (AC)
Annual Energy Consumption	376 Kilowatt Hours Per Year
Special Features	Adjustable Shelves, Reversible Door, LED Lighting
Color	Silver



1.03 kwh / day

≈ 0.03USD / day

Image 8.1: Information on the refrigerator's energy consumption, approximately 1.03 kWh per day.

9. WARRANTY AND SUPPORT

EUHOMY is committed to providing quality products and customer satisfaction. While specific warranty details are not provided in this document, please retain your proof of purchase for any warranty claims.

For technical assistance, troubleshooting beyond this manual, or warranty inquiries, please contact EUHOMY customer support. Our professional team is ready to respond to your needs.

You can often find contact information on the manufacturer's official website or through the retailer where the product was purchased.



© 2026 EUHOMY. All rights reserved.