

AIRROBO P25

AIRROBO P25 Robot Vacuum Cleaner User Manual

Model: P25

1. IMPORTANT SAFETY INFORMATION

Please read this manual carefully before using the AIRROBO P25 Robot Vacuum Cleaner and retain it for future reference. Adhere to all safety warnings and instructions to prevent injury or damage.

- This appliance can be used by children aged 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
- Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- Ensure the charging base is placed against a wall on a level surface and is connected to a power outlet.
- Do not use the robot vacuum in wet environments or near water.
- Keep hair, loose clothing, fingers, and all parts of body away from openings and moving parts.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- Do not use without dust bin and/or filters in place.
- Only use the charging adapter provided by the manufacturer.

2. PACKAGE CONTENTS

Verify that all items are present and in good condition upon opening the package:

- AIRROBO P25 Robot Vacuum
- Charging Base
- AC Power Adapter
- Remote Control
- 4 Side Brushes
- Hepa Filter (pre-installed)
- Cleaning Tool
- User Guide
- Service Card

- Main Brush (pre-installed)

What's in the Box

- ① AIRROBO P25 Robot Vacuum
- ② Charging Base
- ③ Charge Adapter
- ④ Remote Control
- ⑤ Side Brush
- ⑥ Hepa Filter
- ⑦ User Manual
- ⑧ Service Card
- ⑨ Main Brush



Image: All components included in the AIRROBO P25 Robot Vacuum package.

3. PRODUCT OVERVIEW

3.1 Components

The AIRROBO P25 Robot Vacuum consists of the following main components:

- Main Unit (Robot Vacuum)
- Dustbin with HEPA Filter
- Side Brushes
- Main Brush
- Charging Contacts
- Infrared Sensors (Anti-collision, Anti-fall)
- Power Button
- Home Button (Return to Charging Base)



Image: The AIRROBO P25 Robot Vacuum with its primary controls visible.

3.2 Key Features

The AIRROBO P25 is designed with advanced features for efficient cleaning:

- **Powerful 2800Pa Suction:** Effectively cleans dust, dirt, and pet hair from various floor types, including low-pile carpets and hard floors.
- **Slim 3-inch Design:** Allows the vacuum to easily navigate under furniture like sofas, beds, and cabinets, reaching hidden dirt.
- **Smart Gyroscope Navigation:** Utilizes precision gyroscope navigation and infrared sensors to clean in systematic rows, avoiding obstacles and preventing falls.
- **600ML Large Dustbin:** A generous dustbin capacity reduces the frequency of emptying, especially beneficial for pet owners.
- **Smart APP Control & Voice Control:** Manage cleaning schedules, modes, and monitor status via a dedicated smartphone application. Compatible with Amazon Alexa and Google Assistant for voice commands.
- **Automatic Recharge:** The robot automatically returns to its charging base when the battery is low or after completing a cleaning cycle.

- **Multiple Cleaning Modes:** Offers various cleaning modes including Auto Clean, Spot Clean, Edge Clean, and Spiral Clean to suit different cleaning needs.



Image: The robot vacuum showcasing its powerful 2800Pa suction capability.

Slim body effectively cleans hidden dirt



Angle 15°



15mm



55dB Noise




2.99 inch



Image: The slim design of the robot vacuum allows it to clean under low furniture.


Smart Dynamic Navigation

Improve Cleaning efficient to 95%



AIRROBO P25

VS



Others brand



Image: Illustration of the robot's efficient gyroscope navigation system.

4. SETUP

4.1 Charging the Robot

Before first use, fully charge the robot vacuum. Place the charging base against a wall in an open area, ensuring there are no obstacles within 1 meter (3 feet) to the sides and 2 meters (6 feet) in front. Connect the power adapter to the charging base and plug it into a wall outlet. Place the robot onto the charging base, ensuring the charging contacts align. The indicator light on the robot will show charging status.



Image: The robot vacuum automatically docking with its charging base.

4.2 Connecting to the AIRROBO App

For enhanced control and scheduling, connect your AIRROBO P25 to the official AIRROBO app:

1. Connect your smartphone to a 2.4GHz Wi-Fi network and ensure Bluetooth is enabled.
2. Turn on the AIRROBO P25 robot vacuum.
3. Download the 'AIRROBO' app from your smartphone's app store.
4. Create an account and log in to the AIRROBO app.
5. Click 'Add device' within the app and select the P25 robot vacuum from the list.
6. Follow the on-screen prompts to complete the connection.




Image: Step-by-step guide for connecting the robot vacuum to the AIRROBO mobile application.

5. OPERATING THE ROBOT VACUUM

5.1 Cleaning Modes

The AIRROBO P25 offers several cleaning modes to address different cleaning needs:

- **Auto Clean:** The robot cleans systematically in a zig-zag pattern, covering the entire floor area.

- **Spot Clean:** The robot cleans a concentrated area in a spiral pattern, ideal for localized spills or dirt.
- **Edge Clean:** The robot cleans along walls and furniture edges to ensure thorough cleaning of corners and perimeters.
- **Spiral Clean:** Similar to Spot Clean, but can be initiated for a larger area.

4 Cleaning Modes

Let the dust have nowhere to go



Image: Visual representation of the four distinct cleaning modes.




Image: Different cleaning paths the robot can follow based on selected mode.

5.2 Scheduling Cleaning

Use the AIRROBO app to set up scheduled cleaning times. This allows the robot to automatically start cleaning at your preferred times, even when you are not home.

- Open the AIRROBO app.
- Navigate to the scheduling section.
- Set desired cleaning times and days.
- Confirm the schedule.



Image: Setting a timed cleaning task via the mobile app.

5.3 Voice Control

The AIRROBO P25 is compatible with Amazon Alexa and Google Assistant. Once connected to your smart home system, you can control the robot with voice commands.

- Ensure your robot is connected to the AIRROBO app and your smart home assistant (Alexa/Google Assistant) is linked to your AIRROBO account.
- Use commands such as "Alexa, turn on the P25" or "Hey Google, start cleaning with P25."

Smart APP & Voice Control



Image: Controlling the robot vacuum using smart app and voice commands.

6. MAINTENANCE

Regular maintenance ensures optimal performance and extends the lifespan of your robot vacuum.

6.1 Emptying the Dustbin

The 600ML dustbin should be emptied after each cleaning cycle or when full.

1. Press the dustbin release button to remove the dustbin from the robot.
2. Open the dustbin cover and empty its contents into a trash can.
3. Close the dustbin cover and reinsert it into the robot until it clicks into place.

600ML Large Dustbin



Image: The 600ML large dustbin, shown with collected debris.

6.2 Cleaning Filters and Brushes

Clean the HEPA filter and brushes regularly to maintain suction power.

- **HEPA Filter:** Tap the filter gently to remove dust. Do not wash the HEPA filter with water. Replace every 3-6 months depending on usage.
- **Side Brushes:** Remove any tangled hair or debris from the side brushes. If brushes are worn, replace them.
- **Main Brush:** Remove the main brush cover and lift out the brush. Use the cleaning tool to cut and remove tangled hair.
- **Charging Contacts:** Wipe the charging contacts on both the robot and the charging base with a dry cloth periodically to ensure good connection.

7. TROUBLESHOOTING

Refer to the table below for common issues and their solutions:

Problem	Possible Cause	Solution
Robot does not turn on	Low battery; Power switch off	Place robot on charging base; Ensure power switch is ON.
Robot does not charge	Charging contacts dirty; Charging base not powered	Clean charging contacts; Check power connection to charging base.
Reduced suction power	Dustbin full; Filter clogged; Main brush tangled	Empty dustbin; Clean/replace filter; Clean main brush.
Robot gets stuck frequently	Obstacles on floor; Cliff sensors dirty	Clear cables/small objects; Clean cliff sensors.
Cannot connect to App	Incorrect Wi-Fi band (not 2.4GHz); Incorrect password; Bluetooth off	Ensure 2.4GHz Wi-Fi; Re-enter password; Turn on Bluetooth.

8. SPECIFICATIONS

Key technical specifications for the AIRROBO P25 Robot Vacuum Cleaner:

Feature	Specification
Brand	AIRROBO
Model Name	P25
Suction Power	2800Pa (Max Mode)
Product Dimensions	12" L x 12" W x 3" H (30cm x 30cm x 8cm)
Dustbin Capacity	600 ml
Battery Life	Up to 120 minutes
Filter Type	HEPA
Control Method	App, Remote Control
Navigation Type	Gyroscope Navigation
Noise Level	55dB (Quiet Mode)
Power Source	Battery Powered
Item Weight	7.7 pounds

Dimensions

P25 Robot Vacuum
30*30*8cm



Image: Dimensions of the AIRROBO P25 Robot Vacuum.

9. WARRANTY AND SUPPORT


The AIRROBO P25 Robot Vacuum Cleaner comes with a worry-free **12-month warranty** from the date of purchase. This warranty covers manufacturing defects and malfunctions under normal use.

For customer support, technical assistance, or warranty claims, please contact AIRROBO directly:

- **Customer Support Phone:** +1 8599558668
- **Operating Hours:** 9 AM to 5 PM, Monday to Friday (Eastern Time)
- You can also visit the official AIRROBO store on Amazon for more information and support resources:
[AIRROBO Amazon Store](#)

© 2025 AIRROBO. All rights reserved.

Related Documents



[AIRROBO T20+ Robot Vacuum Cleaner User Manual](#)

Comprehensive user manual for the AIRROBO T20+ Robot Vacuum Cleaner with LDS Laser Navigation and Automatic Dirt Disposal. Includes setup, operation, maintenance, troubleshooting, and safety information.

	<p>AIRROBO P20 Robot Vacuum Cleaner User Manual</p> <p>This user manual provides comprehensive instructions for the AIRROBO P20 Robot Vacuum Cleaner, covering proper use, safety information, and maintenance. Learn about setup, operation, app connectivity, and specifications.</p>
	<p>AIRROBO P10 Robot Vacuum Cleaner User Manual</p> <p>This user manual provides comprehensive instructions for the AIRROBO P10 Robot Vacuum Cleaner, covering setup, operation, cleaning, maintenance, troubleshooting, specifications, and warranty information.</p>
	<p>AIRROBO T10+ Robot Vacuum App Connection Guide</p> <p>A step-by-step guide on how to connect your AIRROBO T10+ Robot Vacuum to the Tuya Smart app via Wi-Fi, including troubleshooting tips for 2.4GHz connections.</p>

Documents - AIRROBO – P25



[\[pdf\] User Manual Instructions](#)

PC10 EN 20240312 AIRROBO User Manual US Official Website v 1751615564 cdn shopify s files 1 0578
6373 3436 |||

36 1 # # Robotic Pool Cleaner PC 10 User Manual Please read this manual carefully
... IT ItalianoP20-P25

4.Instructions for Use.....P02...

lang:en **score:29** filesize: 8.83 M page_count: 11 document date: 2024-04-08



[Robotic Pool Cleaner User Manual - Airrobo](#)

Comprehensive user manual for the Airrobo Robotic Pool Cleaner, covering setup, operation, maintenance, troubleshooting, and compliance information. Learn how to effectively clean and maintain your pool with this guide.

lang:en **score:28** filesize: 15.75 M page_count: 54 document date: 2025-07-04



[\[pdf\] User Manual](#)

PC10 IT 20240312 AIRROBO User Manual US Official Website v 1751615562 cdn shopify s files 1 0578
6373 3436 |||

Contents IT 1.AVVERTENZE..... P24-P25
P24 8.Domande frequenti P25-P25 1.

AVVERTENZE Grazie per aver scelto di acquistare il Robot da piscina Airrobo. Si prega di...

lang:it **score:28** filesize: 7.89 M page_count: 6 document date: 2025-04-01