esonstyle S8

esonstyle Invisible Sleep Headphones S8 User Manual

Model: S8

Product Overview

The esonstyle Invisible Sleep Headphones S8 are designed for comfort and effective noise blocking, particularly for side sleepers. These mini earbuds incorporate Bluetooth 5.3 technology for stable wireless connectivity and feature an IPX6 waterproof rating, making them suitable for various activities including sleeping, workouts, and general daily use.



Image: The esonstyle S8 Invisible Sleep Headphones, showing the earbuds inside their open charging case. A single earbud is also shown separately in the top right corner, highlighting its compact design and ear tip.

What's in the Box

- Sleep Earbuds (Left and Right)
- Eartips
- Wireless Charging Case
- User Manual

Setup

Initial Charging

1. Place both earbuds into the charging case.
2. Connect a USB-C charging cable (not included) to the charging case and a power source.
3. Allow the earbuds and case to fully charge before first use. Charging indicator lights will provide status.

Pairing with Your Device

1. Ensure the earbuds are in the charging case and the lid is open, or remove them from the case to activate pairing mode.
2. On your device (smartphone, tablet, etc.), enable Bluetooth.
3. Search for available Bluetooth devices. The earbuds will appear as "esonstyle S8" or similar.
4. Select "esonstyle S8" to connect. A voice prompt or indicator light will confirm successful pairing.

Operating Instructions

Wearing the Earbuds

- Identify the Left (L) and Right (R) earbuds.
- Gently insert each earbud into the corresponding ear canal.
- Adjust the earbud until it fits snugly and comfortably, ensuring an effective noise-blocking seal. The small design is optimized for side sleepers.

Basic Controls (Touch Sensitive)

The earbuds feature touch-sensitive controls. Specific functions may vary slightly; refer to the included user manual for detailed gestures.

- **Play/Pause:** Single tap on either earbud.
- **Next Track:** Double tap on the right earbud.
- **Previous Track:** Double tap on the left earbud.
- **Answer/End Call:** Single tap on either earbud.
- **Reject Call:** Press and hold either earbud for 2 seconds.
- **Activate Voice Assistant:** Triple tap on either earbud.

Power On/Off

- **Power On:** Earbuds automatically power on when removed from the charging case.
- **Power Off:** Earbuds automatically power off when placed back into the charging case and the lid is closed.

Maintenance

- **Cleaning:** Use a soft, dry, lint-free cloth to clean the earbuds and charging case. Do not use harsh chemicals or abrasive materials.
- **Eartips:** Periodically remove and clean the eartips with a damp cloth. Ensure they are completely dry before reattaching.
- **Storage:** When not in use, store the earbuds in their charging case to protect them and keep them charged.
- **Water Resistance:** The earbuds are IPX6 waterproof, meaning they can withstand strong jets of water. However, they are not designed for submersion. Avoid exposing the charging case to water.
- **Battery Care:** To prolong battery life, avoid fully discharging the earbuds and charging case frequently. Charge them regularly.

Troubleshooting

Problem	Possible Cause	Solution
Earbuds not pairing.	Earbuds not in pairing mode; Bluetooth off on device; previously paired device interfering.	Ensure earbuds are removed from case or case lid is open. Turn Bluetooth off and on again on your device. Forget "esonstyle S8" from your device's Bluetooth list and re-pair.

Problem	Possible Cause	Solution
No sound from one earbud.	Low battery; earbud not properly connected; earbud dirty.	Place both earbuds back in the charging case and ensure they are charging. Clean the charging contacts on the earbud and in the case. Re-pair the earbuds.
Charging case not charging.	Faulty cable or power source; dirty charging port.	Try a different USB-C cable and power adapter. Ensure the charging port on the case is clean and free of debris.
Poor sound quality.	Improper fit; low battery; interference.	Adjust the earbuds for a better seal. Ensure earbuds are fully charged. Move closer to your connected device to reduce interference.

Specifications

Model Name	S8
Brand	esonstyle
Connectivity Technology	Wireless (Bluetooth 5.3)
Ear Placement	In Ear
Form Factor	In Ear
Color	Black
Battery Life (Earbuds)	Up to 4 hours (music time)
Battery Life (with Charging Case)	Approximately 24 hours additional
Charging Port	USB-C
Waterproof Rating	IPX6
Item Weight	3.2 ounces
Package Dimensions	4.33 x 2.95 x 1.61 inches

Warranty and Support

For warranty information and customer support, please refer to the official esonstyle website or contact their customer service directly. The included user manual may also contain specific warranty details.
Manufacturer: esonstyle
ASIN: B0DY4S9CX9
For further assistance, visit the esonstyle Store on Amazon.

© 2025 esonstyle. All rights reserved.