

AGARO 34331

AGARO Regal Portable Clothes Dryer (Model 34331)
User Manual
Your guide to efficient and convenient clothes drying.

Overview	Safety Instructions	Package Contents	Setup	Operation	Maintenance
	Troubleshooting	Specifications	Warranty & Support		

1. PRODUCT OVERVIEW

The AGARO Regal Portable Clothes Dryer (Model 34331) is designed for efficient and convenient drying of clothes. Featuring a 103-liter capacity and 600W power, it utilizes a 3D hot air drying system to protect fabrics and eliminate odors. Its compact and portable design makes it suitable for home use, travel, and drying various items including baby clothing and towels.



Image 1.1: Overview of the AGARO Regal Portable Clothes Dryer highlighting its key features such as 20-minute quick drying, expandable design, compact and portable nature, travel-friendliness, and 360-degree hot air circulation.

2. IMPORTANT SAFETY INSTRUCTIONS

Please read all safety instructions carefully before using the appliance to prevent injury or damage. Keep this manual for future reference.

- Ensure the power supply matches the voltage specified on the appliance.
- Do not operate the dryer with a damaged cord or plug. Contact customer support for repairs.
- Keep the appliance away from water or other liquids to avoid electric shock.
- Do not block air vents during operation to prevent overheating.
- Always unplug the dryer when not in use or before cleaning.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Do not overload the dryer. Adhere to the recommended capacity.
- Avoid drying items that have been soiled with cooking oil, gasoline, or other flammable substances.

3. PACKAGE CONTENTS

Verify that all components are present in the package:

- AGARO Regal Portable Clothes Dryer Unit
- Cloth Cover (103L capacity)
- Hangers (typically 9 pieces, or as specified)
- User Manual

4. SETUP INSTRUCTIONS

The AGARO Regal Portable Clothes Dryer is designed for hassle-free setup with no assembly required. Follow these steps to prepare your dryer for use:

1. **Remove the Machine Cover:** Carefully open the packaging and remove the main dryer unit.



Image 4.1: Visual guide for the initial setup, showing the dryer unit and the cloth cover.

2. **Unzip and Remove the Cloth Cover:** Unzip the cloth cover and attach it to the main dryer unit. Ensure it is securely fastened.
3. **Extend the Dryer (Optional):** For increased capacity, the dryer unit can be freely extended. This provides approximately 40% more drying space.



Image 4.2: Demonstrates how to extend the dryer unit to increase its capacity.

4. **Placement:** Place the dryer on a stable, flat surface or utilize its wall-mountable feature for added convenience. Ensure adequate space around the unit for proper air circulation.

Wall-mountable for added convenience!



Image 4.3: The dryer unit shown in a wall-mounted configuration, illustrating its versatility.

5. OPERATING INSTRUCTIONS

Operating your AGARO Regal Portable Clothes Dryer is straightforward. Follow these steps for optimal drying results:

1. **Load Clothes:** Hang up to 9 items of clothing (or up to 9kg) on the provided hangers inside the cloth cover. Ensure clothes are not overlapping excessively to allow for proper air circulation. The 103-liter capacity is designed for efficient drying of various garments, including light clothes, baby clothes, and undergarments.



Image 5.1: Illustrates the dryer's capacity, showing multiple garments hung inside for drying.

2. **Close the Zipper:** Securely close the zipper of the cloth cover to create an enclosed drying environment.
3. **Plug In and Power On:** Connect the power cord to a suitable electrical outlet. The control panel is located on the top of the unit.

Fast Drying Technology

Comes with timer & dries fast.



Image 5.2: Close-up of the dryer's control panel, showing power and timer settings.

4. **Select Drying Time:** Use the timer controls on the unit to select the desired drying duration. Available options typically include 1 hour, 2 hours, and 3 hours. The 3D hot air drying system provides fast and efficient drying.
5. **UV Protection (if applicable):** The dryer may feature UV protection for germ-free clothes, suitable for families and baby-safe laundry. This function operates automatically during the drying cycle.
6. **Quiet Operation:** The dryer incorporates shock-absorbing and noise-reducing technology for quiet operation, ensuring minimal disturbance.
7. **Drying Complete:** Once the selected drying time has elapsed, the unit will automatically shut off. Carefully open the cloth cover and remove your dry clothes.

6. CARE AND MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your AGARO Regal Portable Clothes Dryer.

- **Cleaning the Unit:** Disconnect the power cord before cleaning. Wipe the exterior of the dryer unit with a soft, damp cloth. Do not use abrasive cleaners or solvents.

- **Cleaning the Cloth Cover:** The cloth cover can be hand washed or machine washed on a gentle cycle with mild detergent. Ensure it is completely dry before reattaching it to the unit.
- **Storage:** When not in use, the dryer is compact and easy to store. Fold the cloth cover and store the main unit in a dry, cool place.

7. TROUBLESHOOTING GUIDE

If you encounter any issues with your dryer, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Dryer does not turn on.	No power supply; power cord not properly connected.	Check if the power cord is securely plugged into a working outlet. Ensure the power switch is on.
Clothes are not drying completely.	Overloaded capacity; insufficient drying time; poor air circulation.	Reduce the number of clothes. Increase drying time. Ensure clothes are hung without excessive overlap and the cloth cover is fully zipped.
Unusual noise during operation.	Unit not on a stable surface; foreign object inside.	Place the dryer on a flat, stable surface. Unplug and check for any obstructions inside the unit.
Dryer overheats and shuts off.	Blocked air vents; internal malfunction.	Ensure air vents are clear. If the problem persists, discontinue use and contact customer support.

If the problem persists after attempting these solutions, please contact AGARO customer support.

8. PRODUCT SPECIFICATIONS

Brand	AGARO
Model Name	AGARO Regal
Model Number	34331
Form Factor	Portable
Access Location	Top Load
Capacity	103 Liters
Colour	Beige
Item Weight	1750 Grams
Material Type	Plastic (Outer Body), Stainless Steel (Internal Drum)
Manufacturer	UNIVERSAL CORPORATION LTD. Guangdong Province, China
Importer Contact Information	UNIVERSAL CORPORATION LTD. ADDRESS:37, GREAMS ROAD, CHENNAI:600006, INDIA

9. WARRANTY AND SUPPORT

The AGARO Regal Portable Clothes Dryer comes with a **1-year warranty** from the date of purchase, covering manufacturing defects. Please retain your purchase receipt as proof of purchase.

For technical support, warranty claims, or any inquiries regarding your product, please contact:

- **Manufacturer:** UNIVERSAL CORPORATION LTD.
- **Importer:** UNIVERSAL CORPORATION LTD.
- **Address:** 37, GREAMS ROAD, CHENNAI:600006, INDIA
- *(Specific contact numbers or email addresses are not provided in the product data. Please refer to the product packaging or AGARO's official website for direct support contact details.)*



Image 9.1: The dryer unit displaying a "1 Year Warranty" badge, confirming the warranty period.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0DY4YSJR3>

More documents and user manuals: <https://manuals.plus/>