

[Manuals.plus](#) /

› [WLIVE](#) /

› WLIVE 9-Drawer LED Dresser User Manual

WLIVE ASNG122/QX

WLIVE 9-Drawer LED Dresser

USER MANUAL

Product Overview

The WLIVE 9-Drawer LED Dresser is a versatile storage solution designed for bedrooms, living rooms, and other spaces. It features integrated LED lighting with multiple modes and colors, built-in power outlets and USB ports for convenient charging, and ample storage with both wooden and fabric drawers. Its robust construction ensures stability and durability.



Image: The WLIVE 9-Drawer LED Dresser in Light Oak, showcasing its design and LED lighting.

Safety Information

Please read all safety instructions carefully before assembly and use. Failure to follow these instructions may result in injury or damage to the product.

- Always assemble the dresser on a soft, clean surface to prevent scratches.
- Ensure all screws and fasteners are securely tightened before use. Periodically check and re-tighten as needed.
- Do not overload drawers. Refer to the specifications for maximum weight capacity.
- Keep small parts and packaging materials away from children during assembly.
- The built-in power outlets and USB ports are UL/ETL certified. Do not exceed the specified electrical ratings.

Anti-Tip Device Installation

To prevent serious injury from tipping, this dresser must be permanently attached to the wall using the provided anti-tip device. This is crucial for the safety of children and pets.

ANTI-TIP LOCK DETAILS




Image: Detailed view of the anti-tip device and its installation process, emphasizing wall attachment for stability.

Package Contents

Before beginning assembly, ensure all parts are present and undamaged. If any parts are missing or damaged, please contact customer service.

- Dresser panels (top, bottom, sides, back)
- Drawer components (wooden and fabric)
- LED light strip and controller
- Power outlet and USB port module
- Metal handles and drawer slides
- Anti-tip device
- All necessary hardware (screws, dowels, etc.)
- Assembly tools (e.g., Allen wrench)

- Detailed assembly guide

Assembly Instructions

Assembly is required for this product. It is recommended that two people assemble the dresser, which typically takes approximately 1.5 hours. Follow the detailed assembly guide included in your package for step-by-step instructions.

1. Unpack all components and verify against the parts list in the assembly guide.
2. Identify each part, as they are clearly marked.
3. Follow the numerical sequence of steps in the assembly guide.
4. Ensure all connections are secure but do not overtighten screws.
5. Install the anti-tip device as instructed in the safety section and assembly guide.



Image: Diagram illustrating the overall dimensions of the dresser, including depth, width, and height.

Operating Instructions

LED Lighting System

The dresser is equipped with an LED light strip that offers 12 scene modes and 6000 colors. Control the lighting via the included remote control or a dedicated mobile application.

- **Power On/Off:** Use the remote or app to turn the LED lights on or off.
- **Color Selection:** Choose from 6000 colors to match your mood or decor.
- **Scene Modes:** Select from 12 pre-programmed scene modes for various atmospheres.
- **Brightness & Speed:** Adjust the brightness and speed of dynamic lighting effects.
- **Music Synchronization:** The lighting can synchronize with music, providing an immersive experience.



Image: Visual representation of the smart LED light features, including color options, music mode, and control methods.

Built-in Charging Station

The dresser includes 2 AC outlets and 2 USB ports for convenient charging of electronic devices. The power cord is 5 feet long.

- **AC Outlets:** Use for devices requiring standard AC power (125V/12A).

- **USB Ports:** Use for charging USB-powered devices (5V/2A).
- Ensure devices are compatible with the specified voltage and current.



Image: Close-up view of the integrated power strip with two AC outlets and two USB ports, showing devices connected for charging.

Drawer and Storage Features

The dresser offers ample storage with 6 large wooden drawers and 3 smaller fabric drawers (located above the open shelves). The drawers are designed for smooth operation and enhanced load-bearing capacity.

- **Smooth Operation:** Drawers are equipped with smooth rails and sturdy metal handles for easy opening and closing.
- **Load Capacity:** Extra support plates at the bottom of the drawers enhance their load-bearing capability.
- **Flexible Shelves:** The upper drawers can be removed to create open shelves, ideal for media equipment (e.g., DVD players, game consoles) or decorative items. This feature allows the dresser to function as a TV stand for TVs up to 65 inches.



Image: The dresser with one of the upper drawers removed, demonstrating how it converts into an open shelf for media devices or display.

9-DRAWER DRESSER with Flexible Shelves



100+
clothes



30+
Toys



120+
Cosmetics



80+
Stationery



50+
Diaper



80+
Snacks

Image: Infographic showing the various items that can be stored in the dresser's drawers and shelves, such as clothes, toys, cosmetics, and snacks.



Elegant metal handles



Metal Roller Glide



Sturdy Wood Pedestal



support plates more load-bearing

Image: Detailed views highlighting the quality features of the dresser, including elegant metal handles, smooth metal roller glides, sturdy wood pedestal, and support plates for enhanced load-bearing.

Product Video

Your browser does not support the video tag.

Video: An official product video demonstrating the features and functionality of the WLIVE 9-Drawer LED Dresser, including its use as a TV stand and storage capabilities.

Maintenance and Care

Proper care will extend the life and appearance of your dresser.

- **Cleaning:** The dresser is made of high-quality artificial wood, which is scratch-resistant and easy to clean. Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Spills:** Promptly wipe up any spills to prevent damage to the surface.
- **Sunlight:** Avoid prolonged exposure to direct sunlight to prevent fading.

- **Temperature & Humidity:** Maintain a stable room temperature and humidity level to prevent warping or cracking.



Image: A hand wiping water droplets from the dresser's surface, demonstrating its water-resistant properties and ease of cleaning.

Troubleshooting

If you encounter any issues with your dresser, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
LED lights not working	Loose connection, power issue, remote battery dead.	Check all cable connections. Ensure power outlet is functional. Replace remote battery.
Drawers are stiff or not sliding smoothly	Improper assembly, overloaded, debris in slides.	Verify assembly steps for drawer slides. Reduce drawer load. Clean slides of any obstructions.
Dresser feels unstable or wobbly	Loose fasteners, anti-tip device not installed.	Re-tighten all screws. Ensure anti-tip device is securely anchored to the wall.
Power outlets/USB ports not working	Not plugged in, circuit breaker tripped, faulty device.	Ensure the dresser's power cord is fully plugged into a working wall outlet. Check your home's circuit breaker. Test with a different device.

If the problem persists after attempting these solutions, please contact WLIVE customer support.

Specifications

Feature	Detail
Brand	WLIVE
Model Name	ASNG122 Wood dresser / QX
Product Dimensions	17.8"D x 58.35"W x 32.28"H
Color	Light Oak
Material	High quality artificial wood, fiberboard, non-woven fabric
Item Weight	122.7 pounds
Load Capacity (Overall)	Up to 228 LBS
Power Outlets	2 AC Sockets (125V/12A)

Feature	Detail
USB Ports	2 USB Ports (5V/2A)
Power Cord Length	1.5m (5-ft)
LED Light Features	12 Scene Modes, 6000 Colors, Adjustable Speed/Brightness, Music Sync
TV Compatibility	Suitable for TVs up to 65 inches

Warranty and Customer Support

WLIVE is committed to providing excellent quality products and customer service. Your product is backed by our commitment to quality.

- For any questions, missing parts, or issues during assembly or use, please refer to the detailed assembly guide or contact our professional after-sales team.
- Contact information for support can typically be found on the product packaging, the included assembly guide, or the official WLIVE website.
- Please retain your purchase receipt for warranty claims.

We are dedicated to ensuring your satisfaction and providing a worry-free experience.

© 2025 WLIVE. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

