

[Manuals.plus](#) /

› [BILITOK](#) /

› BILITOK Massage Chair User Manual

BILITOK 608-C2-Black

BILITOK Massage Chair User Manual

Model: 608-C2-Black

INTRODUCTION

Thank you for choosing the BILITOK Massage Chair. This manual provides essential information for the safe and effective operation, maintenance, and troubleshooting of your new massage chair. Please read this manual thoroughly before use and retain it for future reference.



Figure 1: The BILITOK Massage Chair, featuring its sleek design and comfortable seating, ready for use in a home environment.

SAFETY PRECAUTIONS

To ensure safe operation and prevent injury or damage, always adhere to the following safety guidelines:

- Do not use the chair if you have any medical conditions that may be aggravated by massage, such as severe osteoporosis, heart conditions, or pregnancy. Consult a physician before use.
- Keep children and pets away from the chair during operation.
- Ensure the power cord is not damaged and is properly plugged into a grounded outlet.
- Do not operate the chair in wet or damp environments.
- Avoid prolonged use. Limit massage sessions to 15-20 minutes.
- Do not stand on or apply excessive weight to the chair's components.

SETUP AND ASSEMBLY

The BILITOK Massage Chair is designed for easy assembly. Follow these steps to set up your chair:

1. **Unpacking:** Carefully remove all components from the packaging. Retain packaging for future transport or storage.
2. **Positioning:** Place the chair on a flat, stable surface. The chair features moving rollers at the bottom for easy repositioning within your room.
3. **Assembly:** Connect any detached components as per the included quick-start guide. Ensure all connections are secure.
4. **Power Connection:** Plug the power cord into a suitable grounded electrical outlet.



Figure 2: The chair is designed for fast delivery and easy assembly, with clear dimensions provided for placement consideration.

FOOT ROLLER MASSAGE

Multiple functions to relieve
sore muscles



Figure 3: Moving rollers located at the bottom of the chair allow for convenient repositioning and mobility.

OPERATING INSTRUCTIONS

Familiarize yourself with the control panel and various massage functions to customize your experience.

Control Panel Overview

The intuitive touch screen control panel allows you to select massage modes, adjust intensity, and activate special features.



Figure 4: The touch screen control panel provides easy access to all massage functions and settings.

Zero Gravity Mode

Activate the Zero Gravity mode to recline the chair to an optimal position where your feet are elevated above your heart. This posture helps to lighten the load on your heart, stimulate blood circulation, and provide a deeper sense of relaxation. The armrests and body tilt simultaneously, ensuring continuous arm massage.

ZERO GRAVITY DESIGN



Figure 5: Illustration of the Zero Gravity design, showing initial, comfort, and deep zero gravity recline positions.

Your browser does not support the video tag.

Video 1: Demonstrates the Zero Gravity feature of the BILITOK Massage Chair, showing how it reclines to reduce pressure and enhance relaxation.

Full-Body Massage Functions

The chair offers a comprehensive full-body massage experience:

- **6 Fixed Rollers:** Located in the backrest, these rollers target your neck, back, and waist. Choose from 5 preset automatic modes for varied massage experiences.
- **Full Body Airbags:** Airbags are strategically placed to pinch and massage your shoulders, arms, and calves. Adjust the air compression strength with three-gear settings.
- **Foot Rollers:** Located at the base of the footrest, these rollers knead and stimulate acupuncture points, promoting blood circulation and relieving muscle tension in the feet. The footrest is retractable to accommodate different user heights.

FULL BODY MASSAGE



Airbags massage:
Massage shoulders, arms, calves



Rapid heating:
Heating function, relax muscles

Figure 6: Overview of the full body massage system, highlighting airbag massage for shoulders, arms, and calves, and rapid heating for muscle relaxation.

6 MASSAGE ROLLERS

Providing a massage customized just for you
and release full body fatigue



Figure 7: The 6 massage rollers provide a customized massage experience to release full body fatigue.

Heating Function

The massage chair includes heating functions for both the waist and legs. This feature helps to promote blood circulation and effectively relieve muscle soreness and tension.

Bluetooth Speaker

Connect your smartphone or other Bluetooth-enabled device to the chair's integrated Bluetooth speaker. Enjoy your favorite music or audio content while experiencing a relaxing massage.



Figure 8: The chair features a Bluetooth audio connection, allowing users to enjoy music during their massage.

Humanized Design Features

- **Automatic Hover:** After a massage session concludes, the chair automatically maintains the zero gravity mode, allowing you to remain in a relaxed, reclined position for continued comfort or to ease into sleep.
- **Atmosphere Lights:** Breathing blue atmosphere lights on both sides of the chair create a soothing and relaxing ambiance during your massage.
- **Phone Holder:** A convenient phone holder is integrated for easy access to your device.

MAINTENANCE AND CARE

Proper maintenance ensures the longevity and optimal performance of your massage chair.

- **Cleaning:** Wipe the chair's surface with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Storage:** If storing the chair for an extended period, ensure it is clean, dry, and covered to protect it from dust.
- **Inspection:** Regularly inspect the power cord and all connections for any signs of wear or damage.

TROUBLESHOOTING

If you encounter any issues with your massage chair, refer to the following common troubleshooting tips:

Problem	Possible Cause	Solution
Chair does not power on.	Power cord not connected; power outlet issue.	Ensure power cord is securely plugged in. Test the outlet with another device.
Massage function not working.	Incorrect mode selected; safety feature activated.	Check the control panel for selected mode. Ensure no objects are obstructing moving parts.
Unusual noise during operation.	Loose component; normal operational sound.	Verify all parts are securely fastened. Some operational sounds are normal. If noise is excessive, contact customer support.
Bluetooth not connecting.	Device not in pairing mode; interference.	Ensure your device's Bluetooth is on and in pairing mode. Move closer to the chair.

If the problem persists after attempting these solutions, please contact customer support.

SPECIFICATIONS

Feature	Detail
Brand	BILITOK
Model Name	608-C2-Black
Color	Blue
Product Dimensions (D x W x H)	43.3"D x 28.7"W x 27.6"H
Maximum Weight Recommendation	300 Pounds
Item Weight	100 pounds
Material	Foam (Fill Material)
Reclining Position Count	2
UPC	709347458061
ASIN	B0DY7HRNPS

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the official BILITOK customer support channels. You can visit the BILITOK Store on Amazon for more information and contact options:[BILITOK Store](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question