

Texciting TW1-B-F

Texciting Heated Blanket Electric Throw User Manual

MODEL: TW1-B-F (50"x60" THROW)

Introduction

This manual provides essential instructions for the safe and efficient use of your Texciting Heated Blanket Electric Throw. Please read all instructions carefully before use and retain this manual for future reference.

Important Safety Instructions

When using electrical appliances, basic precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

1. Read all instructions before using this heated blanket.
2. Do not use this blanket with an infant, a child, an incapacitated person, or anyone insensitive to heat, such as a person with poor blood circulation.
3. Do not use this blanket on an animal.
4. Never use the blanket if the cord or plug is damaged.
5. Do not use this blanket in conjunction with another heating pad or blanket.
6. Do not use this blanket if it is wet.
7. Keep the control unit away from open windows or heat sources.
8. Do not tuck in the control unit or power cord.
9. This blanket is equipped with an Overheat Protection System and a 3-hour automatic shut-off for safety. Do not attempt to override these features.
10. Always unplug the blanket from the electrical outlet when not in use.

Setup

Follow these steps to set up your heated blanket:

1. **Unpack:** Carefully remove the heated blanket and controller from its packaging.

2. **Inspect:** Check the blanket, power cord, and controller for any signs of damage. Do not use if damaged.
3. **Connect Controller:** Ensure the controller cable is securely plugged into the blanket's connector.
4. **Placement:** Lay the blanket flat on a bed, sofa, or chair. Ensure the control unit is placed on a flat, stable surface where it will not be covered.
5. **Power Connection:** Plug the power cord into a standard 120V AC electrical outlet. Ensure the connection is snug.



Image: The Texciting Heated Blanket Electric Throw, folded, with its detachable controller. This image illustrates the product's appearance and the controller's connection point.


Operating Instructions

Your heated blanket features a user-friendly controller with multiple heat settings and an automatic shut-off function.

1. **Power On/Off:** Press the power button on the controller to turn the blanket on or off.
2. **Adjust Heat Settings:** Use the control buttons to cycle through the 5 available heat settings. The indicator lights on the controller will show the selected heat level (1 being the lowest, 5 being the highest).
3. **Automatic Shut-Off:** The blanket is designed with a 3-hour automatic shut-off timer for safety and energy conservation. After 3 hours of continuous operation, the blanket will automatically turn off. To restart, simply turn the blanket off and then on again using the power button.

5 Heating Settings

Fast warming with fully adjustable heat control.

86°F  113°F



3 Hours
Auto Off



5 speed
Control



ETL
Certified



Image: A close-up view of the blanket's digital controller, highlighting the 5 heat settings and the 3-hour auto-off indicator. This demonstrates the user interface for temperature and timer control.



Image: The purple heated blanket draped over a classic wooden chair, showcasing its use as a comfortable throw in a home setting. The controller is visible hanging from the side.

Maintenance

Proper care ensures the longevity and performance of your heated blanket.

1. **Before Cleaning:** Always unplug the blanket from the wall outlet and detach the controller from the blanket. Allow the blanket to cool completely.
2. **Machine Washing:** The blanket is machine washable. Wash in cold water on a gentle cycle.
3. **Drying:** Tumble dry on low heat. Ensure the blanket is completely dry before reattaching the controller or storing.
4. **Do Not:** Do not iron, bleach, or dry clean the blanket. These actions can damage the heating elements and fabric.
5. **Storage:** When not in use, store the blanket in a cool, dry place. Avoid folding it tightly or placing heavy objects on it, which could damage the internal wiring.



Image: A purple heated blanket neatly folded inside a wicker basket, accompanied by a graphic indicating it is machine washable. This visually confirms the ease of cleaning.

Troubleshooting

If your heated blanket is not operating correctly, please refer to the following common issues and solutions:

- **Blanket Not Heating:**
 - Ensure the power cord is securely plugged into a working electrical outlet.
 - Verify that the controller cable is firmly connected to the blanket.
 - Check if the automatic shut-off timer has activated (after 3 hours). Turn the blanket off and then on again.
 - Ensure no other heating devices are being used simultaneously with the blanket.
- **Controller Displaying Error Code:**
 - Unplug the blanket from the wall outlet for 5 minutes, then plug it back in.
 - Ensure all electrical connections (wall outlet, controller to blanket) are secure and snug. Loose connections can sometimes trigger error codes.
- **Uneven Heating:**

- Ensure the blanket is laid flat and not bunched or folded during use, which can impede heat distribution.

If the problem persists after attempting these solutions, discontinue use and contact customer support.

Specifications

Model Number	TW1-B-F
Dimensions	50 inches (W) x 60 inches (L)
Material	100% Polyester
Heat Settings	5 levels
Auto-Off Timer	3 Hours
Certifications	ETL, FCC
Power Source	Corded Electric
Weight	Approximately 3.3 pounds

Warranty and Support

For warranty information or technical support, please refer to the documentation included with your purchase or contact Texciting customer service directly. Contact details can typically be found on the product packaging or the official Texciting website.