

VEVOR ET1611

VEVOR ET1611 Pole Cordless Hedge Trimmer User Manual

Model: ET1611 | Brand: VEVOR

1. INTRODUCTION

The VEVOR ET1611 Pole Cordless Hedge Trimmer is designed for efficient and convenient trimming of hedges and bushes. This 20V electric tool features an 18-inch double-edged steel blade and a telescoping design, allowing users to reach high branches and low-lying areas with ease. Its lightweight construction and adjustable features make it suitable for various gardening tasks, transforming overgrown areas into neat landscapes.

2. SAFETY INFORMATION

Always prioritize safety when operating power tools. This hedge trimmer is equipped with double safety switches, requiring both the main handle switch and the sub-handle switch to be engaged for operation. Releasing either switch immediately stops the blade, enhancing user control and safety. Always wear appropriate personal protective equipment, including safety glasses and gloves, during operation. Store the blade in its protective cover when not in use to prevent accidental injury and protect the blade.

3. COMPONENTS

The VEVOR ET1611 Pole Cordless Hedge Trimmer comes with several key components designed for optimal performance and safety. Refer to the diagrams below for a visual guide to the parts.



Figure 3.1: Main components of the VEVOR Pole Cordless Hedge Trimmer, highlighting the dual-action blade, safety switches, and battery.



Figure 3.2: A comprehensive view of the VEVOR ET1611, showing its overall dimensions and the complete set of accessories provided, including the battery, charger, shoulder strap, safety glasses, and protective gloves.

4. SETUP

Before operating your VEVOR Pole Cordless Hedge Trimmer, ensure proper assembly and battery preparation.

1. **Assembly:** The trimmer features a 2-in-1 design. To assemble the pole configuration, simply tighten the two pole sections together. No additional tools are required.
2. **Battery Charging:** The 20V, 2.0Ah high-capacity battery requires approximately 1 hour for a full charge using the provided fast charger. Ensure the battery is fully charged before first use.
3. **Battery Installation:** Insert the charged battery securely into the designated slot on the trimmer handle until it clicks into place.

Your browser does not support the video tag.

Video 4.1: This video demonstrates the quick and easy installation process of the VEVOR Pole Cordless Hedge Trimmer, highlighting how to assemble the pole and attach the head.

5. OPERATING INSTRUCTIONS

The VEVOR Pole Cordless Hedge Trimmer offers versatile operation for various trimming needs.

1. **Starting the Trimmer:** Engage both the main handle switch and the sub-handle switch simultaneously to start the trimmer. Release either switch to stop the blades.
2. **Adjusting Pole Length:** The telescoping pole allows for an adjustable height range of 74-94 inches (188-239 cm). Adjust the pole to the desired length by loosening the locking mechanism, extending or retracting the pole, and then securing the lock.
3. **Adjusting Head Angle:** The trimmer head can rotate from 30° to 150°, offering five adjustable angles. This flexibility allows for trimming hard-to-reach tree branches, low-lying lawns, and shaping hedges.
4. **Trimming Techniques:**
 - **Flat Trimming:** Use the adjustable head to achieve a flat top on hedges.
 - **Spherical Trimming:** Adjust the head angle for shaping rounded bushes.
 - **High Branch Trimming:** Utilize the extended pole and adjustable head to reach elevated areas without a ladder.
 - **Low Branch/Lawn Trimming:** Adjust the head for comfortable trimming of lower sections or ground cover.
5. **Shoulder Strap:** For prolonged comfort and stability, especially when working at elevated positions, attach and use the provided shoulder strap.

VEVOR[®]
TOUGH TOOLS, HALF PRICE

Sub Handle Switch

Sub Handle Switch

5/8" Cutting Capacity

20V 2.0Ah

Dual Action Hardened Steel Blade



Safety Lock



Easy Installation



Double Safety Switch

Figure 5.1: Man using the VEVOR pole hedge trimmer to trim a tall hedge, demonstrating its extended reach of up to 94 inches.



Figure 5.2: A visual guide to the adjustable head angles of the trimmer, showcasing its versatility for different trimming styles like high reach, spherical, and lawn trimming.

Your browser does not support the video tag.

Video 5.1: This video provides an overview of the VEVOR Upgraded Cordless Hedge Trimmer, demonstrating its features and various applications for garden maintenance.

6. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your hedge trimmer.

1. **Blade Cleaning:** After each use, clean the blades of any sap, debris, or plant residue. Use a stiff brush and a suitable cleaning solution if necessary.
2. **Blade Lubrication:** Apply a light machine oil or blade lubricant to the cutting blades periodically to ensure smooth operation and prevent rust.
3. **Blade Storage:** Always store the trimmer with the blade in its protective cover to prevent accidental contact and protect the blades from damage and corrosion.
4. **Battery Care:** Store the battery in a cool, dry place. Avoid fully discharging the battery for extended periods.

Charge it regularly, even when not in use, to maintain battery health.

7. TROUBLESHOOTING

If you encounter issues with your VEVOR Pole Cordless Hedge Trimmer, refer to these common troubleshooting tips.

- **Trimmer Not Starting:**
 - Ensure the battery is fully charged and properly installed.
 - Verify that both safety switches (main and sub-handle) are engaged simultaneously.
- **Reduced Cutting Performance:**
 - Check if the blades are clean and free of debris.
 - Inspect blades for dullness or damage; sharpen or replace if necessary.
 - Ensure the battery has sufficient charge.
- **Unusual Noise or Vibration:**
 - Immediately stop the trimmer.
 - Inspect the blades and motor housing for any loose parts or obstructions.
 - If the issue persists, contact customer support.

8. SPECIFICATIONS

Feature	Specification
Brand	VEVOR
Model Number	ET1611
Power Source	Battery Powered (20V, 2.0Ah)
Blade Length	18 Inches
Cutting Thickness	5/8 inch
Speed	17500 RPM
Material Type	Alloy Steel
Blade Material	Double-edged Steel
Product Dimensions	34.45"L x 5.91"W x 3.94"H
Item Weight	7.9 Pounds
Extendable Length	74-94 inch / 188-239 cm

9. WARRANTY AND SUPPORT

For warranty information, technical assistance, or replacement parts, please contact VEVOR customer support through their official website or the retailer where the product was purchased. Keep your purchase receipt and

model number (ET1611) handy for faster service.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question